# Getac

# T800
## OFFICE DOCK
## USER GUIDE

# 1. *Introduction*

The office dock duplicates most of your computer's ports and provides extra ports.

With peripherals such as a keyboard, mouse, monitor, and printer all connected to the office dock, you have a handy work area on your desk.

Release Latch

Docking Connector

DC-In LED

Getac

Holding Clamp

Kensington Lock

Power Connector

Microphone Connector

Audio Output Connector

LAN (RJ45) Port

USB 2.0 Port x 3

VGA Port

USB 3.0 Port

# 2. *Installation*

1. Push the release latch toward the right. The holding clamp will slide up slowly.



2. Align the connector and place T800 on the dock. Press down the holding clamp until it clicks into place.



3. Connect the cables of peripheral devices to the corresponding connectors on your office dock.

4. Connect the AC adapter to the office dock. The DC-In LED lights up.

*See reverse side for notes and precautions.*

# 3. *Notes and Precautions*

- When the office dock is connected, the USB 3.0 port on your T800 will be disabled.

- **DO NOT** touch the connectors of the office dock.

- **DO NOT** attempt to make connections if there is any object between the computer and the office dock. Doing so could damage the computer and the office dock.

- **DO NOT** attempt to move the office dock when it is connected to the computer.

- If the computer malfunctions while the office dock is connected, turn off the computer and disconnect the office dock. Connect the AC adapter to the computer and check to see if the computer operates normally. If the computer operates normally, the office dock may be malfunctioning.

- **DO NOT** place metal objects or containers of liquid on top of the office dock. If metal objects (such as paper clips and coins) or any liquid spills get inside the office dock, fire or electric shock may result. Immediately unplug the power cable and remove the computer from the office dock.

- Unplug the power cord and remove the computer from the office dock if any of the following occurs:
  – the office dock is damaged
  – smoke is emitted
  – an unusual smell is emitted
  – the office dock is unusually hot
  Continuing to use the office dock while any of the above conditions are present may result in fire or electric shock.

## Getac Contact Information

$CE$

| Company name | Getac Technology GmbH. |
|---|---|
| Address | Kanzlerstrasse 4 40472 Dusseldorf |
| Phone | +49 (0) 211-984819-0 |

**UKCA**

| Company name | Getac UK Ltd. |
|---|---|
| Address | Getac House, Stafford Park 12, Telford, Shropshire, TF3 3BJ, UK |
| Phone | +44 (0) 1952-207-222 |

**FC**

| Company name | Getac Inc. |
|---|---|
| Address | 15495 Sand Canyon Rd., Suite 350 Irvine, CA 92618 USA |
| Phone | +1-949-681-2900 |

5 6 1 8 1 2 2 1 0 0 0 3  R 0 1