




Camera cover. Capable of physically disabling the camera function for privacy protection.



Plug in the included ac power adapter to this power connector. This is required before you turn on your computer for the first time.

 Selected models are equipped with the fan, which may generate considerable noise. This is normal and not a cause of concern.



Fn shortcuts

- + Q** Switches among the computer's operating modes
- + M** Enables/disables the touchpad



One-touch access to the Lenovo service website



Answer calls (Microsoft Teams)



Decline calls (Microsoft Teams)



PAP



SP11K53373
BK