Updated energy conservation features

Use Sleep and Inactivity Shutdown to conserve electricity.

NOTE: Configuring longer times for these settings or turning off these features will increase energy consumption.

- **Sleep**

  After initial setup, the printer enters Sleep mode by default after a preset time of inactivity.

- **Inactivity Shutdown**

  This feature turns the printer off completely after a default period of inactivity to help reduce energy use. Press the **Power** button to turn on the printer again.

  Inactivity Shutdown is disabled when a printer wireless or **Wi-Fi Direct** capability is turned on or when a printer with USB or Ethernet network capability establishes a USB or Ethernet network connection.

Follow these steps to change the settings:

1. On the control panel Home screen, touch **Menu**.
2. Scroll to **Utilities** and touch **Settings**.
3. Touch **General**, and then touch **Energy**.
4. Select the feature and change the desired settings.

© Copyright 2024 HP Development Company, L.P.