

Interactive Part Locator

HP Pro c640 G2 Chromebook

Welcome to the interactive part locator for the
HP Pro c640 G2 Chromebook

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.


 To exit or enter full screen mode, press Ctrl + L on your keyboard

External Views


[Back to Welcome page](#)




Front



Left



Right



Rear



Display



Top



Bottom



Internal

[Go to Parts List](#)

Front View


[Back to External Views](#)



[Go to Parts List](#)

Left View


[Back to External Views](#)



[Go to Parts List](#)

Right View

[Back to External Views](#)



[Go to Parts List](#)

Rear View

[Back to External Views](#)




Hinge

[Go to Parts List](#)

Display View


[Back to External Views](#)



[Go to Parts List](#)

Top View


[Back to External Views](#)



[Go to Parts List](#)

Bottom View


[Back to External Views](#)



[Go to Parts List](#)

Internal View

[Back to External Views](#)




[Go to Parts List](#)

Base Enclosure

Base Enclosure

- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



[Go to External Views](#)

Base Enclosure

Battery

M.2 Solid State Drive

Speakers

Touchpad

Fingerprint Reader

System Fan

USB Board

Heat Sink

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel Assembly

Hinge Cap

Display Bezel

Display Panel

Hinges

Display Panel Cable


Webcam

Display Panel Bracket

Webcam Cable

Wireless LAN Antenna Cables


Battery



Go to External Views

- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables


M.2 Solid State Drive



Go to External Views

Speakers



- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers**
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



Go to External Views

Touchpad


Base Enclosure
Battery
M.2 Solid State Drive
Speakers
Touchpad
Fingerprint Reader
System Fan
USB Board
Heat Sink
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel Assembly
Hinge Cap
Display Bezel
Display Panel
Hinges
Display Panel Cable
Webcam
Display Panel Bracket
Webcam Cable
Wireless LAN Antenna Cables



[Go to External Views](#)

Fingerprint Reader


- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader**
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



[Go to External Views](#)

System Fan


- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



Go to External Views

- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables


USB Board



Go to External Views

- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables

Heat Sink



Go to External Views

System Board (top)

Base Enclosure

Battery

M.2 Solid State Drive

Speakers

Touchpad

Fingerprint Reader

System Fan

USB Board

Heat Sink

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel Assembly

Hinge Cap

Display Bezel

Display Panel

Hinges



Display Panel Cable

Webcam

Display Panel Bracket

Webcam Cable



Wireless LAN Antenna Cables



[Go to External Views](#)

System Board (bottom)

- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)**
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



[Go to External Views](#)

Top Cover with Keyboard


- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard**
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



Go to External Views

Display Panel Assembly


- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



[Go to External Views](#)

Hinge Cap


- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



Go to External Views

Display Bezel


Base Enclosure
Battery
M.2 Solid State Drive
Speakers
Touchpad
Fingerprint Reader
System Fan
USB Board
Heat Sink
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel Assembly
Hinge Cap
Display Bezel
Display Panel
Hinges
Display Panel Cable
Webcam
Display Panel Bracket
Webcam Cable
Wireless LAN Antenna Cables



[Go to External Views](#)

Display Panel

- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel**
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



[Go to External Views](#)

Hinges


Base Enclosure
Battery
M.2 Solid State Drive
Speakers
Touchpad
Fingerprint Reader
System Fan
USB Board
Heat Sink
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel Assembly
Hinge Cap
Display Bezel
Display Panel
Hinges
Display Panel Cable
Webcam
Display Panel Bracket
Webcam Cable
Wireless LAN Antenna Cables



[Go to External Views](#)

Display Panel Cable


- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



[Go to External Views](#)

Webcam


- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam**
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables



[Go to External Views](#)

Display Panel Bracket


Base Enclosure
Battery
M.2 Solid State Drive
Speakers
Touchpad
Fingerprint Reader
System Fan
USB Board
Heat Sink
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel Assembly
Hinge Cap
Display Bezel
Display Panel
Hinges
Display Panel Cable
Webcam
Display Panel Bracket
Webcam Cable
Wireless LAN Antenna Cables



[Go to External Views](#)

Webcam Cable


Base Enclosure
Battery
M.2 Solid State Drive
Speakers
Touchpad
Fingerprint Reader
System Fan
USB Board
Heat Sink
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel Assembly
Hinge Cap
Display Bezel
Display Panel
Hinges
Display Panel Cable
Webcam
Display Panel Bracket
Webcam Cable
Wireless LAN Antenna Cables



[Go to External Views](#)

Wireless LAN Antenna Cables

- Base Enclosure
- Battery
- M.2 Solid State Drive
- Speakers
- Touchpad
- Fingerprint Reader
- System Fan
- USB Board
- Heat Sink
- System Board (top)
- System Board (bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Hinge Cap
- Display Bezel
- Display Panel
- Hinges
- Display Panel Cable
- Webcam
- Display Panel Bracket
- Webcam Cable
- Wireless LAN Antenna Cables**



[Go to External Views](#)