



## DJI Osmo Pocket 3 Release Notes

---

Date:	2023.11.13
Firmware Version:	v01.01.08.70
DJI Mimo App iOS:	v1.11.2
DJI Mimo App Android:	v1.11.2

---

### What's New

- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart Osmo Pocket 3 and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect Osmo Pocket 3 to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.



## DJI Osmo Pocket 3 Release Notes

---

Date:	2023.10.25
Firmware Version:	v01.01.08.40
DJI Mimo App iOS:	v1.11.0
DJI Mimo App Android:	v1.11.0

---

### What's New

- Added Image Adjustment. Sharpness and Noise Reduction level can be customized in Video, Slow Motion, and Hyperlapse modes (0 is default, -2 is lowest).
- Added Screen Rotate & Capture. When enabled, shooting will be started as soon as the touchscreen has been rotated clockwise to power on the camera. After shooting, the camera will automatically power off if left idle for two seconds.
- Added Low-Light shooting mode, helping improve image quality and reduce noise in low-light environments.
- Optimized image quality and enhanced color performance.
- Optimized the skin tone performance in multiple scenes.
- Optimized accuracy and stability for auto-focus in multiple scenes.
- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart Osmo Pocket 3 and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect Osmo Pocket 3 to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.