

OMEN by HP 40L Gaming Desktop PC - Upgrading the top fans

On your computer, you can install up to two 120 mm × 120 mm top fans.

Install the top fans

Use this procedure to install top fans into the computer.

1. Remove the glass front bezel.



2. Remove the left side access panel.



3. From the back of the computer, push the top cover forward, and then lift it off the computer.



4. Position the computer on its side.
5. Find the installation locations for the fans on the inside top of the computer.



6. Place the fans onto the inside wall of the computer.




NOTE: To prevent overheating, be sure to position the fans so that air flows out of the computer. Arrows on the fans indicate the airflow direction.



7. From the outside of the computer, secure each fan with four screws.



8. Connect the fan cable to an empty four-pin fan power connector on the system board. If an empty fan power connector is not available, connect a Y cable to a populated fan power connector to power additional fans.



9. Be sure that you route the fan power cable inside the computer so that it does not interfere with the fan blades.
10. Install the top cover.
11. Install the left side access panel.
12. Install the glass front bezel.