

Using the T800 Shoulder Strap

1. The shoulder strap includes a long strap and two short straps at both ends. For the installation, you need to temporarily detach the short straps. Open the snap buttons to detach the short strap.
2. Using the supplied wire as a tool, pull the loop of the short strap through the holder at one corner of T800 (as indicated by **1** below). Then, insert the strap through the loop (as indicated by **2** below) and pull it tight.



3. Insert the short strap through the bracket of the long strap and button up the short strap. Make sure that the two buttons click into place.



4. Follow the same procedure to secure the strap to the other side of T800.
5. You can adjust the strap length using the sliding loop.



NOTE: If you want to temporarily remove the shoulder strap, simply unbutton the short straps to detach the long strap. The red line on the short strap helps you quickly locate where to unbutton.



5 6 1 8 1 2 2 1 0 0 0 8 R 0 1