

RMN/型號/型号: HSN-NL02


© Copyright 2020, 2021 HP Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.


Third Edition: November 2021
First Edition: October 2020

M16137-B23


1*




2*




3*




4




5



6



7



<https://www.hp.com/support>

Go to www.hp.com/support to locate your user guide, drivers, and software.



CAUTION: Turn off all power and disconnect the power cord before inserting or removing this device from the USB port.

* Required for HP Engage One Essential AIO System only.

