

HP is committed to reducing the environmental impact of our products. As part of our continuing efforts, HP is moving more content to the web and to your hard drive. This card directs you to appropriate resources. Thank you for purchasing an HP computer!

Locating resources

Where do I find?	See one or more of the following:
QuickSpecs	Go to https://www.hp.com/go/quickspecs to view the QuickSpecs for your computer model.
Replacement videos and other resources	Go to https://www.youtube.com/hpsupport where you can access removal and replacement videos and other resources.
Documentation	Go to https://www.hp.com/support, and follow the instructions to find your product and view a list of available documentation.
	To access the user guides:
	Windows® products: Select the Search icon (select products only) in the taskbar, type HP Documentation in the search box, and then select HP Documentation .
	Linux® products: Double-click the HP Documents icon.
Diagnostics, troubleshooting, software, and drivers	Go to https://www.hp.com/support , and follow the instructions to find your product. You can find the following types of assistance:
	Troubleshooting a problem (self-help documents)
	Diagnosing a problem
	Customer Advisories or Customer Notices
	Available software and drivers
US support	For U.S. support, go to https://www.hp.com/support, and follow the instructions to
	find your product. Here you can access the following types of support:
	Online chat with an HP technician
	Support telephone numbers Paplace parts video (select products only)
	Replace parts video (select products only)Maintenance and service guides
	HP service center locations
	- FIF Service certier tocations
Warranty information	You can find your HP Limited Warranty located with the user guides on your product and/or on the CD or DVD provided in the box. In some countries or regions, HP may provide a printed warranty in the box. For countries or regions where the warranty is not provided in printed format, you can request a copy from https://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

Quick setup

- 1. Connect the monitor to the computer.
- 2. Plug the computer power cord and monitor power cord into an AC outlet.
- 3. Connect the mouse and keyboard to the computer.
- 4. Turn the computer on.
- 5. Connect a network cable to the RJ-45 (network) jack or set up a WLAN connection via an Internet router.
- 6. Connect other peripheral devices (such as a printer) according to the instructions included with the device.

End User License Agreement

By installing, copying, downloading, or otherwise using any software product preinstalled on this computer, you agree to be bound by the terms of the HP End User License Agreement (EULA). If you do not accept these license terms, your sole remedy is to return the entire unused product (hardware and software) within 14 days for a full refund subject to the refund policy of your seller. For any further information or to request a full refund of the price of the computer, please contact your seller.

Warnings



WARNING! To reduce the risk of electric shock:

- Plug the power cord into an AC outlet that is easily accessible at all times.
- If the power cord has a 3-pin attachment plug, plug the cord into a grounded (earthed) 3-pin outlet.

For more safety, regulatory, labeling, battery disposal information, and Restriction of Hazardous Substances (RoHS), see the *Regulatory, Safety, and Environmental Notices* provided with your user guides. To locate the user guides for your computer, see the "Locating resources" section of this poster.

WARNING! To reduce the risk of serious injury, read the *Safety & Comfort Guide* provided with your user guides. It describes proper workstation setup, and proper posture, health, and work habits for computer users. The *Safety & Comfort Guide* also provides important electrical and mechanical safety information. The *Safety & Comfort Guide* is also available on the web at https://www.hp.com/ergo.

WARNING! To reduce the possibility of heat-related injuries or of overheating the computer, do not place the computer directly on your lap or obstruct the computer air vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to come into contact with the skin or a soft surface, such as pillows or rugs or clothing, during operation. The computer and the AC adapter comply with the user-accessible surface temperature limits defined by applicable safety standards.



WARNING! If a product is shipped in packaging marked with this symbol, **T**, the product must always be lifted by two persons to avoid personal injury due to product weight.

Documentation feedback

To help us improve this document, please send any suggestions, comments, or errors to **hp.doc.feedback@hp.com**. Include the document part number (located near the barcode) when submitting your feedback.

© Copyright 2021 HP Development Company, L.P.

Windows® is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries. Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services.

Not all features are available in all editions or versions of Windows. Systems may require upgraded and/or separately purchased hardware, drivers, software or BIOS update to take full advantage of Windows functionality. Windows is automatically updated, which is always enabled. High-speed internet and Microsoft account required. ISP fees may apply and additional requirements may apply over time for updates. See http://www.windows.com. If your product ships with Windows in S Mode: Windows in S Mode works exclusively with apps from the Microsoft Store within Windows. Certain default settings, features, and apps cannot be changed. Some accessories and apps that are compatible with Windows may not work (including some antivirus, PDF writers, driver utilities, and accessibility apps), and performance may vary, even if you switch out of S Mode. If you switch to Windows, you cannot switch back to S Mode. Learn more at Windows, com/SmodeFAO.

Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Third Edition: December 2021 First Edition: August 2021