

Interactive System Board Viewer

HP Engage One Pro AIO System

Welcome to the interactive System Board for the
HP Engage One Pro AIO System

Here's how to use it...

[Zoomable View](#) (Click the link to navigate to the viewer)



On the Zoomable View page, you will find the viewer's zoom navigation links above the viewer on the left-hand side. You can choose from four levels of magnification: 1x, 2x, 3x, and 4x.

1x: The default magnification is 1x and at this magnification you can view the location of a feature by selecting it from the numbered list on the left.



2x, 3x, 4x: When you choose a greater magnification level, you use the navigation arrows and numbered features list to focus on the feature that you wish to review.

That's it!


1x view





2 X View




1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector






2 X View

1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector





A detailed photograph of a laptop motherboard with various components labeled with orange circles and numbers. The labels are: 1. USB port, 2. Small circular component (possibly a sensor or capacitor), 3. Small rectangular component, 4. Small rectangular component, 6. Large square component (likely a CPU or GPU), 18. Small rectangular component, 19. Small rectangular component, 20. Small rectangular component, 21. Small rectangular component, 22. Small rectangular component.




1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector



2 X View




1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector





3 X View




1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector






3 X View



1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector






3 X View





1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector

3 X View






1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector

4 X View




1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector








4 X View






4 X View



1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector




4 X View




1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector




4 X View



1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector





4 X View




1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector




4 X View



1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector






4 X View



1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector

4 X View



1. USB 3.1 port
2. CPU Fan connector
3. Backlight board connector
4. CPU XDP connector
5. M.2 Memory Module sockets
6. CPU socket
7. Top USB 3.1 port
8. 2x M.2 Solid State Drive sockets
9. NFC board connector
10. M.2 Wireless LAN socket
11. Flood Sensor
12. USB 3.1 port
13. Left USB 3.1 port
14. Fan connector
15. CMOS Battery socket
16. CMOS Reset button
17. Power Button Board connector
18. EDP connector
19. Speaker connector
20. RJ-45 connector
21. Bottom USB 3.1 port
22. LVDS connector