







**PARTS & QUANTITY**

PARTS		LLR84270	LLR84171
Phillips Screws (for tray)		2pcs	4pcs
Wall Brackets		2pcs	2pcs
Drywall Anchors		4pcs	4pcs
Phillips Screws (for bracket)		4pcs	4pcs
Phillips Head Tip		1pc	1pc


**SECURING MARKER/ERASER TRAY TO BOARD FRAME**

1. Position Marker/Eraser Tray at desired location along board rail.
2. Place screws into board rail where the pre-drilled holes are on the pen tray. Tighten with phillips head tip.
3. Check results. If not satisfied, start over from the beginning.



**MOUNTING INSTRUCTIONS**

1. Punch or drill holes in wall that are no larger than 1/4" in diameter. Insert anchors into holes so that they are set firmly into wall. Attach bracket into anchors with screws. Do not over tighten.



2. Place back of frame over top of wall bracket so that wall bracket slips between back of board and metal frame. Center board on brackets.

