












**IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.**

MODEL: B330A B331A

(1)x1  BACK	(2)x1  SEAT	(3)x5  CASTERS
(4)x1 (L)x1 (R)  LARM LEFT ARM RARM RIGHT ARM	(5)x1  GAS LIFT	(6)x1  BASE
(7)x1  MECHANISM	(A)x4  M8*22 MECHANISM SCREW	(B)x4  M8*30 L-BAR SCREW
	(C)x8  M6*22 ARM SCREW	



B330A



B331A

Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.