


Remove all items from the carton. Verify all pieces before assembly


PARTS LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
A	5	Caster	F	2	Arm Rest	K	12	Armrest+Mechanism flat Washer(6*18*1MM)
B	1	Base	G	1	Back Rest	L	4	Backrest Washer (8*22*1.5MM)
C	1	Gas lift	H	8	Armset Screw M6*35mm	M	7	Lock Washer (M8)
D	1	Mechanism	I	4	Mechanism Screw M6*25mm	N	1	Allen Wrench
E	1	Seat	J	3	Backrest Screw M8*18mm			


STEP 1.




STEP 2.



STEP 3.



STEP 4.



STEP 5.



NOTICE:
EVERY 6 MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY

MECHANISM OPERATION INSTRUCTION WHILE SEATED:

(1) SEAT HEIGHT ADJUSTMENT


Pull lever up, release lever when desired position is reached

(2) TILT LOCK

Tilt back. When desired position is reached pull lever down

(3) TILT TENSION ADJUSTMENT KNOB

Rotate knob clockwise/counterclockwise to adjust tilt tension based on body weight.



PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE THIS CHAIR AS A STEP STOOL/LADDER.
- DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
- DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
- DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHT.
- AT LEAST EVERY SIX MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY ARE TIGHT.

- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
- DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING-IT MAY CAUSE SUFFOCATION.
- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.