











**IMPORTANT NOTICE:  
HARDWARE PACKAGE IS ATTACHED  
ON THE BOTTOM OF SEAT CUSHION.**

MODEL : B994

(1)X1	(2)X1	(3)X1 (L)x1 (R)
		
BACK	SEAT & MECHANISM	ARM
(4)X1	(5)X1	(6)X5
		
GAS LIFT W/ COVER	BASE	CASTERS
<div><div>(A)X4M8*50 ARM SCREW</div><div>(B)X4M6*30 L-BAR SCREW</div><div>(C)X1ALLEN KEY</div></div>		



**Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using.  
This chair is only intended for sitting. Any other use will void the warranty.**

