

INSTALLATION INSTRUCTIONS



Laptop Tray

DISCLAIMER

Lorell and its affiliated corporations and subsidiaries (collectively "Lorell"), intend to make this manual accurate and complete. However, Lorell makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Lorell makes no representation of warranty, expressed or implied, regarding the information contained herein. Lorell assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Lorell product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Lorell product which is attached to a primary Lorell product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.



WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.



WARNING: Use this mounting system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located between the LLR03189 up to (and including) the laptop does not exceed 15 lbs (6.8 kg). Use with products heavier than the maximum weight indicated may result in collapse of the mount and its accessories causing possible injury.




WARNING: Never operate this mounting system if it is damaged. Return the mounting system to a service center for examination and repair.




WARNING: Do not use this product outdoors.

--SAVE THESE INSTRUCTIONS--

DIMENSIONS



PARTS



ASSEMBLY AND INSTALLATION

1. Remove existing quick release faceplate from monitor arm by pulling quick release lever and lifting faceplate from arm. (See Figure 1)




Figure 1

2. Use four M4x12mm Phillips pan machine screws (B) to attach laptop tray (A) to removed faceplate. (See Figure 2)




Figure 2

3. Slide laptop tray (A) onto mounting head until quick release tab clicks into place. (See Figure 3)
4. Adjust mounting arm and tray to desired mounting level. See monitor arm installation instructions for adjustment details. (See Figure 3)




Figure 3

5. Turn extension rod tension adjustment knob counter-clockwise to decrease tension. (See Figure 3)
6. Extend laptop extension rod as desired. (See Figure 3)
7. Turn extension rod tension adjustment knob clockwise to tighten extension rod in place.



WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located between the LLR03189 up to (and including) the laptop does not exceed 15 lbs (6.8 kg). Use with products heavier than the maximum weight indicated may result in collapse of the mount and its accessories causing possible injury.

8. Center laptop on tray and adjust pitch tension as needed to hold tray in desired position. (See Figure 3)



Instructions

CALL US FIRST! DO NOT RETURN TO STORE.

For immediate help with assembly or product information call our toll-free number: **1-888-598-7316** Mon. - Fri. 7am to 7 pm CST
Our staff is ready to provide assistance. Damaged or missing parts ship from our facility in 1-2 business days.

Please provide the following information:

1. Full Name
2. Physical Address – do not include P.O. Box as our carriers cannot deliver to P.O. Boxes
3. Phone Number
4. Model Number
5. Part Number
6. Invoice #
7. Date of Purchase

Note: Our policy is to send all parts requests via normal ground transportation. If your requirements are to have these parts via overnight/next day, please provide your designated carrier and account number. Replacement panels are not available. If any damage has occurred during shipment please return the entire unit to place of purchase for credit and replacement. Original invoice may be required.

Before you begin:

Open, identify and count all parts prior to assembly. Lay out the parts on a non-abrasive surface such as carpet or blanket.