





ACC-MBCR1




⚠ WARNING

ENG - Before installing make sure the supporting surface will support the combined load of the equipment and hardware. Screws must be tightly secured. Do not overtighten screws or damage can occur and product may fail. Never exceed the Maximum Load Capacity. Always use an assistant or mechanical lifting equipment to safely lift and position equipment. This product is intended for indoor use only. Use of this product outdoors could lead to product failure or personal injury. Be careful not to pinch fingers when operating the mount. For support please call customer care at 1-800-865-2112.


ENG Symbols



ENG WARNING



ENG Skip to step.




ENG Do not overtighten screws.




ENG To properly tighten screws: Tighten until screw head makes contact, then tighten another 1/2 turn. Do not overtighten screws.


1



2









3



4




ENG Tools Needed for Assembly.




ENG Parts (Before beginning, make sure you have all parts shown below).

Parts List			
	Description	Qty	Part #
A	connector tube	2	10021858-RBLK
B	support bracket	4	10002758-RBLK
C	1/4-20 x 3/4" hex head screw	36	520-1321
D	1/4-20 x 1/2" phillips screw	2	510-9108


A (2)
connector tube




B (4)
support bracket




C (36)
1/4-20 x 3/4"
hex head screw




D (2)
1/4-20 x 1/2"
phillips screw




1





2-1




2-2



3-1




[ENG] Loosen, adjust, tighten.




3-2


[ENG] Sold separately.




3-3







3-4




3-5




DS-MBZ942L-2X1**4a-1****DS-MBZ942L-2X1
and ACC-MB0800****4b-1****DS-MBZ947L-2X1****4c-1****DS-MBZ947L-2X1
and ACC-MB0800****4d-1**


4a-1





4a-2




4b-1




4b-2




4c-1




4c-2



4d-1



4d-2



ENG	Warranty	ESP	Garantía	FRN	Garantie	DEU	Garantie	NEL	Garantie
ITL	Garanzia	CES	Záruka	SLK	Záruka	POR	Garantia	TÜR	Garanti

www.peerless-av.com/warranty • www.peerless-av.com • www.peerless-av.com/patents

peerless-AV®

Peerless-AV
2300 White Oak Circle
Aurora, IL 60502, USA
info@peerless-av.com

(800) 865-2112
(630) 375-5100

Peerless-AV EMEA
Unit 2, Curo Park
Frogmore, St. Albans,
Hertfordshire, AL2 2DD
United Kingdom

+44 (0) 1923 200 100

Peerless-AV B.V.
Papendorpseweg 75
3528 BJ Utrecht
The Netherlands

+31 (0) 70 770 8037

Peerless-AV Latin America
Av. de las Industrias 413
Parque Industrial Escobedo
General Escobedo N.L.,
México 66062

+52 (81) 8384-8300