




⚠ WARNING

ENG - Do not begin to install product until you have read and understood the instructions and warnings contained in this user guide. Before installing make sure the supporting surface will support the combined load of the equipment and hardware. Screws must be tightly secured. Do not overtighten screws or damage can occur and product may fail. Never exceed the Maximum Load Capacity. Always use an assistant or mechanical lifting equipment to safely lift and position equipment. This product must be installed onto flat, hard, level surface to prevent tipping. This product is intended for indoor use only. Use of this product outdoors could lead to product failure or personal injury. To reduce the risk of electric shock or fire, do not expose product to water or moisture. Be sure power cord is routed so that it will not be tripped on, stepped on, or pinched by heavy items. Avoid overloading electrical outlets or extension cords. Always disconnect the power cord from the power outlet when installing, servicing, or not using the product for an extended period of time. Do not block ventilation slots or fan exhaust on product. Blocking airflow could damage product. Arrange product to allow air to flow freely around product. Keep product away from direct sunlight or any source of heat. For support please call 1-800-865-2112.

ENG Symbols






ENG **WARNING**



ENG Screws must get at least three full turns and fit snug.





ENG Tools Needed for Assembly.



ENG Do not overtighten screws.













ENG To properly tighten screws: Tighten until screw head makes contact, then tighten another 1/2 turn. Do not overtighten screws.





ENG Parts (Before beginning, make sure you have all parts shown below).


Parts List		
Description	Qty	Part #
A base assembly		
KILH540	1	151-P1995-S
KILH540-S	1	151-4995-S
KILH542	1	151-P1995-S
KILH542-S	1	151-4995-S
KILH543	1	151-P1995-S
KILH543-S	1	151-4995-S
KILH546	1	151-P1995-M
KILH546-S	1	151-4995-M
KILH547	1	151-P1995-M
KILH547-S	1	151-4995-M
KILH548	1	151-P1995-M
KILH548-S	1	151-4995-M
KILH549	1	151-P1995-L
KILH549-S	1	151-4995-L
KILH550	1	151-P1995-L
KILH550-S	1	151-4995-L
KILH555	1	151-P1995-XL
KILH555-S	1	151-4995-XL
B adaptor bracket	2	202-SG1695
C display hood		
KILH540	1	151-P1957
KILH540-S	1	151-4957
KILH542	1	151-P1959
KILH542-S	1	151-4959
KILH543	1	151-P1961
KILH543-S	1	151-4961
KILH546	1	151-P1963
KILH546-S	1	151-4963
KILH547	1	151-P1965
KILH547-S	1	151-4965
KILH548	1	151-P1967
KILH548-S	1	151-4967
KILH549	1	151-P1969
KILH549-S	1	151-4969
KILH550	1	151-P1971
KILH550-S	1	151-4971
KILH555	1	151-P1973
KILH555-S	1	151-4973
D 4mm allen wrench	1	560-1146
E M4 x 12mm	4	520-1079
F M4 x 25mm	4	520-1082
G M6 x 12mm	4	520-1050
H M6 x 25mm	4	520-1211
I M8 x 12mm	4	520-1724
J M8 x 25mm	4	520-1101
K M4 x 1mm washer	4	540-9400
L M6/M8 x 1.5mm washer	8	540-9406
M 1/4" (6mm) height spacer	8	600-1215
N M8 x 50mm	4	521-1013
O power strip	1	600-0370



1-1





1-2




2

ENG Caution: Remove bolts to disengage kiosk from pallet before installing product.






3

ENG Center adaptor brackets vertically on back of screen.




4


ENG If adapter brackets interfere with display peripherals (plugs, etc.), use spacers provided. Consider the depth of the display and spacer when determining if the display will fit within the kiosk.



5







6




7

ENG Height adjustment: Tighten or loosen.






9-1





9-2



ENG Back view


10-1

ENG Loosen screws to allow bracket to slide up and down.





10-2


ENG Insert media player (not included).




10-3

ENG Lower bracket so it rests on media player. Tighten screws to secure bracket in place.







12-1



12-2



ENG	Warranty	ESP	Garantía	FRN	Garantie	DEU	Garantie	NEL	Garantie
ITL	Garanzia	ČES	Záruka	SLK	Záruka	POR	Garantia	TÜR	Garanti

www.peerless-av.com/warranty

peerless-AV®

Peerless-AV

2300 White Oak Circle
Aurora, IL 60502
Email: tech@peerlessmounts.com
Ph: (800) 865-2112
Fax: (800) 359-6500
www.peerless-av.com

© 2020, Peerless Industries, Inc.

Peerless-AV Europe

Unit 3 Watford Interchange,
Colonial Way, Watford, Herts,
WD24 4WP, United Kingdom
Customer Care
44 (0) 1923 200 100
www.peerless-av.com

© 2020, Peerless Industries, Inc.

Peerless-AV América Latina

Av. de las Industrias 413
Parque Industrial Escobedo
General Escobedo N.L., México 66062
Servicio al Cliente
01-800-849-65-77
www.peerless-av.com

© 2020, Peerless Industries, Inc.