

T-Mobile®



start guide

Getting Started

Introducing Your Phone.....	2
Service Activation	4
SIM Card	5
Battery	6
Power	7
MOTOBLUR™ Account.....	8
Call Functions	10
Home Screen.....	12
Personalize Home Screen.....	20
Social Networking.....	24
Contacts	27
myFaves®.....	32
Bluetooth® Setup	40

Having Fun

Turn to the **Having Fun** section (Page 43) to learn what else your new phone can do.

INTRODUCING YOUR PHONE

With the MOTOROLA CLIQ™ with MOTOBLUR™, you can:

- Synchronize, view, and share contacts, messages, feeds, and updates from the most popular social Web sites on your phone (Facebook®, MySpace®, Twitter®, and more).
- Access full HTML browser using high-speed 3G and Wi-Fi networks.
- Send text messages, e-mails, and wall posts using the QWERTY keyboard.
- Snap photos with the 5 megapixel camera and post them to favorite sites, such as Picasa®, Photobucket®, and more.
- And much more!



SERVICE ACTIVATION

If you are a new T-Mobile customer and your service has not been activated, simply call Customer Care at **1-800-937-8997** from your landline phone and a T-Mobile Activations representative will assist you.

You will need the following information when activating service:

- Service Agreement and agent code on your Agreement
- Your name, home address, home phone, and billing address
- NOTE: For business and government accounts, please provide the name of your company or government agency, address, and tax ID.
- Your Social Security number, current driver's license number, and date of birth for credit check purposes
- Your choice of T-Mobile rate plan and services (see www.t-mobile.com for latest plan information)
- SIM serial number and IMEI number (located on the box bar code label)

By activating service, you acknowledge that you have read, understand, and agree to be bound by each of T-Mobile's Terms and Conditions and your Service Agreement.

SIM CARD

Your Subscriber Identity Module (SIM) card identifies you to the wireless network. Your phone will not work without the SIM card.

To insert the SIM card and battery:

1. Detach your SIM card.
2. Press the battery cover and slide it off. Lift the tab and remove the battery.



3. Lift the slot guard. Slide the SIM card into the SIM card slot with the gold contacts facing down and the notched corner aligned as shown.



4. Align the gold contacts on the battery with the contacts in the battery compartment. Snap the battery into place and replace the battery cover.

BATTERY

You can charge your phone using the charger cable connected to a wall power outlet or by using the USB cable connected to your computer.

Charge using a charger cable

Connect the small end of the charger cable to the micro-USB port on the left side of your phone. Plug the other end of the charger into a wall outlet.

Charge using a USB cable

Connect the small end of the USB cable to the micro-USB port on the left side of your phone. Plug the other end of the USB cable to the USB port of your computer.



POWER

Press and hold the **Power/Lock** key on the right side of the phone to turn on.


MOTOBLUR ACCOUNT

Before using your phone, you must first create a MOTOBLUR account to get your contacts, e-mail, messages, and social networking status on your phone (MySpace, Facebook, Twitter, etc.).

See the **Social Networking** section in this guide for more information on how to manage your accounts.

Create a MOTOBLUR account

1. Select the language.
2. Tap **Start**.
3. Tap **Register new account**.
4. Tap **Next**.
5. Read the MOTOBLUR Terms of Service, End User License Agreement, and Privacy Statement.
6. Tap the check mark next to **I agree**.
7. Tap **Next**.
8. Enter your name and the e-mail address where MOTOBLUR can send account information.
9. Enter a new MOTOBLUR account password.
10. Tap **Next**.
11. Verify the information is correct and tap **Confirm**.
12. When account creation is complete, tap **Next**.
13. Tap the icon for a service you use.
14. Enter your logon information for that service.
15. Tap **Next**.
16. Repeat steps 13–15 for all of your accounts.
17. Tap **Done adding accounts**.
18. Tap the **Down Arrow** icon and then tap the social networking site you want to use as the picture source for your contacts' picture IDs.
19. Tap **Next**.



20. To complete setup and download your contacts, tap **Next**.
21. Tap **Done**.

Congratulations on creating your new MOTOBLUR account! Now you are ready to make calls or continue on with this guide to learn more about your phone.

CALL FUNCTIONS

Make and end calls

1. On the Home screen, tap the green **Phone** icon.
2. Tap the **Dialer** tab, if necessary.
3. Enter the number and tap **Call**.
4. To end the call, tap **End call**.


Answer calls

Tap **Answer**. When the screen is locked, touch **Answer** and swipe your finger left.

Check Visual Voicemail

Visual Voicemail allows you to play and replay messages in any order, save voice messages to your phone, choose how you want to respond to messages, share special audio messages via e-mail, and create personalized greetings.

1. On the Home screen, tap the **Application** tab.
2. Scroll down and tap **Voice-mails**.
3. Tap a contact and do the following:
 - Tap the **Up** or **Down Arrow** icons to scroll through multiple voicemails.
 - Tap the **Play** icon to listen to a voicemail.
 - Tap the **Trash** icon to delete a voicemail.
 - Tap **Call Contact** to call the contact.
 - Tap **Send Text** to send a text message to the contact.



HOME SCREEN

Your Home screen is wider than you'd think. Simply swipe your finger to the left or right to view any of the five panels.

You can customize each panel with widgets, shortcuts to your favorite applications, or folders that contain shortcuts and files.


Slide your finger to the right to see the left side of your **Home** screen.



Slide your finger to the left to see the right side of your **Home** screen.

Widgets

Widgets bring the content you want right to your Home page. Weather, news, messages, and updates from your social networking contacts are pushed to your widgets as the updates happen.




Social Status widget

Tap this widget on the Home screen to display your most recent status updates to your social networks. You can then update your status on one or all of your social networks.




Messages widget

Tap this widget on the Home screen to display your recently received text messages, e-mails, and social network-ing direct messages. Swipe your finger left or right to scroll through multiple messages or tap the title bar to see the full list.



Happenings widget

Tap this widget on the Home screen to display the most recent photos, events, and other items posted by your social networking contacts. Swipe your finger left or right to scroll through multiple happenings or tap the title bar to see the full list.



Shortcuts


There are two default shortcuts on your center Home screen (Messages and Browser) to allow you to quickly access your messages and to open up the browser.

See the **Personalize Home Screen** section of this guide for more information on how to delete and add shortcuts.


Notification drawer

The **Notification drawer** runs across the top of your screen. Icons appear to let you know when information is waiting for you.

Touch and slide the drawer down with your finger.




Tap the desired Notifier icon.



Application tray

Tap the **Application** tab to open the Application Tray. Touch and slide your finger up or down the screen to scroll through your applications.

New applications are automatically added to your drawer in alphabetical order.



PERSONALIZE HOME SCREEN

Swipe left or right to personalize each of the five panels of your Home screen.

Add widgets to Home screen

1. On the Home screen, touch and hold an empty space until you see the **Add to Home screen** menu.
2. Tap **Widgets**.
3. Tap the desired widget.
4. If necessary, complete additional setup steps and tap **Done**.

Arrange widgets

1. On the Home screen, touch and hold the widget you want to move. The **Application** tab will turn red when the widget is active.
2. Drag the widget to the desired location and release your finger from the screen.

Delete widgets

1. On the Home screen, touch and hold the widget you want to delete. The **Application** tab will turn red when the widget is active.
2. Drag the widget to the **Trash** icon on the **Application** tab and release your finger from the screen.

Create shortcuts on the Home screen

1. On the Home screen, tap the **Application** tab.
2. Touch and hold the desired application.
3. Drag the application icon to the desired location on the desired panel and release your finger from the screen.

Delete shortcuts

1. On the Home screen, touch and hold the shortcut you want to delete. The **Application** tab will turn red when the shortcut is active.
2. Drag the shortcut to the **Trash** icon on the **Application** tab and release your finger from the screen.

Change wallpapers

1. On the Home screen, touch and hold an empty space until you see the **Add to Home screen** menu.
2. Tap **Wallpapers**.
3. Tap one of the following:
 - **Picture gallery**: Tap to view a picture. Touch and drag the **Circle** and **Arrow** icons to adjust the crop box. Tap the **Check Mark** icon when done.
 - **Wallpaper gallery**: Touch and drag to scroll through the wallpapers. Tap **Set wallpaper**.

Create folders on the Home screen

1. On the Home screen, touch and hold an empty space until you see the **Add to Home screen** menu.
2. Tap **Folders**.
3. Tap **New folder**.
4. Tap to open the new folder.
5. Touch and hold the top bar to rename the folder.
6. Enter a name for your folder.
7. Tap **OK** when done.

Add shortcuts to a folder

1. On the Home screen, touch and hold the shortcut you want to add to a folder. The **Application** tab will turn red when the shortcut is active.
2. Drag the shortcut on top of the folder and release your finger from the screen.

Note: You cannot move widgets into a folder.

SOCIAL NETWORKING

Your phone automatically delivers and organizes your conversations, friends and favorite content from so many sources directly to your phone in easy-to-manage streams.

It syncs contacts, posts, feeds, messages, e-mails, photos and much more—from sources like Facebook, Twitter, MySpace, Gmail®, Yahoo!®, your work e-mail, Picasa, Photobucket, Last.fm®—and automatically serves it up just the way you want it. No opening and closing apps and menus, it's all front and center on your Home screen and integrated throughout the entire phone so you can communicate anyway you like.

Add accounts

You can add your Facebook, MySpace, Twitter, or other accounts to your phone any time. To set up social networking accounts, visit their Web sites.

1. On the Home screen, tap the **Application** tab.

2. Tap **Accounts**.
3. Tap **Add account**.
4. Tap the icon for the desired account.
5. Enter your logon information.
6. Tap **Next**.

View accounts

1. On the Home screen, tap the **Application** tab.
2. Tap **Accounts**.

Delete accounts

1. On the Home screen, tap the **Application** tab.
2. Tap **Accounts**.
3. Tap the account you want to delete.
4. Tap **Delete account**.
5. Tap **Yes** to confirm.

Update your status

You can update and see your current status in the **Social Status** widget on your Home screen. To update:

1. On the Home screen, tap the **Social Status** widget.
2. Enter your status.
If you have more than one account, you can use the pull-down menu to limit which accounts are updated.
3. Tap **Post**.


If you don't see a **Social Status** widget, swipe your Home screen left or right to check all panels. To add the **Social Status** widget:

1. On the Home screen, touch and hold an empty space until you see the **Add to Home screen** menu.
2. Tap **Widgets**.
3. Scroll to and tap **Social Status**. The widget will appear in the empty spot and will show your status the next time your phone updates from the network.

CONTACTS

There are several important things to know when managing contacts on your phone:

- New contacts are saved in the phone memory, and also updated in your MOTOBLUR and T-Mobile® Mobile Backup accounts at www.motorola.com/mymotoblur and www.my.T-Mobile.com.
- If you edit one of your social networking contacts on the Web site, your changes will be synchronized to your phone automatically.
- You cannot save new contacts to your SIM card.
- Contacts downloaded from Facebook, MySpace, Twitter, Gmail, and Corporate Sync are not backed up to T-Mobile Mobile Backup.



Group filter: Tap to choose which group to display, such as Facebook, MySpace, or All contacts.

Add new contacts: Tap to enter a new contact.

Contact list: Tap to view a contact. Touch and hold to edit, delete, and more.

Views: Tap to view your contact list in different ways:

History: Recently used
A-Z: View without status
Status: View with status

5. Repeat step 4 for other sections, if desired.
6. Tap **Save** when done.

Call contacts

1. On the Home screen, tap the blue **Contacts** icon.
2. Scroll to and tap the contact you wish to call.
3. Tap the desired phone number.

Link contacts

If one of your contacts is stored in multiple social networking sites, it may result in duplicate entries. You can easily link a contact's multiple entries into one.

1. On the Home screen, tap the blue **Contacts** icon.
2. Tap the contact entry you want to link.
3. Press the **Menu** key.
4. Tap **Link contact**.
5. Scroll to and tap the contact entry you want to link with previous entry.

Add contacts using your phone

1. On the Home screen, tap the blue **Contacts** icon.
2. Tap the green **Plus** icon.
3. Enter the contact's name.
4. Under **Phone**, tap the green **Plus** icon and enter the phone number.

Filter contacts

To view where a contact is stored, such as on Facebook or in T-Mobile Mobile Backup, you can easily filter your contacts.


1. While in your contact list, tap **Contacts** in the top left corner of the screen.
2. Tap **All contacts**, **MOTOBLUR address book**, **T-Mobile Network Address Book**, or the desired linked account.

Contact list views

You have three options for viewing the contacts in your contact list.


History view:

To view the contacts you have sent or received messages from, beginning with the most recent.




A-Z view:

To view your contacts in alphabetical order.



Status view:

To view your contacts' status updates, beginning with the most recent.






myFaves® is an optional calling plan.
Benefits of signing up to myFaves:

- Unlimited nationwide calling to any five U.S. numbers, on any network (even landlines)*
 - Calling, text messaging, and photo sharing**
 - No domestic roaming or domestic long-distance charges
 - Personalize contacts with favorite pictures and downloadable icons**
- * myFaves only applies to calls directly between two people and allows unlimited nationwide calling to five U.S. numbers. You can change myFaves numbers once/month.
- ** Separate charges may apply.


Subscribe to myFaves

To subscribe, go to **www.T-Mobile.com**. When you have subscribed to myFaves, you will see five circles on the main screen a few minutes after you power on your phone.



Add myFaves contacts

1. On the Home screen, swipe your finger to the left to view the first panel to the right .
2. Tap the **myFaves** shortcut.
3. Tap an unassigned circle.
4. Tap one of the following:
 - **Create new:** Enter the contact's name and phone number.
 - **Get from Phonebook:** Select a contact.



5. Tap **Save** or continue to Step 6 to assign an icon.


Assign an icon

6. Tap the icon circle in the top left corner of the screen.
7. Tap one of the following:
 - **myFaves icons:** Tap the desired myFaves icon.
 - **Photos:** Tap the desired photo. Touch and drag the crop circle to the desired location and size. Tap **Crop**.
 - **Take picture:** Frame your subject and press the **Camera** key.
8. Tap **Save**.
9. Tap **OK**.

An hourglass displays in the circle while the contact is being added to your contacts. You can use your phone during this time. Once the contact is added, you will receive a confirmation message and the hourglass is replaced by your new contact.

Assign a ringtone

1. On the Home screen, swipe your finger to the left to view the first panel to the right.
2. Tap the **myFaves** shortcut.
3. Tap the myFaves contact's circle.
4. Tap **Edit**.
5. By **Contact Details**, tap **Edit**.
6. Scroll down to **Ringtone**.
7. Tap **No ringtone specified**.
8. Tap the desired ringtone.
9. Tap **OK**.
10. Tap **Save**.



Edit a myFaves contact


Names, icons, and ringtones: You can change names, icons, and ringtones at any time.

Phone numbers: You can only change a contact's phone number once per calendar month. If a number change is not allowed, you will receive an error message explaining why.

1. On the Home screen, swipe your finger to the left to view the first panel to the right.
2. Tap the **myFaves** shortcut.
3. Tap the myFaves contact's circle.
4. Tap **Edit**.
5. By **Contact Details**, tap **Edit**.
6. Scroll down and edit the contact's information, such as name, phone number, e-mail address, mailing address, birthday, anniversary, and ringtone.
7. Tap **Save**.

Contact myFaves

1. On the Home screen, swipe your finger to the left to view the first panel to the right.
2. Tap the **myFaves** shortcut.
3. Tap the myFaves contact's circle.
4. Tap one of the following:
 - Call
 - Send Message
 - Wave Hello
 - Send Audio Postcard
 - Send E-Mail
 - Send IM



View Happenings

Easily view all of your social networking feeds for your FavesSM in one view.

1. On the Home screen, tap the **myFaves** shortcut.
2. Tap **Happenings**.

Separate charges may apply to send/receive domestic/international text, picture, instant, Wave HelloSM, or Audio PostcardSM messages, or to send/receive/read e-mails.

BLUETOOTH® SETUP

Your phone comes with Bluetooth connectivity, which is a wireless technology that enables a data connection between your phone and a Bluetooth wireless headset (headset sold separately).

Prepare a Bluetooth wireless headset

To pair your phone with a Bluetooth headset, make sure that your headset is fully charged and that you put the headset into pairing mode. See your Bluetooth headset's manual for more information.

Turn on Bluetooth and pair

1. On the Home screen, press the **Menu** key.
2. Tap **Settings**.
3. Tap **Wireless controls**.
4. Tap **Bluetooth settings**.



5. Tap **Turn on Bluetooth**. Your phone scans for available Bluetooth devices.
6. If you do not see your headset, tap **Scan for devices**.
7. Tap your headset.
8. Enter the **PIN**, if required.
9. Tap **OK**.

Having Fun

E-mail	44
Text Messaging	50
Picture Messaging.....	52
Instant Messaging	54
Market	55
Web Browsing	57
Location	59
YouTube®	66
Security	67
Emergency Dialing	70
Caring for Your Phone	71
Tips for Safety	73
Accessories for Your Phone.....	75
Additional Information	76
More Help	77

E-mail

Your phone comes with e-mail capability so you can stay connected with Yahoo!, Gmail, Windows Live™ Hotmail®, AOL®, and other popular e-mail providers. Setting up e-mail on your phone is easy—enter your e-mail address and password and your phone automatically receives e-mails from your e-mail account. You can read, send, reply, and even delete e-mails so you can keep in touch whenever you want.

Set up Internet e-mail

1. On the Home screen, tap the **Application** tab.
2. Tap **Accounts**.
3. Tap **Add account**.
4. Tap the icon for your e-mail client, or tap **Email**.
5. Enter your e-mail address and password.
6. Tap **Next**.



Set up corporate e-mail

1. On the Home screen, tap the **Application** tab.
2. Tap **Accounts**.
3. Tap **Add account**.
4. Tap **Corporate Sync**.
5. Enter the domain, username, pass-word, e-mail address, and server for your Microsoft Exchange e-mail account.
6. Tap **Next**.

Note: Contact your company's IT department if you need more help. This feature works with Microsoft Exchange e-mail servers only.

Read e-mail

To view new e-mail alerts:

1. Touch and hold the **Notification Drawer** and then slide your finger down the screen to open.
2. Tap the **Notifier** icon for the message you want to read.
3. Tap the message you want to read.

To view e-mails in your Inbox:


1. On the Home screen, tap the **Messaging** shortcut.
2. Tap **Universal Inbox**, or tap the icon for the desired account.
3. Tap the message you want to read.

Access and send e-mail

1. On the Home screen, tap the **Messaging** shortcut.
2. Tap **Universal Inbox**, or tap the icon for the desired account.
3. Tap the green **Plus** icon in the top-right corner of the screen.
4. At **To**, enter the contact's e-mail address. If the contact is saved in your contact list, tap to select from the list.
5. Enter your subject and message.
6. Tap **Send**.

Delete e-mail

1. On the Home screen, tap the **Messaging** shortcut.
2. Tap **Universal Inbox**, or tap the icon for the desired account.
3. Touch and hold the e-mail you want to delete.
4. Tap **Delete**.



Separate charges may apply to send/receive/read domestic/international e-mail messages.

Text Messaging

Read text messages

To view new text messaging alerts:

1. Touch and hold the **Notification Drawer** and then slide your finger down the screen to open.
2. Tap the **Notifier** icon for the message you want to read.
3. Tap the message you want to read.

To view text messages in your Inbox:

1. On the Home screen, tap the **Messaging** shortcut.
2. Tap **Text Messaging**.
3. Tap the message you want to read.

Send text messages

1. On the Home screen, tap the **Messaging** shortcut.
2. Tap **Text Messaging**.
3. Tap **New Text Message**.
4. At **To**, enter the contact's phone number. If the contact is saved in your contact list, tap to select from the list.
5. Enter your message.
6. Tap **Send**.

Separate charges may apply to send/receive domestic/international text messages.



Picture Messaging

Send picture messages

1. Press and hold the **Camera** key.
2. Frame your subject and press the **Camera** key.
3. Tap the thumbnail preview in the lower right corner.
4. Tap **Share**.
5. Tap the e-mail account you want to use or scroll down and tap **Text Messaging**.
6. At **To**, enter the contact's e-mail address or phone number. If the contact is saved in your contact list, tap to select from the list.
7. Enter your message.
8. Tap **Send**.

Upload to social networking sites

1. On the Home screen, tap the **Application** tab.
2. Scroll down and tap **Picture Gallery**.
3. Tap **My Pictures** or **All Pictures**.
4. Touch and hold the desired picture.
5. Tap **Share**.
6. Tap the desired social networking account.
7. If necessary, follow the on-screen instructions to enter your account information and login.
8. Enter a caption and choose an album, if applicable.
9. Tap **Send, Upload, Add to MySpace Now**, or another social networking site to which you are linked.

Separate charges may apply to send/receive domestic/international picture messages.

Instant Messaging

Access IM accounts

1. On the Home screen, tap the **Application** tab.
2. Scroll down and tap **IM**.
3. Tap the desired IM client.
4. Enter your logon information.
5. Tap **Remember my password**.
6. Tap **Sign In**.



Separate charges may apply to send/receive domestic/international instant messages.

Market

Get all the fun games and cool apps you want! Android Market provides you with access to software developers everywhere, so you can find the app you want.

Browse applications

1. On the Home screen, tap the **Application** tab.
2. Scroll down and tap **Market**.
3. Tap **Accept**.
4. Tap a marketplace category, or tap **Search** to enter a term and search all categories.

Install applications

1. While browsing the marketplace, tap on the desired application.
2. Tap **Install**.
3. Tap **OK** to allow the application access, if necessary.
4. When the application has successfully installed you will see a **Notifier** icon in the **Notification Drawer**.
5. Tap the **Notifier** icon to complete additional installation steps or to launch the application. You can also launch the application from the icon in your **Application Tray**.

Separate charges may apply to purchase/download applications.

Web Browsing

Access browser

On the Home screen, tap the **Browser** shortcut.

Visit Web pages

1. While in the browser, press the **Menu** key.
2. Tap **Go**.
3. Enter the Web address.
4. Tap **Go**.



Add a bookmark

1. While in the browser, navigate to the Web page you want to add.
2. Press the **Menu** key.
3. Tap **Bookmarks**.
4. Tap **Add bookmark....**
5. Enter a name for your bookmark.
6. Tap **OK**.

Full access to the web requires the purchase of a compatible data plan.

Location

Google Maps™

Find a location:

1. On the Home screen, swipe your finger to the right to view the first panel to the left.
2. Tap the **Google Maps** shortcut.
3. Read what's new and tap **OK**.
4. Press the **Menu** key.
5. Tap **Search**.
6. Enter the location you want to find.
7. Tap the **Magnifying Glass** icon to begin the search.

Find your location:

1. While in Google Maps, press the **Menu** key.
2. Tap **Find my location**.

Get directions:

1. While in Google Maps, press the **Menu** key.
2. Tap **Directions**.
3. Enter the start and end points.
4. Tap the **Car**, **Bus**, or **Walking** icon to indicate mode of travel.
5. Tap **Go**.

Change map mode:

1. While in Google Maps, if you are in list view, press the **Menu** key and then tap **Show on map**.
2. Press the **Menu** key.
3. Tap **Map mode**.
4. Tap one of the following:
 - **Map**: To view in standard map mode.
 - **Satellite**: To view map as satellite imagery.
 - **Traffic**: To view traffic conditions.

TeleNav GPS Navigator™

Sign up:

1. On the Home screen, tap the **Application** tab.
2. Scroll down and tap **TeleNav GPS Navigator**.
3. Read the warning and tap **Accept**.
4. Enter your first and last name and your e-mail address.
5. Tap **Submit**.
6. Read the 14 day trial information and tap **Go**.

Find a location:

1. While in TeleNav, if you do not have GPS enabled, tap **Go to GPS Settings**.
2. Tap **Enable GPS satellites**.
3. Press the **Back** key.
4. Read the Warning and tap **Go**.
5. Tap **Search**.
6. Tap **Type It**. You can also tap **Speak It** if you would like to try speech recognition.

7. At **What**, enter the desired business name or street address.
8. Tap **Category** and tap a category, if desired.
9. Tap **Search**.

Get directions to:

1. While in TeleNav, if you do not have GPS enabled, tap **Go to GPS Settings**.
2. Tap **Enable GPS satellites**.
3. Press the **Back** key.
4. Read the Warning and tap **Go**.
5. Tap **Drive To**.
6. Read the Tip and tap **Close**.
7. Tap **Address**.
8. Tap **Type It**.
9. At **Address**, enter the desired address.
10. Enter the city and state or zip code.
11. Tap **Done**.

The free trial of TeleNav GPS Navigator automatically expires after 14 days. To continue use of the TeleNav GPS Navigator after expiration of the free 14 day trial, you must sign up for regular service. TeleNav is a registered trademark and TeleNav GPS Navigator is a trademark of TeleNav, Inc.

Google Latitude

See where your friends and family are on Google Maps. Plan to meet up, check that your parents got home safely, or just stay in touch. Don't worry, your location is not shared unless you agree to it. You need to join Google Latitude, and then invite your friends to view your location or accept their invitations.

Join Google Latitude:

1. On the Home screen, swipe your finger to the right to view the first panel to the left.
2. Tap the **Google Maps** shortcut.
3. Read what's new and tap **OK**.
4. Press the **Menu** key.
5. Tap **Join Latitude**.



Add and remove friends:

1. While in Google Latitude, tap the **Friends** tab.
2. Press the **Menu** key.
3. Tap **Add friends**.
4. Tap **Select from Contacts**.
5. Tap the friends you want to add.
6. Tap **Add friends**.
7. Tap **Yes** to confirm.

Share location:

1. While in Google Latitude, tap the **Friends** tab.
2. Press the **Menu** key.
3. Tap **Privacy**.
4. Tap the desired setting.
5. Press the **Back** key to return to your Friends list.

Hide location:

1. While in Google Latitude, tap the **Friends** tab.
2. Press the **Menu** key.
3. Tap **Privacy**.
4. Tap **Hide your location**.
5. Press the **Back** key to return to your Friends list.

Disable Google Latitude:

1. While in Google Latitude, tap the **Friends** tab.
2. Press the **Menu** key.
3. Tap **Privacy**.
4. Tap **Turn off Latitude**.
5. Tap **Yes** to confirm.

YouTube®

Watch a YouTube video

1. On the Home screen, tap the **Application** tab.
2. Scroll down and tap **YouTube**.
3. Tap the desired video category.
4. Tap the video listing to view.

Search for YouTube videos

1. While in YouTube, press the **Menu** key.
2. Tap **Search**.
3. Enter your search term.
4. Tap the **Magnifying Glass** icon.

Security

Don't you just hate it when your life is on your phone and it all goes wrong? Lose it, break it, reset it, or even worse—stolen! Relax, MOTOBLUR can help find your phone, clear it (if you need to), and best of all, restore all your stuff.

Track your phone

1. Log into your MOTOBLUR account at: **www.motorola.com/mymotoblur**.
2. In the MOTOBLUR window, click on **Locate Device**. Your phone's location is shown in Google Maps.

Remote clear

1. Log into your MOTOBLUR account at: **www.motorola.com/mymotoblur**.
2. In the MOTOBLUR window, click **Wipe Device**.
3. A warning notification is displayed, enter your MOTOBLUR password again.

Warning: All downloaded apps and user data will be deleted.

Restore your phone

If you lose your phone don't worry, your contacts are backed-up on MOTOBLUR.

1. Access your MOTOBLUR account at **www.motorola.com/mymotoblur** and remotely locate your phone, clear the data on your phone, and more.
2. When you get your next MOTOBLUR product, just log into your existing MOTOBLUR account on your phone to recover all your stuff automatically.
3. To recover your Android Market apps, see "Uninstall applications" in your Motorola User Manual.

Emergency Dialing

While all phones are equipped with 911 emergency calling, this phone may or may not permit its location to be approximated during a 911 call.*

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 911 calling system that are required to be installed by the local 911 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped or refused. The phone's approximate location is transmitted to the local 911 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

Caring for Your Phone

MAKING IT LAST

Your phone is a complex electronic device; think of it as a mini-computer. Here are some hints that will help you extend the life of your new phone.

Phones aren't cheap, so keep yours in a safe place. Keep the phone away from children who want to see if the phone sinks or floats, and away from dogs that find plastic-coated products to be irresistible chew toys.

Water will damage your phone and accessories. Even a small amount of water from a soda in your car cup-holder, melting snowflakes, tears of joy, squirt-gun crossfire, or steam from the kitchen or bathroom can damage your phone.

Use only batteries and accessories from the original manufacturer of your phone. Non-approved accessories can damage you or your phone and shorten the phone's

life. Hint: If it's being sold out of someone's car trunk, walk away.

If your charger or any other accessory is damaged, replace it or take it to a qualified service dealer. Do not attempt to operate your phone charger if it has received a sharp blow, been dropped, thrown from a speeding motorcycle, or is otherwise damaged; doing so may damage your phone.

Tips for Safety

Check with your doctor if you have a pacemaker or hearing aid to ensure that cell phone usage is safe with your device. If you have questions about the interaction of cellular radio frequency and any other electronic equipment, ask the manufacturer of the equipment if cell phone radio frequencies will disrupt the equipment's performance.

When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner. Here are a few tips:

- Assess road conditions before answering. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone option before you start moving.

- If your phone rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.
- Program frequently used numbers into your speed dial for easy one-select dialing.
- Remember that laws prohibiting or restricting the use of a mobile phone while driving may apply in your area.

Accessories for Your Phone

Whether you are looking for a charger, a fashionable carrying case, a Bluetooth® headset or just want to browse for fun extras for your phone, T-Mobile is the place to shop for accessories. Here are a few examples...



Bluetooth®
Headset



Car Charger

To purchase accessories for your phone, visit T-Mobile.com, call 1.800.204.2449 or visit your nearest T-Mobile store.

Accessory selection subject to change and may vary by location.

Additional Information

myFaves: Capable phones required. myFaves only applies to calls directly between two people and allows unlimited nationwide calling to 5 U.S. numbers. You can change myFaves numbers once/month.

Messaging Plans/Features: You will be charged for all data sent by or to you through the network, regardless of whether received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications.

Data Downloads: Additional charges may apply; not all downloads available on all devices. You obtain no rights in downloads; duration of use may be limited; may be stored solely for use with your device. T-Mobile is not responsible for any download lost due to your error. See brochures, and **T-Mobile's Terms and Conditions (including arbitration provision)** at T-Mobile.com, for rate plan information, charges for features and services, and restrictions and details.

Yahoo!® and the Yahoo!® Messenger logos are registered trademarks of Yahoo! Inc. The Bluetooth® word mark and logo are owned by the Bluetooth SIG, Inc. and are used by T-Mobile under license. MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The MOTOBLUR logo is a trademark of Motorola. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. myFaves, the MyFaves logo, and the myFaves design are registered trademarks, and Faves, web2go, Audio Postcard, and Wave Hello are service marks, of T-Mobile USA, Inc. All other brands, product names, company names, trademarks, and service marks are the property of their respective owners. ©2009 T-Mobile USA, Inc.

More Help

This guide helps you get started using your phone. If you need more information, please go to:

- My Account: On your phone, tap the **Application** tab and tap **My Account**.
- Get Started widget and Tips and Tricks widget on your Home screen.
- **www.t-mobile.com** and **www.motorola.com/mycliq** to view the user guide, video, and online tutorials.
- Motorola Android support for North America and Canada, **800-734-5870**.



MOTOROLA **CLIQ**™ with MOTOBLUR™