

PowerScan 9600	
PowerScan PBT9600, Bluetooth, Document Capture, Color sensor, Removable Battery	PBT9600-DCRB
PowerScan PBT9600, Bluetooth, Document Capture, Removable Battery, USB Kit (Kit includes Scanner PBT9600-DC, Cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-DCRBK10EU
PowerScan PBT9600, Bluetooth, Document Capture, Removable Battery, USB Kit (Kit includes Scanner PBT9600-DC, Cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-DCRBK10US
PowerScan PBT9600, Bluetooth, High Performance, Removable Battery	PBT9600-HPRB
PowerScan PBT9600, Bluetooth, High Performance, Removable Battery, RS-232 Kit (Kit includes Scanner PBT9600-HP, Cradle BC9630-BT, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-HPRBK20EU
PowerScan PBT9600, Bluetooth, High Performance, Removable Battery, RS-232 Kit (Kit includes Scanner PBT9600-HP, Cradle BC9630-BT, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-HPRBK20US
PowerScan PBT9600, Bluetooth, High Performance, Removable Battery, USB Kit (Kit includes Scanner PBT9600-HP, Cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-HPRBK10EU
PowerScan PBT9600, Bluetooth, High Performance, Removable Battery, USB Kit (Kit includes Scanner PBT9600-HP, Cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-HPRBK10US
PowerScan PBT9600, Bluetooth, Standard Range, Removable Battery	PBT9600-SRRB
PowerScan PBT9600, Bluetooth, Standard Range, Removable Battery, RS-232 Kit (Kit includes Scanner PBT9600-SR, Cradle BC9630-BT, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-SRRBK20EU
PowerScan PBT9600, Bluetooth, Standard Range, Removable Battery, RS-232 Kit (Kit includes Scanner PBT9600-SR, Cradle BC9630-BT, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-SRRBK20US
PowerScan PBT9600, Bluetooth, Standard Range, Removable Battery, USB Kit (Kit includes Scanner PBT9600-SR, Cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-SRRBK10EU
PowerScan PBT9600, Bluetooth, Standard Range, Removable Battery, USB Kit (Kit includes Scanner PBT9600-SR, Cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-SRRBK10US
PowerScan PBT9600, Standard Range, Bluetooth, USB Kit (Kit includes Scanner PBT9600-SR, Cradle BC9620-BT, Cable CAB-438, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-SRRBK12EU
PowerScan PBT9600, Standard Range, Bluetooth, USB Kit (Kit includes Scanner PBT9600-SR, Cradle BC9620-BT, Cable CAB-438, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-SRRBK12US
PowerScan PBT9600-AR, Auto Range, Bluetooth, Removable Battery	PBT9600-ARRB
PowerScan PBT9600-AR, Auto Range, Bluetooth, Removable Battery, USB Kit (Kit includes Scanner PBT9600-ARRB, cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-ARRBK10EU
PowerScan PBT9600-AR, Auto Range, Bluetooth, Removable Battery, USB Kit (Kit includes Scanner PBT9600-ARRB, cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-ARRBK10US

PowerScan 9600 DPX	
PowerScan PBT9600-DPX, Direct Part Marking, Bluetooth, Removable Battery	PBT9600-DPXR B
PowerScan PBT9600-DPX, Direct Part Marking, Bluetooth, Removable Battery, Ethernet Kit (Kit includes Scanner PBT9600-DPX, cradle BC9680-BT, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-DPXR BK30EU
PowerScan PBT9600-DPX, Direct Part Marking, Bluetooth, Removable Battery, Ethernet Kit (Kit includes Scanner PBT9600-DPX, cradle BC9680-BT, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-DPXR BK30US
PowerScan PBT9600-DPX, Direct Part Marking, Bluetooth, Removable Battery, RS-232 Kit (Kit includes Scanner PBT9600-DPX, cradle BC9630-BT, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-DPXR BK20EU
PowerScan PBT9600-DPX, Direct Part Marking, Bluetooth, Removable Battery, RS-232 Kit (Kit includes Scanner PBT9600-DPX, cradle BC9630-BT, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-DPXR BK20US
PowerScan PBT9600-DPX, Direct Part Marking, Bluetooth, Removable Battery, USB Kit (Kit includes Scanner PBT9600-DPX, cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PBT9600-DPXR BK10EU
PowerScan PBT9600-DPX, Direct Part Marking, Bluetooth, Removable Battery, USB Kit (Kit includes Scanner PBT9600-DPX, cradle BC9630-BT, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0941)	PBT9600-DPXR BK10US

PowerScan 9600	
PowerScan PD9630-AR, Auto Range, RS-232 Kit (Kit includes Scanner and RS232 Cable CAB-549)	PD9630-AR K2
PowerScan PD9630-AR, Auto Range, USB Kit (Kit includes Scanner and USB Cable CAB-553)	PD9630-AR K1
PowerScan PD9630-AR, Auto Range, USB/RS-232 Multi-Interface	PD9630-AR
PowerScan PD9630-DC, Document Capture, Color sensor, USB Kit (Kit includes Scanner and USB Cable CAB-553)	PD9630-DCK1
PowerScan PD9630-DC, Document Capture, Color sensor, USB/RS-232 Multi-Interface	PD9630-DC

PowerScan 9600 DPX	
PowerScan PD9630-DPX, Direct Part Marking, RS-232 Kit (Kit includes Scanner and RS232 Cable CAB-549)	PD9630-DPX K2
PowerScan PD9630-DPX, Direct Part Marking, USB Kit (includes Scanner and USB cable CAB-553)	PD9630-DPX K1
PowerScan PD9630-DPX, Direct Part Marking, USB/RS-232 Multi-Interface	PD9630-DPX

PowerScan 9600	
PowerScan PD9630-HP, High Performance, RS-232 Kit (Kit includes Scanner and RS232 Cable CAB-549)	PD9630-HPK2
PowerScan PD9630-HP, High Performance, USB Kit (Kit includes Scanner and USB Cable CAB-553)	PD9630-HPK1
PowerScan PD9630-HP, High Performance, USB/RS-232 Multi-Interface	PD9630-HP
PowerScan PD9630-SR, Standard Range, RS-232 Kit (Kit includes Scanner and RS232 Cable CAB-549)	PD9630-SRK2
PowerScan PD9630-SR, Standard Range, USB Kit (Kit includes Scanner and USB Cable CAB-553)	PD9630-SRK1
PowerScan PD9630-SR, Standard Range, USB/RS-232 Multi-Interface	PD9630-SR
PowerScan PM9600, High Performance, 433 MHz, Display/16-key Keypad, Removable Battery	PM9600-DKHP433RB
PowerScan PM9600, High Performance, 433MHz, Display/16-Key Keypad, Removable Battery, RS-232 Kit (Kit includes Scanner, cradle BC9630-433, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-DKHP433RK20
PowerScan PM9600, High Performance, 433MHz, Display/16-Key Keypad, Removable Battery, USB Kit (Kit includes Scanner, cradle BC9630-433, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-DKHP433RK10
PowerScan PM9600, High Performance, 433MHz, Display/4-Key Keypad, Removable Battery	PM9600-DHP433RB
PowerScan PM9600, High Performance, 433MHz, Display/4-Key Keypad, Removable Battery, RS-232 Kit (Kit includes Scanner, cradle BC9630-433, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-DHP433RBK20
PowerScan PM9600, High Performance, 433MHz, Display/4-Key Keypad, Removable Battery, USB Kit (Kit includes Scanner, cradle BC9630-433, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-DHP433RBK10
PowerScan PM9600, High Performance, 910 MHz, Display/16-key Keypad, Removable Battery	PM9600-DKHP910RB
PowerScan PM9600, High Performance, 910MHz, Display/16-Key Keypad, Removable Battery, RS-232 Kit (Kit includes Scanner, cradle BC9630-910, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-DKHP910RK20
PowerScan PM9600, High Performance, 910MHz, Display/16-Key Keypad, Removable Battery, USB Kit (Kit includes Scanner, cradle BC9630-910, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-DKHP910RK10
PowerScan PM9600, High Performance, 910MHz, Display/4-Key Keypad, Removable Battery	PM9600-DHP910RB
PowerScan PM9600, High Performance, 910MHz, Display/4-Key Keypad, Removable Battery, RS-232 Kit (Kit includes Scanner, cradle BC9630-910, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-DHP910RBK20
PowerScan PM9600, High Performance, 910MHz, Display/4-Key Keypad, Removable Battery, USB Kit (Kit includes Scanner, cradle BC9630-910, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-DHP910RBK10
PowerScan PM9600-AR, Auto Range, 433 MHz, Display/16-key Keypad, Removable Battery	PM9600-DKAR433RB
PowerScan PM9600-AR, Auto Range, 433 MHz, Removable Battery	PM9600-AR433RB
PowerScan PM9600-AR, Auto Range, 433MHz, Display/16-key Keypad, Removable Battery, USB Kit (Kit includes Scanner PM9600-DKAR433RB, cradle BC9630-433, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-DKAR433RK10
PowerScan PM9600-AR, Auto Range, 433MHz, USB Kit (Kit includes Scanner PM9600-AR433RB, cradle BC9630-433, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-AR433RBK10

PowerScan 9600 DPX	
PowerScan PM9600-DPX, Direct Part Marking, 433 MHz, Display/4-key Keypad, Removable Battery	PM9600-DDPX433RB
PowerScan PM9600-DPX, Direct Part Marking, 433 MHz, Display/4-key Keypad, Removable Battery, Ethernet Kit (Kit includes Scanner PM9600-DPX, cradle BC9680-433, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-DDPX433RK30
PowerScan PM9600-DPX, Direct Part Marking, 433 MHz, Display/4-key Keypad, Removable Battery, RS-232 Kit (Kit includes Scanner PM9600-DPX, cradle BC9630-433, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-DDPX433RK20
PowerScan PM9600-DPX, Direct Part Marking, 433 MHz, Display/4-key Keypad, Removable Battery, USB Kit (Kit includes Scanner PM9600-DPX, cradle BC9630-433, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-DDPX433RK10

PowerScan 9600	
PowerScan PM9600-HP, High Performance, 433 MHz, Removable Battery	PM9600-HP433RB
PowerScan PM9600-HP, High Performance, 433MHz, Ethernet Kit (Kit includes Scanner PM9600-HP, Cradle BC9680-433, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-HP433RBK30
PowerScan PM9600-HP, High Performance, 433MHz, RS232 Kit (Kit includes Scanner PM9600-HP, cradle BC9630-433, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-HP433RBK20
PowerScan PM9600-HP, High Performance, 433MHz, USB Kit (Kit includes Scanner PM9600-HP, cradle BC9630-433, Cable CAB-552 , Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-HP433RBK10
PowerScan PM9600-HP, High Performance, 910MHz, Ethernet Kit (Kit includes Scanner PM9600-HP, Cradle BC9680-910, Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-HP910RBK30
PowerScan PM9600-HP, High Performance, 910MHz, Removable Battery	PM9600-HP910RB
PowerScan PM9600-HP, High Performance, 910MHz, RS232 Kit (Kit includes Scanner PM9600-HP, cradle BC9630-910, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-HP910RBK20
PowerScan PM9600-HP, High Performance, 910MHz, USB Kit (Kit includes Scanner PM9600-HP, cradle BC9630-910, Cable CAB-552 , Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-HP910RBK10
PowerScan PM9600-SR, Standard Range, 433 MHz, Removable Battery	PM9600-SR433RB
PowerScan PM9600-SR, Standard Range, 433 MHz, RS-232 Kit (Kit includes Scanner PM9600-SR, cradle BC9630-433, Cable CAB-548, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-SR433RBK20
PowerScan PM9600-SR, Standard Range, 433 MHz, USB Kit (Kit includes Scanner PM9600-SR, cradle BC9630-433, Cable CAB-552, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-SR433RBK10
PowerScan PM9600-SR, Standard Range, 433 MHz, USB Kit (Kit includes Scanner PM9600-SR, Cradle BC9620-433, Cable CAB-438, Power Supply 8-0935 and Power Cord 6003-0940)	PM9600-SR433RBK12
PowerScan PM9600-SR, Standard Range, 910MHz, Removable Battery	PM9600-SR910RB
PowerScan PM9600-SR, Standard Range, 910MHz, RS-232 Kit (Kit includes Scanner PM9600-SR, cradle BC9630-910, Cable CAB-548 , Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-SR910RBK20

PowerScan PM9600-SR, Standard Range, 910MHz, USB Kit (Kit includes Scanner PM9600-SR, Cradle BC9620-910, Cable CAB-438 , Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-SR910RBK12
PowerScan PM9600-SR, Standard Range, 910MHz, USB Kit (Kit includes Scanner PM9600-SR, cradle BC9630-910, Cable CAB-552 , Power Supply 8-0935 and Power Cord 6003-0941)	PM9600-SR910RBK10

BASE STATION	
BC9600 Base Station/Charger, 433 MHz, No Interface (requires CM96xx module)	BC9600-433
BC9600 Base Station/Charger, 910 MHz, No Interface (requires CM96xx module)	BC9600-910
BC9600 Base Station/Charger, Bluetooth, No Interface (requires CM96xx module)	BC9600-BT
BC9620 Base Station/Charger, 433 MHz, USB only, no compatibility with CM96xx modules	BC9620-433
BC9620 Base Station/Charger, 910 MHz, USB only, no compatibility with CM96xx modules	BC9620-910
BC9620 Base Station/Charger, Bluetooth, USB only, no compatibility with CM96xx modules	BC9620-BT
BC9630 Base Station/Charger, 433 MHz, Multi-Interface (RS-232, USB)	BC9630-433
BC9630 Base Station/Charger, 910 MHz, Multi-Interface (RS-232, USB)	BC9630-910
BC9630 Base Station/Charger, Bluetooth, Multi-Interface (RS-232, USB)	BC9630-BT
BC9631 Base Station/Charger, 433 MHz, Multi-Interface (RS-232, USB), IP65	BC9631-433
BC9631 Base Station/Charger, 910 MHz, Multi-Interface (RS-232, USB), IP65	BC9631-910
BC9631 Base Station/Charger, Bluetooth, Multi-Interface (RS-232, USB), IP65	BC9631-BT
BC9680 Base Station/Charger, 433 MHz, Ethernet / Profinet	BC9680-433
BC9680 Base Station/Charger, 910 MHz, Ethernet / Profinet	BC9680-910
BC9680 Base Station/Charger, Bluetooth, Ethernet / Profinet	BC9680-BT
BC9681 Base Station/Charger, 433 MHz, Ethernet / ETH IP, IP65	BC9681-433-N200
BC9681 Base Station/Charger, 433 MHz, Ethernet / Profinet, IP65	BC9681-433-N100
BC9681 Base Station/Charger, 910 MHz, Ethernet / ETH IP, IP65	BC9681-910-N200
BC9681 Base Station/Charger, 910 MHz, Ethernet / Profinet, IP65	BC9681-910-N100
BC9681 Base Station/Charger, Bluetooth, Ethernet / ETH IP, IP65	BC9681-BT-N200
BC9681 Base Station/Charger, Bluetooth, Ethernet / Profinet, IP65	BC9681-BT-N100
CM9680 Connection Module, Ethernet / Profinet	CM9680
CM9681 Connection Module, Ethernet / ETH IP, IP65	CM9681-N200
CM9681 Connection Module, Ethernet / Profinet, IP65	CM9681-N100

Connection Module, Multi-Interface (RS-232, USB)	CM9630
Connection Module, Multi-Interface (RS-232, USB), IP65	CM9631


EASEOFCARE AGREEMENTS	
PD96XXAR, 2 DAYS, 3 YEARS, COMP	ZSC2PD96AR31
PD96XXAR, 2 DAYS, 5 YEARS, COMP	ZSC2PD96AR51
PD96XXAR, 2 DAYS, RENEWAL, COMP	ZSC2PD96ARC1
PD96XXAR, 5 DAYS, 3 YEARS	ZSN5PD96AR31
PD96XXAR, 5 DAYS, 5 YEARS	ZSN5PD96AR51
PD96XXAR, 5 DAYS, RENEWAL	ZSN5PD96ARC1
PD96XXAR, OVRNGHT, 3 YEARS, COMP	ZSC1PD96AR31
PD96XXAR, OVRNGHT, 5 YEARS, COMP	ZSC1PD96AR51
PD96XXAR, OVRNGHT, RENEWAL, COMP	ZSC1PD96ARC1
PD96XXDPX, 2 DAYS, 3 YEARS, COMP	ZSC2PD96DPX31
PD96XXDPX, 2 DAYS, 5 YEARS, COMP	ZSC2PD96DPX51
PD96XXDPX, 2 DAYS, RENEWAL, COMP	ZSC2PD96DPXR1
PD96XXDPX, 5 DAYS, 3 YEARS	ZSN5PD96DPX31
PD96XXDPX, 5 DAYS, 5 YEARS	ZSN5PD96DPX51
PD96XXDPX, 5 DAYS, RENEWAL	ZSN5PD96DPXR1
PD96XXDPX, OVRNGHT, 3 YEARS, COMP	ZSC1PD96DPX31
PD96XXSR EofC 2 Days Comp 1 Year	ZSC2PD9611
PD96XXSR EofC 2 Days Comp 2 Year	ZSC2PD9621
PD96XXSR EofC Ovrnght Rplcmnt Comp 1 Yr	ZSC1PD9611
PD96XXSR EofC Ovrnght Rplcmnt Comp 2 Yr	ZSC1PD9621
PD96XXSR EofC Ovrnght Rplcmnt Comp 4 Yr	ZSC1PD9641
PD96XXSR/HP EofC 2 Days Comp 1Yr Renewal	ZSC2PD96C1
PD96XXSR/HP EofC 2 Days Comp 3 Year	ZSC2PD9631
PD96XXSR/HP EofC 2 Days Comp 5 Year	ZSC2PD9651

PD96XXSR/HP EofC 5 Days 1 Yr Renewal	ZSN5PD96C1
PD96XXSR/HP EofC 5 Days 3 Year	ZSN5PD9631
PD96XXSR/HP EofC 5 Days 5 Year	ZSN5PD9651
PD96XXSR/HP EofC Ovnght Rplcmt Comp 3 Yr	ZSC1PD9631
PD96XXSR/HP EofC Ovnght Rplcmt Comp 5 Yr	ZSC1PD9651
PD96XXSR/HP EofC Ovnght Rplmt Comp 1Yr R	ZSC1PD96C1
PM/BT96BASE, 2 DAYS, 3 YEARS, COMP	ZSC2PM96B31
PM/BT96BASE, 2 DAYS, 5 YEARS, COMP	ZSC2PM96B51
PM/BT96BASE, 2 DAYS, RENEWAL, COMP	ZSC2PM96BR1
PM/BT96BASE, 5 DAYS, 3 YEARS	ZSN5PM96B31
PM/BT96BASE, 5 DAYS, 5 YEARS	ZSN5PM96B51
PM/BT96BASE, 5 DAYS, RENEWAL	ZSN5PM96BR1
PM/BT96BASE, OVRNGHT, 3 YEARS, COMP	ZSC1PM96B31
PM/BT96BASE, OVRNGHT, 5 YEARS, COMP	ZSC1PM96B51
PM/BT96BASE, OVRNGHT, RENEWAL, COMP	ZSC1PM96BR1
PM/BT96XXAR, 2 DAYS, 3 YEARS, COMP	ZSC2PM96AR31
PM/BT96XXAR, 2 DAYS, 3 YEARS, COMP, BAT	ZSC2PM96AR3B
PM/BT96XXAR, 2 DAYS, 5 YEARS, COMP	ZSC2PM96AR51
PM/BT96XXAR, 2 DAYS, 5 YEARS, COMP, BAT	ZSC2PM96AR5B
PM/BT96XXAR, 2 DAYS, RENEW, COMP, BAT	ZSC2PM96ARCB
PM/BT96XXAR, 2 DAYS, RENEWAL, COMP	ZSC2PM96ARC1
PM/BT96XXAR, 5 DAYS, 3 YEARS	ZSN5PM96AR31
PM/BT96XXAR, 5 DAYS, 5 YEARS	ZSN5PM96AR51
PM/BT96XXAR, 5 DAYS, RENEWAL	ZSN5PM96ARC1
PM/BT96XXAR, OVRNGHT, 3 YEARS, COMP	ZSC1PM96AR31
PM/BT96XXAR, OVRNGHT, 5 YEARS, COMP	ZSC1PM96AR51
PM/BT96XXAR, OVRNGHT, RENEWAL, COMP	ZSC1PM96ARC1
PM/BT96XXDPX, 2 DAYS, 3 YEARS, COMP	ZSC2PM96DPX31

PM/BT96XXDPX, 2 DAYS, 3 YEARS, COMP, BAT	ZSC2PM96DPX3B
PM/BT96XXDPX, 2 DAYS, 5 YEARS, COMP	ZSC2PM96DPX51
PM/BT96XXDPX, 2 DAYS, 5 YEARS, COMP, BAT	ZSC2PM96DPX5B
PM/BT96XXDPX, 2 DAYS, RENEW, COMP, BAT	ZSC2PM96DPXRB
PM/BT96XXDPX, 2 DAYS, RENEWAL, COMP	ZSC2PM96DPXR1
PM/BT96XXDPX, 5 DAYS, 3 YEARS	ZSN5PM96DPX31
PM/BT96XXDPX, 5 DAYS, 5 YEARS	ZSN5PM96DPX51
PM/BT96XXDPX, 5 DAYS, RENEWAL	ZSN5PM96DPXR1
PM/BT96XXSR/HP, 2 DAYS, 1 YEAR, COMP	ZSC2PM9611
PM/BT96XXSR/HP, 2 DAYS, 3 YEARS, COMP	ZSC2PM9631
PM/BT96XXSR/HP, 2 DAYS, 5 YEARS, COMP	ZSC2PM9651
PM/BT96XXSR/HP, 2 DAYS, RENEWAL, COMP	ZSC2PM96C1
PM/BT96XXSR/HP, 5 DAYS, 3 YEARS	ZSN5PM9631
PM/BT96XXSR/HP, 5 DAYS, 5 YEARS	ZSN5PM9651
PM/BT96XXSR/HP, 5 DAYS, RENEWAL	ZSN5PM96C1
PM/BT96XXSR/HP, OVRNGHT, 3 YEARS, COMP	ZSC1PM9631
PM/BT96XXSR/HP, OVRNGHT, 5 YEARS, COMP	ZSC1PM9651
PM/BT96XXSR/HP, OVRNGHT, RENEWAL, COMP	ZSC1PM96C1
PM/BT96XXSR/HP,2 DAYS, 3 YEARS, COMP, BAT	ZSC2PM963B
PM/BT96XXSR/HP,2 DAYS, 5 YEARS, COMP, BAT	ZSC2PM965B
PM/BT96XXSR/HP,2 DAYS, RENEW, COMP, BAT	ZSC2PM96CB

BATTERIES/BATTERY CHARGERS	
Battery Pack, Removable, PowerScan 9600	RBP-PM96
Multi Battery Charger, Extension, 2-Slot	MC-P096-E2
Multi Battery Charger, Master, 2-Slot (requires the 90ACC0350 power supply)	MC-P096-M2
Multi Battery Charger, Master, 4-Slot (requires the 90ACC0350 power supply)	MC-P096-M4

CABLES	
Cable CAB-548, RS-232 PWR, 9P, Female, Straight, 2 m / 6.5 ft., IP67	CAB-548
Cable CAB-549, RS-232 PWR, 9P, Female, Coiled, 2.4 m / 7.8 ft., IP67	CAB-549
Cable CAB-551, USB Type A, PWR, Straight, 2 m / 6.5. ft. IP67	CAB-551
Cable CAB-552, USB TypeA, Straight, 2m / 6.5 ft., IP67	CAB-552
Cable CAB-553, USB Type A, Coiled, 2.4 m / 7.8 ft, IP67	CAB-553
Cable CAB-557, RS-232 PWR, 9P, Female, Coiled, 3.6 m / 11.8 ft., IP67	CAB-557
Cable CAB-558, RS-232 PWR, 9P, Female, Straight, 4.5 m / 14.7 ft., IP67	CAB-558
Cable CAB-559, RS-232 POT@9, 9P, Female, Coiled, 2.4 m / 7.8 ft., IP67	CAB-559
Cable CAB-560, PWR, USB Type A, Coiled, 3.6 m / 11.8 ft, IP67	CAB-560
Cable CAB-561, USB Type C, 2m / 6.5 ft, IP67	CAB-561
Cable CAB-562, USB Type A, PWR, Straight, 4.5m / 14.7 ft, IP67	CAB-562
Cable CAB-563, 12VDC, USB+PWR, 2m / 6.5 ft, IP67	CAB-563
Cable CAB-564, USB Type A, Straight, 3.6 m / 11.8 ft, IP67	CAB-564

CASES/HOLSTERS	
	Holster, Universal, HLS-8000
Protective Case/Belt Holster, PowerScan 9600	PC-P096

MOUNTS/STANDS	
Holder, Desk/Wall Mount, PowerScan 9600	HLD-P096
Stand, Hands-free, PowerScan 9600	STD-P096
Vehicle Mount, Kit, PowerScan 9600	VMK-P096

POWER SUPPLIES/CORDS	
ADAPTER, POWER PLUG, AUSTRALIA	90ACC0309
ADAPTER, POWER PLUG, EURO, 2 PIN	90ACC0307
ADAPTER, POWER PLUG, UK	90ACC0308
ADAPTER, POWER PLUG, US/JAPAN	90ACC0306
Power Adapter, 12V DC, AC/DC Regulated, RoHS (Requires Power Cord - 6003-XXXX)	8-0935
Power Cord, 110V, US, Standard	6003-0941
Power Cord, 220V, Australia	6003-0925
Power Cord, 220V, Italy/Chile	6003-0924
Power Cord, 240V, UK	6003-0923
Power Cord, 2-Pin, EU	90ACC1885
Power Cord, 2-Pin, UK	90ACC1887
Power Cord, 2-Pin, US	90ACC1886
Power Cord, AC, IEC/EU	6003-0940
Power Cord, IEC C13, Argentina	6003-0926
Power Supply, Switching, 12V, 5A (For Use with 6003-XXXX Power Cords)	90ACC0350