



VIVE Deluxe Pack included with VIVE XR Elite Business Edition*

The new top strap, face gasket, and temple clips provide additional support and comfort for your extended VR experiences. We're also including the mixed reality gasket to deliver spatial awareness when you need it.



VIVE Face Gasket 2.0

Ensures minimal light leakage and even pressure distribution for a more pleasant, natural fit.



VIVE Deluxe Strap

Expertly distributes weight between the front and back of the headset. Adjust to your preferred fit for more comfortable and fluid movement while immersed.



VIVE Temple Clips

Secures the glasses-battery cradle connection for better peace of mind and stability.



VIVE MR Gasket

Stay connected with your real-world surroundings. Offers enhanced peripheral vision and ventilation with a soft, cleanable forehead rest.

*Existing VIVE XR Elite owners can redeem their accessory pack at <https://business.vive.com/redeem-deluxe-pack-accessories/>

VIVE XR Elite Specs

What's in the Box

VIVE XR headset
Battery cradle
Controllers (L/R)
Lanyards x 2
Microfiber pouch
Top strap
USB Type-C to Type-C cable
USB Type-A to Type-C cable x 2
Lens protection card
Documentation (QSG / safety guide / warranty card)
Face Gasket 2.0 (Wide)
Narrow cushion for Face Gasket 2.0
Deluxe Strap
Temple Clips



Headset Specs

Resolution	1920x1920 pixels per eye (3840x1920 pixels combined)
Headset Tracking	6 DoF Inside-out Tracking
Refresh Rate	90 Hz
Field of View	Up to 110 degrees
Interpupillary Distance (IPD)	54 to 73mm
Audio	Dual microphones for echo cancellation Embedded speakers
Inputs	Dual integrated microphones Volume button Headset button
Processor	Qualcomm® Snapdragon™ XR2
Storage & Memory	128 GB / 12 GB
Connections	1x USB 3.2 Gen-1 Type-C peripheral port 1x USB 3.2 Gen-1 Type-C power port Bluetooth 5.2 + BLE Wi-Fi 6 + 6E ¹
Sensors	4x Tracking cameras 16 MP RGB camera Depth sensor G-sensor Gyroscope Proximity sensor
Ergonomics	Rear mounted ergonomically curved battery cradle Magnetically-attached front gasket
Battery	24.32Wh Lithium-Polymer Gel battery Up to 2 hours ⁷ of continuous power Removeable and hot-swappable
Tracking	VIVE Inside-out Tracking

Controller Specs

Inputs	Ergonomic Grip button Analog Trigger button AB / XY buttons System / Menu buttons Joystick
Sensors	Hall sensors on Trigger and Grip button Capacitive sensors on Trigger, Joystick, and Thumb-rest area G-Sensor Gyroscope
Battery	Integrated rechargeable battery (charged via USB-C) Up to 15 hours of battery life ²

Tracked Area Requirements

Standing/Seated	Both available
Room-scale	Up to 10m x 10m play area recommended Minimum play area is 1.5m x 1.5m (standing)

1. Wi-Fi 6E support is country dependent. For more details please refer to vive.com/us/support/focus3/category_howto/in-what-regions-can-wifi-6e-be-used.html.

2. All battery claim results will vary. Battery life and charge cycles vary by use.