



3. Hang Display onto the Wall Plate



Tighten bottom bolts to secure display brackets to the wall plate.

4. Adjustment



Loose the adjusting knobs to tilt desired angle then tighten them.

Maintenance


- · Check that the bracket is secure and safe to use at regular intervals(at least every three months).
- Please contact your dealer if you have any questions.

DR DN

Premium Mount Inc 7300 Bolsa Ave., Westminster, CA 92683 -Phone: 714-766-6303

INSTALLATION INSTRUCTIONS

Tilting Wall Mount





CAUTION: DO NOT EXCEED MAXIMUM LISTED WEIGHT CAPACITY. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

WB-2642








ISSUED: OCT.2012

⚠ WARNING


- Do not begin the installation until you have read and understood the instructions and warnings contained in this installation sheet. If you have any question regarding any of the instruction or warning, please contact your local distributor.
- This mounting bracket was designed to be installed and utilized ONLY as specified in this manual. Improper installation of this product may cause damage or serious injury.
- This product should only be installed by someone of good mechanical ability, with basic building experience and fully understanding of this manual.
- Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.
- If mounting to wood wall studs, make sure that mounting screws are anchored into the center of the studs. The use of a stud finder is highly recommended.
- Always use assistant or mechanical lifting equipment to safely lift and position equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can damage the items, greatly reducing their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Component Checklist


IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installing. If any parts are missing or faulty, telephone your local distributor for a replacement.



Package M




Package W




1++++

1a. Mount on Wood Stud Wall











Find and mark the exact location of mounting holes



Drill pilot holes






Screw the wall plate onto the wall

W-A

- Make sure that mounting screws are anchored into the center of the studs. The use of a stud finder is highly recommended.
- Installers are responsible to provide hardware for other types of mounting situations.
- Installers must verify that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.

1b. Mount on Solid Brick and Concrete Block










Drill pilot holes





Screw the wall plate onto the wall




MARNING MARNING


- When installing wall mounts on cinder block, verify the actual concrete thickness is at least
 1-3/8" (35mm) for using the concrete anchors. Do not drill into mortar joints! Be sure to
 mount in a solid part of the block, generally 1" (25mm) minimum from the side of the block.
 It is suggested electric drill on slow setting be used to drill the hole instead of a hammer drill
 to avoid breaking out the back of the hole when entering a void or cavity.
- Installers must verify that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.

3444

2. Install Adapter Brackets




2-1 For Flat Back Screen



2-2 For Recessed Back Screen or to Access A/V Inputs







Note: Choose appropriate screws, washers and spacers (if necessary) according to the type of screen.

- Position the adapter brackets as close as possible to the center of the display.
 Screw the adapter brackets onto the display.

Tighten all screws but do not over tighten.