Assembly Instructions
FocalPoint™ Projection Screen by Draper

⚠Caution

① Read instructions through completely before proceeding; retain for future reference.
② Handle viewing surface with care; do not allow it to come in contact with sharp or dirty objects.
③ These instructions are based on assembly by a minimum of two people.
④ Make sure screen is level.
⑤ Do not write on viewing surface.
⑥ The ideal temperature range for assembling folding screens to prevent damaging the surface is 68°-78° F (20°-26° C). Assembling below recommended temperatures may damage surface and void warranty.

Frame/Screen Assembly

① Remove tarp from case and place on the ground.



Figure 1

② Remove frame pieces from case and place in the appropriate locations on the tarp.



Figure 2

Please Note: Each piece is color-coded: refer to FocalPoint™ Assembly Map included with screen for correct layout (see reverse side).
Please Note: Frame pieces should be placed with "forks" running counter-clockwise and DuraLoop Attachment Lugs facing out (see Fig. 3).



Figure 3

③ Assemble frame by inserting "forks" of each piece into extrusions on the adjoining piece (see Fig. 3). Tighten by turning color-coded attachment knobs (see Fig. 4).



Figure 4

④ Remove leg pieces from case and place in the appropriate locations on the tarp.
⑤ Assemble leg according to color-coded assembly map by inserting "forks" of front extension into extrusion on the leg base and tighten color-coded attachment knobs. Also, attach vertical frame members in the same manner. Do not yet attach the back extension to the leg base (see Fig. 5).




Figure 5

⑥ Place the screen frame on top of the legs (see Fig. 6).
⑦ Attach legs to frame (see Fig. 6) using provided Leg Cranks as follows: Package A–3 cranks per leg; Package B–4 cranks per leg; and Package C–5 cranks per leg. Leg Cranks should be placed as follows: 1 at the lowest attachment point, 1 at the highest attachment point, and the rest evenly spaced between the two.




Figure 6

⑧ Attach viewing surface to frame (see Fig. 7).




Figure 7

⑨ Raise FocalPoint into place (this step requires at least two people, depending on screen size) (see Fig. 8).




Figure 8

⑩ Attach the back extensions to the leg bases (see Fig. 9).



Figure 9



⚠Caution: Beware of pinch points.

If you encounter any difficulties assembling your FocalPoint™, call your dealer or Draper, Inc. in Spiceland, Indiana, 765-987-7999, or fax 765-987-7142.

411 S. Pearl St., Spiceland, IN 47385 USA ▮ 765-987-7999
www.draperinc.com ▮ fax 765-987-7142
Copyright © 2010 Draper Inc. Form FocalPoint_Inst10 Printed in U.S.A.