# ViewSonic<sup>®</sup>

## VX4380-4K Display User Guide

IMPORTANT: Please read this User Guide to obtain important information on installing and using your product in a safe manner, as well as registering your product for future service. Warranty information contained in this User Guide will describe your limited coverage from ViewSonic Corporation, which is also found on our web site at http://www.viewsonic.com in English, or in specific languages using the Regional selection box in the upper right corner of our website. "Antes de operar su equipo lea cu idadosamente las instrucciones en este manual"

Model No. VS16845

## Thank you for choosing ViewSonic

As a world leading provider of visual solutions, ViewSonic is dedicated to exceeding the world's expectations for technological evolution, innovation, and simplicity. At ViewSonic, we believe that our products have the potential to make a positive impact in the world, and we are confident that the ViewSonic product you have chosen will serve you well

Once again, thank you for choosing ViewSonic!



## **Contents**

1.	Cautions and Warnings	1
2.	Getting Started	4
	2-1. Package Contents	5
	2-2. The Exterior of the Monitor	
	2-3. Hardware Installation	7
	2-4. Quick Installation	
	2-5. Power On	
	2-6. Driver Installation (Windows 10 Setup)	13
3.	Adjusting the Screen Image	14
	3-1. Setting the Timing Mode	14
	3-2. Using the Control Panel	15
4.	OSD Menu Introduction	17
	4-1. OSD Menu Tree	17
	4-2. OSD Menu Explanation	
	4-3. Monitor Setting Management	33
<b>5</b> .	Specifications	34
6.	Troubleshooting	36
7.	Cleaning and Maintenance	37
	Safe Cleaning Practices	37

8.	Compliance Information	39
	8-1. FCC Compliance Statement	39
	8-2. Industry Canada Statement	40
	8-3. Declaration of RoHS2 Compliance	40
	8-4. Indian Restriction of Hazardous Substances	42
	8-5. Product Disposal at End of Product Life	42
9.	Copyright Information	43
10.	Service Information	44
	Product Registration	44
	Customer Service	
	Limited Warranty	48
	Mexico Limited Warranty	53

## 1. Cautions and Warnings

- Read these instructions completely before using the equipment.
- 2. Keep these instructions in a safe place.
- 3. Heed all warnings and follow all instructions.
- 4. Sit at least 18" / 45cm from the monitor.
- 5. When installing the monitor, please leave 10cm of open space around the monitor for ventilation safety purposes.
- Always handle the display with care when moving it.
- 7. Exercise caution when removing the rear cover of the monitor. This monitor contains high-voltage parts.
- 8. Do not use this equipment near water. To reduce the risk of fire or electric shock, do not expose the monitor to rain or moisture.
- Avoid exposing the monitor to direct sunlight or other sources of sustained heat. Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that may increase the temperature of the monitor to dangerous levels.
- 10. Clean with a soft, dry cloth. If further cleaning is required, see "Cleaning the Display" in this guide for further instructions.
- 11. Avoid touching the screen. Skin oils are difficult to remove.
- 12. Do not touch, rub or apply pressure to the monitor screen, as it may permanently damage the screen.
- 13. Place the monitor in a well-ventilated area. Do not place anything on the display that prevents heat dissipation.
- Do not place heavy objects on the display, video cable, or power cord.

- 15. If smoke appears, an abnormal noise, or a strange odor is present, immediately switch the display off and call your dealer or ViewSonic. It is dangerous to continue using the display.
- 16. Do not attempt to circumvent the safety provisions of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade and the third prong are provided for your safety. If the plug does not fit into your outlet, obtain an adaptor and do not attempt to force the plug into the outlet.
- 17. When connecting to a power outlet, DO NOT remove the ground prong. Please ensure grounding prongs are NEVER REMOVED.
- 18. Protect the power cord from being treaded upon or pinched, particularly at the plug, and at the point where it emerges from the equipment. Be sure that the power outlet is located near the equipment so that it is easily accessible.
- 19. Only use attachments/accessories specified by the manufacturer.
- 20. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the equipment. When a cart is used, use with caution when moving the cart/equipment combination to avoid injury from tipping over.



21. Unplug this equipment when it will be unused for long periods of time.

- 22. Refer all servicing to qualified service personnel. Service will be required when the unit has been damaged in any way, such as: if the power-supply cord or plug is damaged, if liquid is spilled onto or objects fall into the unit, if the unit is exposed to rain or moisture, or if the unit does not operate normally or has been dropped.
- 23. Excessive sound pressure from ear-/headphones can cause hearing damage /hearing loss.
- 24. Adjustment of the volume control as well as the equalizer may increase the ear-/ headphones output voltage and therefore, the sound volume level.
- 25. The factors influencing the ear-/headphones output other than those specified by the manufacturer (e.g. operating system, equalizer software, firmware, driver) may increase the ear-/headphone output voltage and therefore, the sound volume level.

## 2. Getting Started

Should problems arise and the product you have purchased needs to be returned for any reason, please keep the original packaging, registration form, and receipt. Having these items will make it easier for you to verify your product and repair, refund and/or return your product to you.

If you have any problems with your product or questions that have not been addressed in the User Guide, please contact customer service for help.

Important! Save the original box and all packing material for your future shipping needs.

**NOTE:** The word "Windows" in this user guide refers to Microsoft Windows operating system.

## 2-1. Package Contents

Your monitor package includes:


- Monitor
- Power cord
- Video cable<sup>1</sup>
- · USB cable
- · Quick Start Guide

### NOTE:


<sup>1</sup> The video cables included in your package may vary depending on your country. Please contact your local reseller for more information.

## 2-2. The Exterior of the Monitor


### A. Front



## B. Left and Right



#### C. Rear



## 1. Control panel

(Expanded in 3-1)

### 2. I/O port (input/output)

This area should include all I/O connection options, as well as the power input connector (Expanded in 2-4)

## 3. Kensington security slot

(Expanded in 2-3 section B)

## 4. VESA wall mounting

This area on the back of the monitor\*. For the VESA wall mounting installation steps, please see 2-3 section A for additional instructions.

## 2-3. Hardware Installation

## A. Wall Mounting (Optional)

**NOTE:** For use only with a UL Listed Wall Mount Bracket.


To obtain a wall-mounting kit or height adjustment base, contact ViewSonic® or your local dealer. Refer to the instructions that come with the base mounting kit. To convert your display from a desk-mounted to a wall-mounted display, do the following:

- 1. Find VESA compatible wall-mounting kit which meets the quaternions in section "Specifications".
- 2. Verify that the power button is turned Off, then disconnect the power cord.
- 3. Lay the display face down on a towel or blanket.
- 4. Remove the base. (Screws removal might be required.)
- 5. Attach the mounting bracket from the wall mounting kit using screws of the appropriate length.
- 6. Attach the display to the wall, following the instructions in the wall-mounting kit.

## **B.** Using the Kensington Lock

The Kensington security connector is located on the back side of the monitor. For more information on installation and usage please visit the Kensington website at http://www.kensington.com.

Below is an example of setting up the Kensington lock on a table for your reference.




## 2-4. Quick Installation

## **Connect Signal Cables**


- 1. Make sure both the LCD monitor and computer are turned OFF.
- 2. Remove rear panel covers if necessary.
- 3. Connect the signal cables from the LCD monitor to the computer.

Macintosh users: Models older than G3 require a Macintosh adapter. Attach the adapter to the computer and plug the video cable into the adapter.

To order a ViewSonic® Macintosh adapter, contact ViewSonic Customer Support.



3.A. Please do not connect the DisplayPort out on the monitor to the DisplayPort or mini DP connector on the computer. DisplayPort out is used for daisy chain connection (Explained in section C)




## 3.B. Video and Audio Cable

For a MAC with Thunderbolt output, please connect the mini DP end of the "mini DP to DisplayPort cable" to the Thunderbolt output of MAC. And connect the other end of the cable to the DisplayPort connector on the rear of the monitor.

## 3.C. DisplayPort SST daisy chain connection

With DisplayPort Single-Stream Transport (SST) support, you can daisy chain connect up to two VX4380-4K monitors. If your Graphic Card is DP 1.2 compliant and support SST mode, connect one end of DP cable to the DP output of the PC/Laptop. Connect the other end of DP cable to the DP input or mini DP input connector on the rear of the monitor. Use another DP cable to connect DP output of the 1st monitor and DP input of the 2nd monitor.




- \* To speedup DisplayPort SST daisy chain handshaking process, suggest to disable Auto Detect function (Under OSD Setup Menu).
- \* For SST clone scenario, the DP output timing exactly the same as input.
  - Please make sure the 2nd monitor is capable to support, or the out of range condition may be expected.

<sup>\*</sup>This picture is for reference only

## 3.D. Power Cable (and AC/DC adapter if required)

Connect the female connector of AC power cord to the power connector of monitor, and the AC plug of AC power cord to the AC outlet.



## 2-5. Power On


## **Turn On LCD Monitor and Computer**

Turn ON the LCD Monitor, then turn ON the computer. This particular order (LCD monitor before computer) is important.

## 2-6. Driver Installation (Windows 10 Setup)

In order to install the driver, first connect your monitor to your PC, boot up your PC (make sure to first turn on the monitor first) and make sure your internet is available. When the PC has finished booting up, your PC should auto- detect the monitor.

To ensure auto-detection is successful, go to 'Advanced Display Settings' under your system 'Display Settings' (screen resolution) window. There you can verify your ViewSonic monitor has been recognized by your PC in the 'Color Management' section of your advanced settings.



If your PC has not auto-detected the monitor, but is still functioning, you can download the driver from ViewSonic website and install it then restart.your computer and follow the steps above again. It is not imperative for your computer to detect the monitor for normal use, but it is recommended.

If you encounter additional problems or have questions, please contact Customer Support.

## 3. Adjusting the Screen Image

## 3-1. Setting the Timing Mode

Set your monitor resolution to its recommended resolution (see section "specification") to get the best experience possible, with brilliant color and crisp text. Here is how:

- 1. Go to your display resolution settings window (each operating system will have a different process to get there).
- Next, adjust the display resolution setting to match your monitor's native resolution. This will provide you with your best usage experience.

If you have difficulty setting the resolution or you do not see recommended resolution as an available option, you may need a newer video card driver. Contact your computer or video card manufacturer to obtain the latest driver.

 If necessary, make small adjustments using H. POSITION and V. POSITION until the screen image is completely visible. (\*for analog only). (The black border around the edge of the screen should barely touch the illuminated "active area" of the LCD monitor.)

## 3-2. Using the Control Panel

After setting the timing mode, use the buttons on the front or rear control panel to display and adjust OSD for screen image adjustment.



<sup>\*</sup> The postition refer to section 2.2

## **Bezel & OSD symbol explanation**


The bezel symbol explanation is stated below:

	Standby Power On/Off
Q	NOTE: Power light  Blue = ON  Orange = Power Saving
	Under MULTI-PICTURE MODE you can select the following settings, QUAD WINDOW, PBP TOP-BOTTOM, PBP LEFT-RIGHT, and PIP.
•	View Mode icon that allows users to choose which View mode setting they would like to activate for monitor use.
	Toggles between the various input options that are available for that particular monitor.
=	Main menu icon that allows users to access the main menu.

## The OSD Menu and OSD Quick-Menu Symbol explanations and their functional uses are stated below.



Activation symbol to exit, go back or deactivate the desired function that is selected.



Symbol used to go back or revert back to the previously selected menu

Information shortcut select button, which gives users access to the information of the monitor currently in use.

Main menu icon that allows users to access the main menu.

Hold down the icon for a few seconds to turn off the main menu


Left and right icons toggle your selected choice horizontally.

OSD quick menu selector, which increases or decreases the currently selected function

## 4. OSD Menu Introduction

## 4-1. OSD Menu Tree

For an explanation of the OSD tree and pertaining functions, please refer to the 4-2 OSD explanation below. The OSD tree visually represents the complete OSD menu that can be accessed by your monitor. If you aren't sure where an option/function is or cannot locate a specific feature, please utilize the OSD tree below.



Joystick Button			
Coystick Button	Custom1		
	Custom2		
	Custom3		
	FPS 1		
Game Mode	FPS 2		
Game Mode	RTS		
	MOBA		
	Off		
	Exit		
	Contrast (-/+)		
Contrast/Brightness	Brightness (-/+)		
Audio Adjust	Volume (-/+)		
Menu	Menu OSD table detail items		
	Werld OSD table detail items		
Exit (OSD off)	LIDAMA		
	HDMI1		
Input Select	HDMI2		
	DisplayPort		
***	miniDP		
Menu	Menu OSD table detail items		
	Standard		
	Game		
March and a	Movie		
ViewMode	Web		
	Text		
	MAC		
	Mono		
	Off		
	PBP Top-Bottom		
Multi-Picture	PBP Left-Right		
	PIP		
	Quad Windows		



Menu		
	HDMI1	
Input Select	HDMI2	
(for multi-source model)	DISPLAYPORT	
	miniDP	
	Volume	(-/+)
		On
	Mute	Off
Audio Adjust		HDMI1
	Audio Outout	HDMI2
	Audio Output	DisplayPort
		miniDP

Low Input Lag					
Dow Input Lag  Off  Black Stabilization Advanced DCR (-/+) Blue Light Filter (-/+)	Menu				
Black Stabilization Advanced DCR (-/+) Blue Light Filter (-/+)			Low Input Lag		
Stabilization  Advanced DCR (-/+)  Blue Light Filter (-/+)			Low input Lag	Off	
Advanced DCR (-/+) Blue Light Filter (-/+)			Black	(_/+)	
Blue Light Filter (-/+)		Stabilization	Stabilization	(-/ ' )	
			Advanced DCR	(-/+)	
Chandand			Blue Light Filter	(-/+)	
Standard				Standard	
Response Time Advanced			Response Time	Advanced	
Ultra Fast		Standard		Ultra Fast	
Red (-/			Hue	Red	(-/+)
Green (-/	\C. B			Green	(-/+)
Standard Blue (-/	ViewMode			Blue	(-/+)
HUE				Cyan	(-/+)
					(-/+)
					(-/+)
				Red	(-/+)
				Green	(-/+)
Blue (-/				Blue	(-/+)
Saturation			Saturation		(-/+)
					(-/+)
					(-/+)
Recall			Possil	TCHOW	(-/ ' )

Menu					
				On	
			Low Input Lag	Off	
			Black Stabilization	(-/+)	
			Advanced DCR	(-/+)	
			Blue Light Filter	(-/+)	
				Standard	
				Advanced	
				Ultra Fast	
				Red	(-/+)
				Green	(-/+)
				Blue	(-/+)
		Custom1	Hue	Cyan	(-/+)
				Magenta	(-/+)
	Game			Yellow	(-/+)
			Saturation	Red	(-/+)
				Green	(-/+)
				Blue	(-/+)
ViewMode				Cyan	(-/+)
				Magenta	(-/+)
				Yellow	(-/+)
			Rename		
			Recall		
			Low Input Lag	On	
				Off	
			Black Stabilization	(-/+)	
			Advanced DCR	(-/+)	
			Blue Light Filter	(-/+)	
				Standard	
		Custom2	Response Time	Advanced	
				Ultra Fast	, , ,
				Red	(-/+)
				Green	(-/+)
			Hue	Blue	(-/+)
				Cyan	(-/+)
				Magenta	(-/+)
				Yellow	(-/+)

Menu					
				Red	(-/+)
				Green	(-/+)
			0.1	Blue	(-/+)
			Saturation	Cyan	(-/+)
		Custom2		Magenta	(-/+)
				Yellow	(-/+)
			Rename		` ′
			Recall		
			Low Input Lag	On	
				Off	
			Black Stabilization	(-/+)	
			Advanced DCR	(-/+)	
			Blue Light Filter	(-/+)	
				Standard	
			Response Time	Advanced	
	Game			Ultra Fast	
			Hue	Red	(-/+)
		Custom3		Green	(-/+)
				Blue	(-/+)
ViewMode				Cyan	(-/+)
				Magenta	(-/+)
				Yellow	(-/+)
			Saturation	Red	(-/+)
				Green	(-/+)
				Blue	(-/+)
				Cyan	(-/+)
				Magenta	(-/+)
				Yellow	(-/+)
			Rename		
			Recall		
		FPS 1			
		FPS 2			
		RTS			
		MOBA			
	Movie				
	Web				
	Text				
	MAC				
	Mono				

Menu			
Morra	O and a set I/D in I/O and	Contrast	(-/+)
	Contrast/Brightness	Brightness	(-/+)
		SRGB	
		Bluish	
		Cool	
	Color Tomporaturo	Native	
	Color Temperature	Warm	
			Red
		User Color	Green
			Blue
Color Adjust	Adjust Color Space	Auto	
Color Aujust		RGB	
		YUV	
	Color Range	Auto	
		Full Range	
		Limited Range	
	Gamma	1.8	
		2.0	
		2.2	
		2.4	
		2.6	
		2.8	
	Sharpness	(-/+)	
		1:1	
Manual	Aspect Ratio	4:3	
Image Adjust		Fill Aspect Ratio	
		Full Screen	
	Overscan	On Off	
		Off	

Menu		
		English
		Français
		Deutsch
		Español
		Italiano
	1	Suomi
	Language	Русский
		Türkçe
		日本語
		한국어
		繁體中文
		简体中文
		On
	Resolution Notice	Off
	Information	
	OSD Timeout	(-/+)
		On
Setup Menu	OSD Background	Off
		On
	Power Indicator	Off
	Auto Power Off	On
		Off
	Clean	30 Minutes
		45 Minutes
		60 Minutes
	Sleep	120 Minutes
		Off
	500 M	Standard
	ECO Mode	Optimize
		Conserve
	DisplayPort1.1	On
		Off
	DDC/CI	On
	550/01	Off

Menu				
		Off		
		PBP Top- Bottom	Top Source Select	HDMI1 HDMI2 DisplayPort miniDP HDMI1
			Bottom Source Select	HDMI2 DisplayPort miniDP
			Swap	
	up Menu Multi-Picture	PBP Left- Right	Left Source Select	HDMI1 HDMI2 DisplayPort miniDP
Setup Menu			Right Source Select	HDMI1 HDMI2 DisplayPort miniDP
			Swap	
		PIP	PIP Source Select	HDMI1 HDMI2 DisplayPort miniDP
			PIP Position	PIP H.Position PIP V.Position
			PIP Size	(-/+)
				PIP Swap

Menu				
				HDMI1
			T 1 -#	HDMI2
			Top-Left	DisplayPort
				miniDP
				HDMI1
			Top Dight	HDMI2
			Top-Right	DisplayPort
	Multi-Picture	Quad Windows		miniDP
	Multi-i icture		Bottom-Left	HDMI1
	ıp Menu			HDMI2
Setup Menu				DisplayPort
				miniDP
			Bottom-Right	HDMI1
				HDMI2
				DisplayPort
				miniDP
	Standby	On		
	Charger	Off		
	Austa Data at	On		
	Auto Detect	Off		
	Memory Recall			

## 4-2. OSD Menu Explanation

**NOTE:** The OSD menu items listed in this section indicate the entire

OSD items of all models. Some of these items may not exist in your product OSD. Please disregard OSD menu item explanations if they do not exist in your OSD Menu. Please refer to the 4-1 OSD Tree (above), for your monitor's available OSD menu items. Please refer to the OSD explanation below (in alphabetical order), for a clearer explanation of what each function does.

#### ▲ Advanced DCR

Advanced DCR technology automatically detects the image signal and intelligently controls the backlight brightness and color, to improve on the ability to make the black blacker in a dark scene, and make the white whiter in a bright environment.

#### **Auto Detect**

If current input source is no signal, monitor will automatically switch to next input option. This function on some model is disabled by default.

## **B** Black stabilization

ViewSonic's Black stabilization provides heightened visibility and detail by brightening dark scenes.

## Blue light filter

Adjusts the filter that blocks high-energy blue light for a safer experience for our users.

## **Brightness**

Adjusts background black levels of the screen image.

### C Color adjust

Provides several color adjustment modes, to help adjust the color settings to fit our users' needs.

### Color range

Adjusts the color range, allowing users to adjust the range in RGB and YUV color settings.

### Color space

Allows users to choose which color space they would like to use for monitor color output (RGB, YUV).

#### C Color temperature

Allows users to select specific color temperature settings to further customize their viewing experience.

	Explanation
sRGB	Standard color space used for the windows system, digital
	cameras and the Internet.
NATIVE	Native is a default color temperature.
	Recommended for general graphic design and regular use.

#### Contrast

Adjusts the difference between the image background (black level) and the foreground (white level).

#### Custom

Providing even more support, three customizable 'Custom' settings are available to help match individual preferences and adapt to every type of game on the market. Select one of the 'Custom' options (Custom 1, Custom 2 etc.) in the Menu and adjust the advanced options. After exiting the setting will automatically be saved under that particular 'Custom' setting or rename the setting to your liking by selecting 'Rename'. You can access your saved 'GAME MODE' settings with the Quick Menu as well.

## G Game mode

Integrating a gaming-oriented OSD design including pre-calibrated FPS, RTS and MOBA gaming settings, each mode is functionally customized with in-game testing and adjustments made for the best blend of color and technology. To access the game mode first open the Main Menu setting, then go to 'ViewMode', select 'Game' and change your 'GAMER' settings from there.

#### **GAMMA**

Allows users to manually adjust the brightness level of the monitor's grayscale levels. There are five selections: 1.8, 2.0, 2.2, 2.4, and 2.6.

### H HUE

Adjusts the hue of each color (red, green, blue, cyan, magenta and yellow).

#### Information

Displays the timing mode (video signal input) coming from the graphics card in the computer, the LCD model number, the serial number, and the ViewSonic® website URL. See your graphics card's user guide for instructions on changing the resolution and refresh rate (vertical frequency).

**NOTE:** VESA 1024 x 768 @ 60Hz (example) means that the resolution is 1024 x 768 and the refresh rate is 60 Hertz.

## Input select

Toggles between the various input options that are available for that particular monitor.

## Low input lag

ViewSonic offers low input lag, utilizing a monitor process reducer, which decreases signal latency. Under the low input lag submenu, you can select the appropriate speed for your desired use from the two options

## Manual image adjust

Displays the Manual Image Adjust menu. You can manually set a variety of image quality adjustments.

#### Multi-picture

Under MULTI-PICTURE MODE you can select the following settings, QUAD WINDOW, PBP TOP-BOTTOM, PBP LEFT-RIGHT, and PIP. The explanations for each setting are below.

- 1. QUAD WINDOWS: You can select four picture split screen type.
- 2. PBP TOP-BOTTOM: You can select two picture split screen types, and display two pictures side-by-sides on the top and bottom.
- 3. PBP LEFT-RIGHT: You can select 2 picture split screen types, and display 2 pictures side-by-side on the left and right.
- 4. PIP: Two picture split screen types, display large and the small pictures on the screen.
- 5. PIP SIZE: This controls the size of the sub-picture used in PIP.
- PIP POSITION: This controls the position of sub-picture used in PIP mode.
- 7. PIP SWAP: This swaps the main-picture source and the sub-picture source.
- 8. SOURCE SELECT: This selects the source of the MULTI-PICTURE use in the
- 9. QUAD WINDOW, PBP TOP-BOTTOM, PBP LEFT-RIGHT and PIP.

## Memory recall

Returns the adjustments back to factory settings if the display is operating in a factory Preset Timing Mode listed in the Specifications of this manual.

**Exception:** This control does not affect changes made with the Language Select or Power Lock setting

#### Overscan

Can be used to adjust the aspect ratio of the input signal received by your monitor to adjust the image so it appears on the monitor.

### Response time

Adjusts the response time, creating smooth images without streaking, blurring or ghosting. A low response time is perfect for the most graphic-intense gaming, and provides amazing visual quality while watching sports or action movies. Setting the menu to 'Ultra Fast' is advised.

#### Resolution notice

The notice tells users that the current viewing resolution is not the correct native resolution. This notice will appear in the display settings window, when setting up the display resolution.

#### Recall

Resets the ViewMode monitor settings.

### Setup menu

Adjusts On-screen Display (OSD) settings. Many of these settings can activate on-screen display notifications so users do not have to reopen the menu.

#### **Sharpness**

Adjusts the sharpness and picture quality of the monitor.

#### ViewMode

ViewSonic's unique ViewMode feature offers "Game," "Movie," "Web," "Text," and "Mono" presets. These presets are specifically designed to deliver an optimized viewing experience for different screen applications.

# 4-3. Monitor Setting Management

#### **OSD Timeout**

The OSD Timeout function, allows users to choose how long the OSD will reside on the screen after in-activity (number of seconds).

### **OSD Background**

The OSD Background function allows users to turn off the OSD background while selecting and adjusting OSD settings.

### **Power Indicator**

The power indicator is the light that displays whether the monitor is on or off.

#### **Auto Power Off**

Selecting Auto Power Off, allows the monitor to shut its power off after a certain amount of time.

### Sleep

This setting allows users to adjust the time of inactivity before the monitor goes on a reduced power mode. The screen will be on 'sleep mode' during this time.

### **Eco Mode**

Allows users to choose between various modes, based on power consumption.

## **DDC/CI (Display Data Channel Command Interface)**

Activating this setting allows monitor control via the graphics card.

# 5. Specifications

LCD	Туре	TFT (Thin Film Transistor), Active Matrix 3840X2160 LCD, 0.2451 mm x 0.2451 mm pixel pitch
	Display Size	Metric: 107.99 cm Imperial: 43" (42.5" viewable)
	Color Filter	RGB vertical stripe
	Glass Surface	Anti-Glare
Input Signal	Video Sync	TMDS digital (100ohms) f <sub>h</sub> :24-160 kHz, f <sub>v</sub> :50-75 Hz
Compatibility	PC Macintosh¹	Up to 3840 x 2160 Non-interlaced Power Macintosh up to 3840 x 2160 (Supported by limited graphic cards)
Resolution <sup>2</sup>	Recommended	3840 X 2160@60Hz
	Supported	1920 x 1080 @ 60 Hz 1680 x 1050 @ 60 Hz 1280 x 1024 @ 60, 75 Hz 1440 x 900 @ 60 Hz 1024 x 768 @ 60, 70, 75 Hz 800 x 600 @ 56, 60, 72, 75 Hz 640 x 480 @ 60, 72, 75 Hz 720 x 400 @ 70 Hz
Power Adaptor <sup>3</sup>	Input Voltage	100-240 VAC, 50/60 Hz (auto switch)
Display area	Full Scan	941.18mm (H) x 529.42 mm (V) 37.05" (H) x 20.84" (V)

Operating	Temperatu	ire +32	°F to +104 °F (0	°C to +40	°C)
conditions	Humidity	10%	to 90% (non-con	densing)	
	Altitude	To 1	0,000 feet		
Storage	Temperatu	ıre -4 °F	to +140 °F (-20	°C to +60	°C)
conditions	Humidity	5% t	o 90% (non-cond	ensing)	
	Altitude	To 4	0,000 feet		
Dimensions	Physical		98 mm(W) x 652. 36 mm(D)	82 mm(H	) x
Wall Mount	Max Loading	Hole pattern (W x H; mm)	Interface Pad (W x H x D)	Pad Hole	Screw Q'ty & Specification
Wall Mount	1010051			1	
Wall Mount Weight	Loading	(W x H; mm) 100mm x 100mm	(W x H x D)  115 mm x 115 mm x	Hole	Specification 4 piece
	Loading 14kg	100mm x 100mm 31.86	(W x H x D)  115 mm x 115 mm x 2.6 mm	Hole Ø 5mm	4 piece M4 x 10mm

- <sup>1</sup> Macintosh computers may require a ViewSonic<sup>®</sup> Macintosh adapter. To order an adapter, contact ViewSonic.
- <sup>2</sup> Do not set the graphics card in your computer to exceed these timing mode; doing so may result in permanent damage to the display.
- <sup>3</sup> Please use the power adaptor from ViewSonic® or authorized source only.
- <sup>4</sup> The test condition follows EEI standard

# 6. Troubleshooting

### No power

- Make sure the power button (or switch) is ON.
- Make sure the A/C power cord is securely connected to the display.
- Plug another electrical device (like a radio) into the power outlet to verify that the outlet is supplying proper voltage.

### Power is ON but no screen image

- Make sure the video cable supplied with the display is properly secured to the video output port on the back of the computer. If the other end of the video cable is not attached permanently to the display, properly secure it to the display.
- Adjust brightness and contrast.
- If you are using an Macintosh older than G3, you need a Macintosh adapt

### Wrong or abnormal colors

- If any colors (red, green, or blue) are missing, check the video cable to make sure it is securely connected. Loose or broken pins in the cable connector could cause an improper connection.
- Connect the display to another computer.
- If you have an older graphics card, contact ViewSonic® for a non-DDC adapter.

### Control buttons do not work

· Press only one button at a time.

# 7. Cleaning and Maintenance

# **Safe Cleaning Practices**

- · Make sure the display is turned off.
- Never spray or pour any liquid directly onto the screen or case.

#### To clean the screen:

- 1. Wipe the screen with a clean, soft, lint-free cloth. This removes dust and other particles.
- 2. If the screen is still not clean, apply a small amount of non-ammonia, non-alcohol based glass cleaner onto a clean, soft, lint-free cloth, and wipe the screen.

#### To clean the case:

- 1. Use a soft, dry cloth.
- 2. If the case is still not clean, apply a small amount of a non-ammonia, non-alcohol based, mild non-abrasive detergent onto a clean, soft, lint-free cloth, then wipe the surface.

### **Disclaimer**

- ViewSonic® does not recommend the use of any ammonia or alcohol-based cleaners on the display screen or case. Some chemical cleaners have been reported to damage the screen and/or case of the display.
- ViewSonic will not be liable for damage resulting from use of any ammonia or alcoholbased cleaners.

### Caution:



Handle the monitor on the edges only.



Clean with water on a soft cotton cloth only.

# 8. Compliance Information

**NOTE:** This section addresses all connected requirements and statements regarding regulations. Confirmed corresponding applications shall refer to nameplate labels and relevant markings on unit.

## 8-1. FCC Compliance Statement

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning:** You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

## 8-2. Industry Canada Statement

CAN ICES-3 (B)/NMB-3(B)

## 8-3. Declaration of RoHS2 Compliance

This product has been designed and manufactured in compliance with Directive 2011/65/EU of the European Parliament and the Council on restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS2 Directive) and is deemed to comply with the maximum concentration values issued by the European Technical Adaptation Committee (TAC) as shown below:

Substance	Proposed Maximum Concentration	Actual Concentration
Lead (Pb)	0.1%	< 0.1%
Mercury (Hg)	0.1%	< 0.1%
Cadmium (Cd)	0.01%	< 0.01%
Hexavalent Chromium (Cr <sup>6+</sup> )	0.1%	< 0.1%
Polybrominated biphenyls (PBB)	0.1%	< 0.1%
Polybrominated diphenyl ethers (PBDE)	0.1%	< 0.1%

# Certain components of products as stated above are exempted under the Annex III of the RoHS2 Directives as noted below:

Examples of exempted components are:

- Mercury in cold cathode fluorescent lamps and external electrode fluorescent lamps (CCFL and EEFL) for special purposes not exceeding (per lamp):
  - (1) Short length (≤500 mm): maximum 3.5 mg per lamp.
  - (2) Medium length (>500 mm and  $\leq$ 1,500 mm): maximum 5 mg per lamp.
  - (3) Long length (>1,500 mm): maximum 13 mg per lamp.
- 2. Lead in glass of cathode ray tubes.
- 3. Lead in glass of fluorescent tubes not exceeding 0.2% by weight.
- 4. Lead as an alloying element in aluminium containing up to 0.4% lead by weight.
- 5. Copper alloy containing up to 4% lead by weight.
- 6. Lead in high melting temperature type solders (i.e. lead-based alloys containing 85% by weight or more lead).
- 7. Electrical and electronic components containing lead in a glass or ceramic other than dielectric ceramic in capacitors, e.g. piezo-electronic devices, or in a glass or ceramic matrix compound.

## 8-4. Indian Restriction of Hazardous Substances

Restriction on Hazardous Substances statement (India) This product complies with the "India E-waste Rule 2011" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

## 8-5. Product Disposal at End of Product Life

ViewSonic respects the environment and is committed to working and living green. Thank you for being part of Smarter, Greener Computing.

Please visit ViewSonic website to learn more.

#### **USA & Canada:**

http://www.viewsonic.com/company/green/recycle-program/

## Europe:

http://www.viewsoniceurope.com/uk/support/recycling-information/

Taiwan: http://recycle.epa.gov.tw/recycle/index2.aspx

# 9. Copyright Information

Copyright ©ViewSonic® Corporation, 2017. All rights reserved.

Macintosh and Power Macintosh are registered trademarks of Apple Inc.

Microsoft, Windows, and the Windows logo are registered trademarks of Microsoft Corporation in the United States and other countries.

ViewSonic, the three birds logo, OnView, ViewMatch, and ViewMeter are registered trademarks of ViewSonic Corporation.

VESA is a registered trademark of the Video Electronics Standards Association. DPMS, DisplayPort, and DDC are trademarks of VESA.

ENERGY STAR® is a registered trademark of the U.S. Environmental Protection Agency (EPA).

As an ENERGY STAR® partner, ViewSonic Corporation has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

Disclaimer: ViewSonic Corporation shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from furnishing this material, or the performance or use of this product.

In the interest of continuing product improvement, ViewSonic Corporation reserves the right to change product specifications without notice. Information in this document may change without notice.

No part of this document may be copied, reproduced, or transmitted by any means, for any purpose without prior written permission from ViewSonic Corporation.

# 10. Service Information

# **Product Registration**

Thank you for purchasing a ViewSonic product! Registering activates your product's standard Limited Warranty and entitles you to receive new product updates and information if desired.

Please complete this form to register your new product, then mail/fax to ViewSonic using the information provided on the following page. Items marked with an asterisk (\*) are required.

First Name* (given name)	
Last Name* (family name)	
Email Address*	
Street Address* (line 1)	
Street Address* (line 2)	
City/County*	State/Province*
Zip code/Postal code*	Country*
Phone Number*	Date Purchased*
Product Type*	Model Number*
Serial Number*	
Operating System	
YES NO Check "YES" to recie exclusive promotional	eve email communication from ViewSonic, including al offers.
At ViewSonic we respect your privacy. ViewSonic of	does not sell its customer lists or similar information to third parties.



\*Product registration available in selected countries only

## **Customer Service**

For technical support or product service, see the table below or contact your reseller.

NOTE: You will need the product serial number.

Asia pacific			
Country/ Region	Website	T= Telephone C = CHAT ONLINE	Email
ViewSonic Corporation	http://www.viewsonic.com.tw/	T= 886 2 2246 3456 F= 886 2 2249 1751 Toll Free= 0800-899880	service@tw.viewsonic.
China	www.viewsonic.com.cn	T= 4008 988 588	service.cn@ cn.viewsonic.com
Hong Kong	www.hk.viewsonic.com	T= 852 3102 2900	service@hk.viewsonic.
Macau	www.hk.viewsonic.com	T= 853 2870 0303	service@hk.viewsonic.
Japan	www.viewsonicjapan.co.jp	T= 0120 341 329	service@jp.viewsonic. com
Korea	ap.viewsonic.com/kr/	T= 080 333 2131	service@kr.viewsonic. com
India	www.in.viewsonic.com	T= 1800 419 0959	service@in.viewsonic.
Singapore/ Malaysia/ Thailand	www.ap.viewsonic.com	T= 65 6461 6044	service@sg.viewsonic. com
Europe			
Europe	www.viewsoniceurope.com	http://www.viewsoniceurope.com	m/eu/support/call-desk/
Arabia	ap.viewsonic.com/me/		اتصل بالبائع المحلي
България	www.viewsoinceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_bg@ viewsoniceurope.com
Hrvatska	www.viewsoinceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_hr@ viewsoniceurope.com
Česká Republika	www.viewsoniceurope.com	www.viewsoniceurope. com/uk/support/call-desk/	service_cz@ viewsoniceurope.com
Nederland	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_nl@ viewsoniceurope.com
Suomi	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_fi@ viewsoniceurope.com
France et autres pays francophones en Europe	www.viewsoniceurope.com/fr/	www.viewsoniceurope.com/ fr/support/call-desk/	service_fr@ viewsoniceurope.com
Canada	www.viewsonic.com	T= 1-866-463-4775	service.ca@viewsonic. com

Suisse	www.viewsoniceurope.com/de/	www.viewsoniceurope.com/de/ support/call-desk/	service_ch@ viewsoniceurope.com
Belgique (Français)	www.viewsoniceurope.com/fr/	www.viewsoniceurope.com/fr/ support/call-desk/	service_be@ viewsoniceurope.com
Luxembourg (Français)	www.viewsoniceurope.com/fr/	www.viewsoniceurope.com/fr/ support/call-desk/	service_lu@ viewsoniceurope.com
Deutschland	www.viewsoniceurope. com/de/	www.viewsoniceurope.com/de/ support/call-desk/	service_deu@ viewsoniceurope.com
Österreich	www.viewsoniceurope. com/de/	www.viewsoniceurope.com/de/ support/call-desk/	service_at@ viewsoniceurope.com
Schweiz (Deutsch)	www.viewsoniceurope. com/de/	www.viewsoniceurope.com/de/ support/call-desk/	service_ch@ viewsoniceurope.com
Ελλάδα	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_gr@ viewsoniceurope.com
Magyar Köztársaság	www.viewsoniceurope. com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_hu@ viewsoniceurope.com
Italia e altri paesi di lingua italiana in Europa	www.viewsoniceurope. com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_it@ viewsoniceurope.com
Spain	www.viewsoniceurope.com/es/	www.viewsoniceurope.com/es/ support/call-desk/	service_es@ viewsoniceurope.com
Latinoamérica (México)	www.viewsonic.com/la/	T= 001-8882328722	soporte@viewsonic.
Italia e altri paesi di lingua italiana in Europa	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_it@ viewsoniceurope.com
Polska i inne kraje Europy Centralnej	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_pl@ viewsoniceurope.com
Portugal	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_pt@ viewsoniceurope.com
România	www.viewsoinceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_ro@ viewsoniceurope.com
Россия	www.viewsoniceurope.com/ru/	www.viewsoniceurope.com/ru/ support/call-desk/	service_ru@ viewsoniceurope.com
Беларусь (Русский)	www.viewsoniceurope.com/ru/	www.viewsoniceurope.com/ru/ support/call-desk/	service_br@ viewsoniceurope.com
Латвия (Русский)	www.viewsoniceurope.com/ru/	www.viewsoniceurope.com/ru/ support/call-desk/	service_lv@ viewsoniceurope.com
Srbija	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_rs@ viewsoniceurope.com
Slovensko	www.viewsoinceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_sk@ viewsoniceurope.com
Slovenija	www.viewsoinceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_si@ viewsoniceurope.com
Sverige	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_se@ viewsoniceurope.com

	http://www.viewsoniceurope.	www.viewsoniceurope.com/tr/	service tr@
Türkiye	com/tr/	support/call-desk/	viewsoniceurope.com
Україна	www.viewsoniceurope.com	http://www.viewsoniceurope. com/eu/support/call-desk/	service_ua@ viewsoniceurope.com
America			
Australia New Zealand	www.viewsonic.com.au	AUS= 1800 880 818 NZ= 0800 008 822	service@ au.viewsonic.com
Canada	www.viewsonic.com	T= 1-866-463-4775	service.ca@viewsonic.
Latin America (Argentina)	www.viewsonic.com/la/	C= http://www.viewsonic.com/ la/soporte/servicio-tecnico	soporte@viewsonic.
Latin America (Chile)	www.viewsonic.com/la/	C= http://www.viewsonic.com/ la/soporte/servicio-tecnico	soporte@viewsonic.
Latin America (Columbia)	www.viewsonic.com/la/	C= http://www.viewsonic.com/ la/soporte/servicio-tecnico	soporte@viewsonic.
Latin America (Mexico)	www.viewsonic.com/la/	C= http://www.viewsonic.com/ la/soporte/servicio-tecnico	soporte@viewsonic. com
Nexus Hightech Tel: 55) 6547-64	Solutions, Cincinnati #40 Desp. 1 454 55)6547-6484	1 Col. De los Deportes Mexico D.	F.
Other places ple	ease refer to http://www.viewsonic	c.com/la/soporte/servicio-tecnico#	mexico
Latin America (Peru)	www.viewsonic.com/la/	C= http://www.viewsonic.com/ la/soporte/servicio-tecnico	soporte@viewsonic.
Middle East	ap.viewsonic.com/me/	Contact your reseller	service@ ap.viewsonic.com
Puerto Rico & Virgin Islands	www.viewsonic.com	T= 1-800-688-6688 (English) C= http://www.viewsonic.com/ la/soporte/servicio-tecnico	service.us@viewsonic. com soporte@viewsonic. com
South Africa	ap.viewsonic.com/za/	Contact your reseller	service@ ap.viewsonic.com
United States	www.viewsonic.com	T= 1-800-688-6688	service.us@viewsonic.

## **Limited Warranty**

## ViewSonic® Display

### What the warranty covers:

ViewSonic warrants its products to be free from defects in material and workmanship during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic will, at its sole option, and as your sole remedy, repair or replace the product with a similar product. Replacement Product or parts may include remanufactured or refurbished parts or components. The repair or replacement unit or parts or components will be covered by the balance of the time remaining on the customer's original limited warranty and the warranty period will not be extended. ViewSonic provides no warranty for any third-party software whether included with the product or installed by the customer, installation of any unauthorized hardware parts or components (e.g. Projector Lamps). (Please refer to: "What the warranty does not cover" section)

### How long the warranty is effective:

ViewSonic displays are warranted for between 1 and 3 years, depending on your country of purchase, for all parts including the light source and for all labour from the date of the first consumer purchase

### Who the warranty protects:

This warranty is valid only for the first consumer purchaser.

## What the warranty excludes and does not cover:

Any product on which the serial number has been defaced, modified or removed.

Damage, deterioration or malfunction resulting from:

- 1. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
- 2. Repair or attempted repair by anyone not authorized by ViewSonic.
- 3. Damage to or loss of any programs, data or removable storage media.
- 4. Software or data loss occurring during repair or replacement.
- 5. Any damage of the product due to shipment.
- 6. Removal or installation of the product.
- 7. Causes external to the product, such as electric power fluctuations or failure.
- 8. Use of supplies or parts not meeting ViewSonic's specifications.
- 9. Normal wear and tear.
- 10. Failure of owner to perform periodic product maintenance as stated in User Guide, such as cleaning of user-cleanable projector filters.
- 11. Any other cause which does not relate to a product defect.
- 12. Damage caused by static (non-moving) images displayed for lengthy periods of time (also referred to as image burn-in).
- 13. Software Any third-party software included with the product or installed by the customer.

- 14. Hardware/Accessories/Parts/Components Installation of any unauthorized hardware, accessories, consumable parts or components (e.g. Projector Lamps).
- 15. Damage to, or abuse of, the coating on the surface of the display through inappropriate cleaning as described in product User Guide.
- Removal, installation, and set-up service charges, including wallmounting of product.

### How to get service:

- 1. For information about receiving service under warranty, contact ViewSonic Customer Support (Please refer to Customer Support page). You will need to provide your product's serial number.
- To obtain warranty service, you will be required to provide (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
- 3. Take or ship the product freight prepaid in the original container to an authorized ViewSonic service center or ViewSonic.
- 4. For additional information or the name of the nearest ViewSonic service center, contact ViewSonic.

## **Limitation of implied warranties:**

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

## **Exclusion of damages:**

ViewSonic's liability is limited to the cost of repair or replacement of the product. ViewSonic shall not be liable for:

- Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
- 2. Any other damages, whether incidental, consequential or otherwise.
- 3. Any claim against the customer by any other party.
- 4. Repair or attempted repair by anyone not authorized by ViewSonic.

#### Effect of state law:

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow limitations on implied warranties and/or do not allow the exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

#### Sales outside the U.S.A. and Canada:

For warranty information and service on ViewSonic products sold outside of the U.S.A. and Canada, contact ViewSonic or your local ViewSonic dealer.

The warranty period for this product in mainland China (Hong Kong, Macao and Taiwan Excluded) is subject to the terms and conditions of the Maintenance Guarantee Card.

For users in Europe and Russia, full details of warranty provided can be found in www.viewsoniceurope.com under Support/Warranty Information

# **Mexico Limited Warranty**

## ViewSonic® Display

### What the warranty covers:

ViewSonic warrants its products to be free from defects in material and workmanship, under normal use, during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic will, at its sole option, repair or replace the product with a like product. Replacement product or parts may include remanufactured or refurbished parts or components & accessories.

### How long the warranty is effective:

ViewSonic LCD displays are warranted for between 1 and 3 years, depending on your country of purchase, for all parts including the light source and for all labour from the date of the first consumer purchase

## Who the warranty protects:

This warranty is valid only for the first consumer purchaser.

## What the warranty does not cover:

- Any product on which the serial number has been defaced, modified or removed.
- 2. Damage, deterioration or malfunction resulting from:
  - a. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, unauthorized attempted repair, or failure to follow instructions supplied with the product.
  - b. Causes external to the product, such as electrical power fluctuations or failure.
  - c. Use of supplies or parts not meeting ViewSonic's specifications.
  - d. Normal wear and tear.
  - e. Any other cause which does not relate to a product defect.
- 3. Any product exhibiting a condition commonly known as "image burn-in" which results when a static image is displayed on the product for an extended period of time.
- 4. Removal, installation, insurance, and set-up service charges.

### How to get service:

For information about receiving service under warranty, contact ViewSonic Customer Support (Please refer to the attached Customer Support page). You will need to provide your product's serial number, so please record the product information in the space provided below on your purchase for your future use. Please retain your receipt of proof of purchase to support your warranty claim.

For Your Records	
Product Name:	Model Number:
Document Number:	Serial Number:
Purchase Date:	_Extended Warranty Purchase?(Y/N)
If so, what date does warra	inty expire?

- To obtain warranty service, you will be required to provide (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
- 2. Take or ship the product in the original container packaging to an authorized ViewSonic service center.
- 3. Round trip transportation costs for in-warranty products will be paid by ViewSonic.

### **Limitation of implied warranties:**

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

### **Exclusion of damages:**

ViewSonic's liability is limited to the cost of repair or replacement of the product. ViewSonic shall not be liable for:

- Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
- 2. Any other damages, whether incidental, consequential or otherwise.
- 3. Any claim against the customer by any other party.
- 4. Repair or attempted repair by anyone not authorized by ViewSonic.

Contact Information for Sales & Authorized Service (Centro Autorizado de Servicio) within Mexico:			
Name, address, of manufacturer and importers:			
México, Av. de la Palma #8 Piso 2 Despacho 203, Corporativo Interpalmas,			
Col. San Fernando Huixquilucan, Estado de México			
Tel: (55) 3605-1099 http://www.viewsonic.com/la/soporte/index.htm			
NÚMERO GRATIS DE ASISTENCIA TÉCNICA PARA	TODO MÉXICO: 001.866.823.2004		
Hermosillo:	Villahermosa:		
Distribuciones y Servicios Computacionales SA de CV.	Compumantenimietnos Garantizados, S.A. de C.V.		
Calle Juarez 284 local 2	AV. GREGORIO MENDEZ #1504		
Col. Bugambilias C.P: 83140	COL, FLORIDA C.P. 86040		
Tel: 01-66-22-14-9005	Tel: 01 (993) 3 52 00 47 / 3522074 / 3 52 20 09		
E-Mail: disc2@hmo.megared.net.mx	E-Mail: compumantenimientos@prodigy.net.mx		
Puebla, Pue. (Matriz):	Veracruz, Ver.:		
RENTA Y DATOS, S.A. DE C.V. Domicilio:	CONEXION Y DESARROLLO, S.A DE C.V. Av.		
29 SUR 721 COL. LA PAZ	Americas # 419		
72160 PUEBLA, PUE.	ENTRE PINZÓN Y ALVARADO		
Tel: 01(52).222.891.55.77 CON 10 LINEAS	Fracc. Reforma C.P. 91919		
E-Mail: datos@puebla.megared.net.mx	Tel: 01-22-91-00-31-67		
	E-Mail: gacosta@gplus.com.mx		
Chihuahua	Cuernavaca		
Soluciones Globales en Computación	Compusupport de Cuernavaca SA de CV		
C. Magisterio # 3321 Col. Magisterial	Francisco Leyva # 178 Col. Miguel Hidalgo		
Chihuahua, Chih.	C.P. 62040, Cuernavaca Morelos		
Tel: 4136954	Tel: 01 777 3180579 / 01 777 3124014		
E-Mail: Cefeo@soluglobales.com	E-Mail: aquevedo@compusupportcva.com		
Distrito Federal:	Guadalajara, Jal.:		
QPLUS, S.A. de C.V.	SERVICRECE, S.A. de C.V.		
Av. Coyoacán 931	Av. Niños Héroes # 2281		
Col. Del Valle 03100, México, D.F.	Col. Arcos Sur, Sector Juárez		
Tel: 01(52)55-50-00-27-35	44170, Guadalajara, Jalisco		
E-Mail: gacosta@gplus.com.mx	Tel: 01(52)33-36-15-15-43		
- man i gareeta @4praereemini	E-Mail: mmiranda@servicrece.com		
Guerrero Acapulco	Monterrey:		
GS Computación (Grupo Sesicomp)	Global Product Services		
Progreso #6-A, Colo Centro	Mar Caribe # 1987, Esquina con Golfo Pérsico		
39300 Acapulco, Guerrero	Fracc. Bernardo Reyes, CP 64280		
Tel: 744-48-32627	Monterrey N.L. México		
	Tel: 8129-5103		
	E-Mail: aydeem@gps1.com.mx		
MERIDA:	Oaxaca, Oax.:		
ELECTROSER	CENTRO DE DISTRIBUCION Y		
Av Reforma No. 403Gx39 y 41	SERVICIO, S.A. de C.V.		
Mérida, Yucatán, México CP97000	Murguía # 708 P.A., Col. Centro, 68000, Oaxaca		
Tel: (52) 999-925-1916	Tel: 01(52)95-15-15-22-22		
E-Mail: rrrb@sureste.com	Fax: 01(52)95-15-13-67-00		
	E-Mail. gpotai2001@hotmail.com		
Tijuana:	FOR USA SUPPORT:		
ISTD	ViewSonic Corporation		
Av Ferrocarril Sonora #3780 L-C	381 Brea Canyon Road, Walnut, CA. 91789 USA		
Col 20 de Noviembre	Tel: 800-688-6688 (English); 866-323-8056 (Spanish);		
Tijuana, Mexico	E-Mail: http://www.viewsonic.com		
injustice, monitor			

LCD Mexico Warranty Term Template In UG

VSC\_TEMP\_2008

