



# Wireless Cube Bluetooth® Speakers

## Users Manual

Part No.	Description
70224	Wireless Cube Bluetooth® Speaker – Black
70225	Wireless Cube Bluetooth® Speaker – Red
70226	Wireless Cube Bluetooth® Speaker – Blue
70227	Wireless Cube Bluetooth® Speaker – White

- TWS Stereo Sound – pair two speakers together
- Powerful bass
- Built-in microphone for hands-free calling
- Convenient carrying strap
- microSD card slot for MP3 playback
- Compatible with most Bluetooth-enabled devices

### Package Includes

- Bluetooth® Speaker
- Charging Cable

Specifications	
Operating Time	About 5 Hours
Operational Range	Up to 33 Feet
Output Power	5W
Frequency Response	100Hz-20KHz
Sensitivity	85db ± 2db

### Pairing Instructions

#### Pairing Speaker to Smartphone

1. Turn on speaker. Make sure Blue LED on the back is flashing.
2. On your smartphone, under Bluetooth devices, search for “Verbatim Cube Speaker” and select to pair.
3. Repeat steps above if the initial pairing is unsuccessful.

#### Pairing Two Speakers

1. Turn on both speakers at the same time. Make sure Blue LED on the back of both speakers is flashing.
2. Double click the “+” button on one of the speakers. This speaker will become the main speaker.
3. On your smartphone, under Bluetooth devices, search for “Verbatim Cube Speaker” and select to pair.
4. Both speakers will now play music together.
5. Repeat steps above if the initial pairing is unsuccessful.

verbatim.com

Verbatim One Year Limited Warranty. See details at [verbatim.com/warranty](http://verbatim.com/warranty).

© Verbatim Americas LLC, 2019.