


# SOUNDFORM™ ELITE

## Set up Guide


1

Plug in SOUNDFORM™ ELITE  
& Download the Google Home App




2

Install SOUNDFORM™ ELITE through  
the Google Home App



Click "Next".  
Wait while it connects.  
You should hear a chime from your SOUNDFORM™ ELITE.  
Click "Next".  
Click "I agree" or "No thanks" to skip.  
Click "I'm Sure".  
Choose the video service you want to link, then click "Next" or skip by clicking "Not Now".  
Choose the Live TV service you want to link, then click "Next" or skip by clicking "Not Now".  
Click "No Thanks" to skip, or "Sign Up" to continue.



Open the Google Home app, your device should appear here. Click on "Set up 1 device".  
Select the "Home" you want this speaker. If you don't have any "Homes" select "Create a home".  
Once your "Home" is selected, it will show this screen.  
Click "Yes, I'm in" or "No thanks" to skip.  
Choose the room this speaker will be. This becomes the default name. Choose "office" here will name this speaker "Office Speaker" – we can change this later.  
Choose the WiFi network. Your mobile phone must be connected to the same WiFi network.  
Click "No Thanks" to skip, or "View More" to continue.  
Choose the music service you want to link, then click "Next" or skip by clicking "Not Now".  
Choose the radio service you want to link, then click "Next" or skip by clicking "Not Now".  
Click "Next".  
The speaker is temporarily named based on what Room you decided to place it "ROOM NAME Speaker".  
Scroll all the way down and click "Finish setup".




# SOUNDFORM™ ELITE

## Set up Guide



3


### Rename your SOUNDFORM™ ELITE (optional)



Go to Google Home main screen and select your speaker.

Click on the settings icon.

Click on Name.




Change the Name.

New name should appear in Device Settings.

New name should appear in Google Home main screen.

4


### Create a “Speaker Group” for multi-room audio



Go to Google Home main screen and click on the “+” sign.

Select “Create speaker group”.

All Google speakers on your Wifi network should appear here.



On Spotify, open a song you want to listen to, and click on “More Devices” icon.

Select your speaker group.

All speakers in your Speaker Group should now be playing together.

Select the devices you want to sync together.

Name the speaker group.

In the main Google Home page, your new Speaker group should appear.

### Optional Connect via Bluetooth only **after** setting up via Google Home app



Plug in SOUNDFORM™ ELITE, once it's turned on, press and hold the Bluetooth button for 3 sec. LEDs should turn white.

Go to your device's Bluetooth settings.

Select your SOUNDFORM™ speaker. The speaker should chime to indicate a successful connection.

### Optional Reset device

If the unit has been previously set up before with another account/wifi network and you want to clear it, there is a reset button at the bottom of the unit. However, it is possible to install the same speaker on different WiFi networks if it's with the same Google Home account (example if you move it from your home to office and set it up in both places, you don't need to reset it every time you move it between the 2 places).



Hold for 10 seconds.

4 color Google LEDs will appear.

When the LEDs are all white, it is ready for set-up.