




Installation Instructions






Adjusting Stand Height


**Press lever to adjust height up/down.



How to Cable Route


**Detatch the cable tray cover. Align cable to device and along the neck down to power surge. Replace the cable tray cover as shown.






Installing VESA Compatible Device

**Align 75x75 or 100x100 holes to compatible device or VESA compatible item. Screw in nails from behind as shown through the VESA plate into the device/item.



Adjusting Arm

**Using provided tool, loosen joint as shown to adjust arm. Rotate opposite direction to to tighten once arm is adjusted to preferred position.



**Caution Disclaimer - Please do not try to adjust any flexible feature when tightened or else product integrity will be in question. CTA will not be liable for any such user actions.



CTA DIGITAL
Brooklyn NY 11205
support@ctadigital.com