


Premium Floor Stand Kiosk with Graphic Slots & VESA Plate for Kitting (Black)


ADD-PARAFSV


INSTRUCTION - MANUAL

CONTENTS:



1. INSTALLING BASE:






2A. SLIDE OUT THE (2) GRAPHIC CARD PANELS IN THE FRONT AND BACK OF THE BODY (J). IF THERE IS A STICKER FILM, REMOVE THAT FIRST. IF YOU HAVE PRINTED OUT A STICKER GRAPHIC, PLACE IT ONTO THE PANEL. IF YOU ARE USING A COMPLETE NEW PANEL, YOU CAN REPLACE THE INITIAL PANELS THAT CAME WITH THE FLOOR STAND. PLACE ONE PANEL BACK FIRST, THEN THE OTHER.






3. SETTING UP CABLE ROUTING



3A. WITH ONLY (1) PANEL BACK IN, SLIDE IN THE POWER CORDS AND ANY OTHER CORDS THAT WOULD NEED TO BE CONNECTED TO THE TABLET THROUGH THE BODY AS SHOWN. THERE WILL BE GAPS AT THE TOP AND BOTTOM FOR THEM TO ROUTE OUT TO THE POWER SOURCE AND TO THE DEVICE. SLIDE IN SECOND PANEL WHEN ROUTING IS FINISHED.

5. ATTACH VESA PLATE



4. ALIGN VESA PLATE AND FRONT PLATE **COMPONENT AND WITH FLOOR STAND**

4A. ALIGN THE VESA PLATE BASE (B) WITH THE FRONT PLATE BASE (D) TO THE TOP OF THE FLOOR STAND (J). MAKE SURE ALL THE HOLES ARE ALIGNED AND READY FOR INSTALLATION.

