

Explorer[™] TV Cart User Guide



The Explorer[™] TV Cart





The Explorer[™] TV Cart with Handle and Directional Locks




About Your Product Technical Specifications

	Explorer™ TV Cart
Model	ETCM Explorer [™] TV Cart ETCMHD Explorer [™] TV Cart with Handle and Directional Locks
Outer Dimensions (W x D x H)	43" x 30" x 68" / 40.6cm x 41.3cm x 99.1 cm 66" x 30" x 68" / 40.6cm x 41.3cm x 99.1 cm
Display Sizes	Supports up to 86" displays
Mounting Pattern	Meets VESA standards 100 x 100mm to 400 x 400mm
Weight	98 lbs / 44.5kg 114 lbs/ 51.7kg
Warranty	For the latest information, please visit bretford.com/warranty.
Certifications	ETL Listed to UL Standard 1678



Getting started

Your Explorer TV Cart was designed to be flexible to fit your desired set up. First thing you want to decide is where to mount your display. There are two positions on the frame to choose from. Keep in mind to set the TV height below 84" to make it easy to move between rooms and through door frames. We recommend displays of 75" of bigger to be on the lower position.



The second decision is the tilt position. There are 3 settings to choose -0° , 5° or 10° degrees.





Features

The hole pattern in the middle of the frame is a flexible system for Explorer TV Cart accessories. Configure your set up to how you want it. Below are the available accessories. Visit Bretford.com for the latest offering.

Ergonomic Handle – allows for one person to easily move from room to room. Is height adjustable with access on both sides of the display.



Device Shelf – This fold up shelf is perfect for resting laptops, tablets, keyboards or even gaming systems on. It can be mounted on the back or in front of the cart. When not in use, it can fold up and stay within the footprint while moving the cart.



Features

6 Outlet Strip – Mount a 6 AC outlet electrical strip to the Explorer[™] TV Cart. Includes a 20 foot power cord and a cubby to store a TV remote, Apple TV or excess cable hidden from the front view.



Soundbar Mount – attach most soundbars to the cart with the universal mount. Fits keyhole slots or threaded slots that are 4.5" - 18" apart.



Directional Locks – Perfect for moving long distances and prevent drifting while pushing. The directional locks attach to swivel casters.



Safety Notice

▲ WARNING: For use with televisions weighing 200lbs (90.7kg) or less. Use with heavier televisions may result in instability causing tip over resulting in death or serious injury

WARNING: Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over on to the child.

WARNING: Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or overturning onto a child.

- Engage locking casters when product is not in transit.
- This cart is intended to be used with a flat panel monitor. Maximum load:
 - Flat Panel Monitor: 200 lbs.
 - Bottom Shelf: 50 lbs.
 - Device Shelf (optional): 25 lbs.



Technical support is available by contacting Bretford Customer Care via phone, email or the web:

Hours of Operation: M-F, 7:30am - 4:30pm CST

Telephone: +1-800-521-9614

Email: customerservice@bretford.com

Website: www.bretford.com/contact

Bretford and Explorer[™] TV Cart are trademarks or registered marks of Bretford Manufacturing, Inc. Patents pending. © 2022 Bretford Manufacturing, Inc. All rights reserved.

