JLAB | EPIC KEYBOARD

We love that you are rocking JLab!
We take pride in our products and fully stand behind them.

YOUR WARRANTY
All warranty claims are subject to JLab authorization and at our sole discretion. Retain your proof of purchase to ensure warranty coverage.

CONTACT US
Reach out to us at **support@jlab.com** or visit **jlab.com/contact**

REGISTER TODAY
jlab.com/register
Product updates | **How-to tips**
FAQs & more

1 CONNECT WITH DONGLE

Install 2.4G USB dongle and switch keyboard on
Epic Keys will auto connect

If connection is unsuccessful, press and hold 2.4 until button flashes quickly. Unplug and re-plug dongle into computer.



Have a JLab Epic or JBuds Mouse?
Scan the QR code to learn how to pair both your devices with just one dongle.

2 CONNECT WITH BLUETOOTH

Press and hold ᛒ1 or ᛒ2 for Bluetooth pairing
LED will blink in pairing mode

Press and hold CONNECT
Select “JLab Epic Keys” in device settings



3 KEYS



SHORTCUT KEYS

Fn +	MAC	PC	Android
Esc	FN Lock	FN Lock	FN Lock
F1	Brightness -	Brightness -	Brightness -
F2	Brightness +	Brightness +	Brightness +
F3	Task Control	Task Control	N/A
F4	Show Applications	Notification Center	N/A
F5	Search	Search	Search
F6	Backlit -	Backlit -	Backlit -
F7	Backlit +	Backlit +	Backlit +
F8	Track Back	Track Back	Track Back
F9	Track Forward	Track Forward	Track Forward
F10	Mute	Mute	Mute
F11	Screenshot	Screenshot	N/A
F12	N/A	Calculator	N/A



Customize the Epic Keys with USB dongle + JLab Work App
jlab.com/software

Shop products | **Product alerts** | **Burn-in your headphones**

JLab Store + Burn-in Tool

Download on the App Store

GET IT ON Google play