







Elo Technical Support

Online self-help:www.elotouch.com/support

America

800-ELO-TOUCH Tel +1 408 597 8000 EloSales.NA@elotouch.com

Europe(EMEA)

Tel +32 (0)16 930 136 EMEA.Sales@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo and the Elo logo are either trademarks or registered trademarks of Elo Touch Solutions, Inc.

Asia-Pacific

Tel +86 (21) 3329 1385 EloAsia@elotouch.com



Flo 3D Camera

Revision B P/N E551069











Installation

Please go to www.elotouch.com/support to verify you have the latest drivers before installing this device.


1



Select location to mount the 3D camera.

Elo recommends the top location in either portrait or landscape orientation.

3



Gently insert the 3D camera into the peripheral bay taking care to ensure the connector mates properly.

2



Remove the selected peripheral cover from the touchmonitor.

4



Install the 2 flat head screws included with the kit and cover the screws with the adhesive mylar covers if desired.