

**ORDERING GUIDE**

# HPE ARUBA NETWORKING 500R SERIES WI-FI 6 REMOTE ACCESS POINTS

Affordable Wi-Fi 6 (802.11ax) for low-to-medium-density indoor environments

1. SELECT A MODEL		
Part number	Description	Configuration comments
<b>HPE Aruba Networking 500R Series Wi-Fi 6 Remote Access Points</b>		
<b>R8N01A</b>	HPE Aruba Networking AP-503R-EG Dual Radio 2x2 Wi-Fi 6 1+2 Ethernet USB Remote Access Point	Includes AC power adapter & plug
	Localization options: #ABB	
<b>R8N02A</b>	HPE Aruba Networking AP-503R-IL Dual Radio 2x2 Wi-Fi 6 1+2 Ethernet USB Remote Access Point	Includes AC power adapter & plug
	Localization options: #ABB	
<b>R8N03A</b>	HPE Aruba Networking AP-503R-JP Dual Radio 2x2 Wi-Fi 6 1+2 Ethernet USB Remote Access Point	Includes AC power adapter & plug
	Localization options: #ABA	
<b>R8N04A</b>	HPE Aruba Networking AP-503R-RW Dual Radio 2x2 Wi-Fi 6 1+2 Ethernet USB Remote Access Point	Includes AC power adapter & plug
	Localization options: #ARM, #ABG, #AC4, #AKM, #ABB, #ACJ, #ABA, #AC6, #ACC	
<b>R8N05A</b>	HPE Aruba Networking AP-503R-US Dual Radio 2x2 Wi-Fi 6 1+2 Ethernet USB Remote Access Point	Includes AC power adapter & plug
	Localization options: #ABA	

**Localization options (affects AC power plug included with AP; primary country/region as shown):**

- #ARM → Argentina
- #ABG → Australia
- #AC4 → Brazil
- #AKM → China
- #ABB → Europe
- #ACJ → India
- #ABA → North America
- #AC6 → South Korea
- #ACC → UK



**2. ADD POWERING ACCESSORY (SPARE, OPTIONAL)**

Part number	Description	Configuration comments
<b>Power accessories</b>		
R9D91A	Aruba AP-AC18-12B 12V/18W AC/DC Wall-wart Style	Includes AC plugs for worldwide coverage
R3K00A	2.1/5.5mm Plug Worldwide Pwr Adapter	Add AC power cord (see below)
<b>AC power cord</b>		
JW113A	PC-AC-ARG (Argentina) 250V/10A 1.8m C13 to IRAM 2073 AC Power Cord	
JW114A	PC-AC-AUS (Australia) 250V/10A 1.8m C13 to AS3112 AC Power Cord	
JW115A	PC-AC-BR (Brazil) 250V/10A 1.8m C13 to NBR 14136 AC Power Cord	
JW116A	PC-AC-CHN (China) 250V/10A 1.8m C13 to GB2099 AC Power Cord	
JW117A	PC-AC-DEN (Denmark) 250V/10A 1.8m C13 to AFSNIT 107-2-D1 AC Power Cord	
JW118A	PC-AC-EC (Europe) 250V/10A 1.8m C13 to CEE7/7 AC Power Cord	
JW119A	PC-AC-IN (India) 250V/6A 1.8m C13 to IS1293 AC Power Cord	
JW120A	PC-AC-IL (Israel) 250V/10A 1.8m C13 to SI32 AC Power Cord	
JW121A	PC-AC-IT (Italy) 250V/10A 1.8m C13 to CEI 23-50 AC Power Cord	
JW122A	PC-AC-JPN (Japan) 125V/12A 1.8m C13 to JISC 8303 AC Power Cord	
JW123A	PC-AC-KOR (Korea) 250V/7A 1.8m C13 to KSC 8305 AC Power Cord	
JW124A	PC-AC-NA (North America) 125V/10A 1.8m C13 to NEMA 5-15P AC Power Cord	
JW125A	PC-AC-SWI (Switzerland) 220V/10A 1.8m C13 to SEV 1011 AC Power Cord	
S0P44A	PC-AC-TH (Thailand) 250V/10A 1.8m C13 to TIS 166-2549 AC Power Cord	
JW126A	PC-AC-TW (Taiwan) 125V/7A 1.8m C13 to CNS 10917 AC Power Cord	
JW127A	PC-AC-UK (United Kingdom) 250V/10A 1.8m C13 to BS1363 AC Power Cord	
JW128A	PC-AC-ZA (South Africa) 250V/10A 1.8m C13 to SANS 164-1 AC Power Cord	



3. ADD OTHER ACCESSORIES (OPTIONAL)		
Part number	Description	Configuration comments
<b>Console port adapters</b>		
JY728A	Aruba AP-CBL-SERU Micro-USB TTL3.3V to USB2.0 AP Console Adapter Cable	Drivers available on the Aruba Support Portal (ASP)
R6Q99A	Aruba AP-MOD-SERU Micro-USB TTL3.3V to RJ45 RS232 AP Console Adapter Module	
<b>BLE and Zigbee IOT dongle radio</b>		
R2X45A	Aruba AP-USB-ZB-1 Access Point BLE and Zigbee Radio USB Dongle	Single USB dongle
R2Y09A	Aruba AP-USB-ZB-10 10-Pack Access Point BLE and Zigbee Radio USB Dongle	10-pack USB dongle
R2Y10A	Aruba AP-USB-ZB-10 10-Pack Access Point BLE and Zigbee Radio USB Dongle	50-pack USB dongle
<b>USB Cellular radio dongle</b>		
R8F34A	Aruba USB LTE Modem for use with Access Points and Gateways	
R8G76A	Aruba USB Extender Cable Kit for use with Aruba USB LTE Modem	Optional extender cable kit for USB LTE Modem