




Sleek Rotating Desk Mount w/ Security Enclosure for 9-11" Tablets (Black/White)

PAD-RSDMB / PAD-RSDMW


INSTALLATION - MANUAL

CONTENTS:




INSTALLATION:

1.Assembling main body:




1A. Align base plate (C) to bottom of the body (B) and tighten screws (F) with provided tool (I) until securely tightened. Shown above.

2. Attaching enclosure:




2A. Align VESA holes of enclosure with pre-threaded VESA plate of Kiosk (B) and thread included screws (F) until securely tightened.

3. Swivel adjustability:



3A. Loosen the screws with provided tool (I) to turn 180° degrees to get desired view.

4. Optional - Placing blank sheet insert into enclosure:




4A. Lay-in correct masking insert from bundle (B) as needed the correct fitted look for your device.

4B. Close and lock enclosure afterwards and you're set.


5. Fixed setup:

No Anchors




5A. Place the kiosk on top of desired surface, then rotate included screws (E) until securely tightened.

With Anchors



5B. Insert the anchors into the surface's pre-drilled holes then place the kiosk in the desired location over the inserted anchors (H). Finally, secure the kiosk by threading the included screws (E). Shown above.

6. Adjustable angles:




6A. Tilt VESA head to desired angle view as shown.




6B. Device can be setup in Portrait or landscape modes.

7 Setting up security:




***Tablet shown for illustration only, NOT INCLUDED.*

7A. Once the tablet device is setup, close the front lid of the enclosure.



7B. Insert the key (K) in the keyhole on top of the enclosure, and turn clockwise to lock the enclosure in place.

8. Removing front rubber covers:



8A. Please remove the rubber cover if you want to use iPad 10th with front camera exposed