

Modern Series All-in-One PC

Modern AM273Q AI 1UM (MS-AF01) Modern AM273Q AI 1UMG (MS-AF01) Modern AM273QP AI 1UM (MS-AF01) Modern AM273QP AI 1UMG (MS-AF01)

User Guide

Contents

Getting Started	3
Package Contents	3
Safety & Comfort Tips	3
System Overview	4
Hardware Setup	13
OSD Setup	19
Component Replacement & Upgrade	23
Windows 11 System Operations	24
Power Management	24
Network Connections	
System Recovery	
F3 Hotkey Recovery (Optional)	
Troubleshooting	
Safety Instructions	41
TÜV Rheinland Certification	
ENERGY STAR Certification	43
Regulatory Notices	

Getting Started

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents

All-in-One PC	Modern AM273Q AI 1UM, Modern AM273Q AI 1UMG	Modern AM273QP AI 1UM, Modern AM273QP AI 1UMG		
	Quick Start Guide (optional)			
Documentation	User Guide (optional)			
Documentation	Warranty Book (optional)			
	Warranty Card (optional)			
	Stand	Stand with Screw(s)		
	Stand Screws	Stand Base with Screw(s)		
Accessories	Power Cord			
Accessories	External Power Supply			
	Mouse (optional)			
	Keyboard (optional)			

🕼 Important


- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country and model.
- The included power cord is exclusively for this personal computer and should not be used with other products.


Safety & Comfort Tips

- Choosing a good workspace is important if you have to work with your PC for a long period of time.
- Your work area should have enough illumination.
- Choose the proper desk and chair and adjust their height to fit your posture when operating.
- When sitting on the chair, sit straight and keep a good posture. Adjust the chair's back (if available) to support your back comfortably.
- Place you feet flat and naturally on the floor, so that your knees and elbows have the proper position (about 90-degree) when operating.
- Put your hands on the desk naturally to support your wrists.
- Avoid using your PC in a place where discomfort may occur (such as on the bed).
- The PC is an electrical device. Please treat it with great care to avoid personal injury.

System Overview


Front View






9	IR Webcam
	The IR Webcam supports infrared-based facial recognition for instant access to your computer.
0	Power Button
•	Press the power button to turn the system on and off.
3	Monitor LED
4	Hard Disk Drive LED
	This indicator shows the activity status of the HDD. It flashes when the system is accessing data on the HDD and remains off when no disk activity is detected.
ß	Power LED
	The power LED glows when the system is turned on and goes off when the system is shut down. In terms of power saving, the LED blinks in Modern Standby (S0 Low Power Idle) mode and goes off in S4 (Suspend to Disk) mode.


Rear View






	Navi Key				
V	The AIO PC comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.				
2	Power Jack				
•	Power supplied through this ja	ck supplies po	wer to your	system.	
	Important				
	We suggest that you connect the connect the AC power cord to a				
3					
	This input port comes with MSI Instant Display Technology. When you connect power to the AIO PC successfully, the monitor will automatically enter "standby" mode without pressing the power button. When devices are connected to the HDMI [™] port, the monitor will be turned on immediately. You can also switch the modes through the Monitor Power/ Mode Button on the side panel if you have already turned on your AIO PC. This technology helps to save more energy for your system.				
4					
	Supports 4K@60Hz as specified	d in HDMI™ 2.1			
	Important				
	• Available for the processor v	vith integrated	graphics.		
	• Graphics specifications may	vary depending	g on the ins	talled CPU.	
A	USB 5Gbps Port				
5	This connector is provided for	USB periphera	l devices. (Speed up to 5 Gbps)	
6	2.5 Gbps LAN Jack			•	
•	The standard RJ-45 LAN jack is provided for connection to the Local Area Network (LAN). You can connect a network cable to it.				
		LED	Status	Description	
		Link/	Off	No link	
		Activity LED	Yellow	Linked	
	LED		Blinking	Data activity	
			Off	10 Mbps	
		Speed LED	Green	100/1000 Mbps	
			Orange	2.5 Gbps	
7	Kensington Lock				

Side View






1	USB Type-C Port
	This port supports DisplayPort Alternate (DP Alt) Mode. It only carriies video signals and doesn't support data transmission function. This input port comes with MSI Instant Display Technology. When you connect power to the AIO PC successfully, the monitor will automatically enter "standby" mode without pressing the power button.
	Important
	Your USB-C signal source and cable must support DisplayPort Alternate Mode to enable video output to the monitor.
0	Card Reader
9	The built-in card reader supports various types of memory cards: SD/ MMC.
8	USB 5Gbps Port
	This connector is provided for USB peripheral devices. (Speed up to 5 Gbps)


4	Thunderbolt™ 4 USB-C Port
	 Support up to 40Gbps transfer rate with Thunderbolt[™] devices.
	• Support up to 5V/3A,15W power charging.
	 Each port can daisy-chain up to three Thunderbolt[™] 4 devices or five Thunderbolt[™] 3 devices.
	• Support up to 8K display.
5	Combo Audio Jack
	This connector is provided for headphones, speakers, or microphones.
6	2.5" HDD Bay


Top & Bottom View

Modern AM273Q AI 1UM, Modern AM273Q AI 1UMG



Modern AM273QP AI 1UM, Modern AM273QP AI 1UMG








Stereo Speakers

The built-in stereo speakers deliver high quality sound with stereo system.


Hardware Setup

Installing the AIO PC Stand

- 1. Take out the AIO PC from its protective packaging.
- 2. Align the stand to the monitor groove and tighten both stands with screws.
- **3.** Make sure the stand assembly is properly installed before setting the AIO PC upright.




- 1. Leave the AIO PC in its protective packaging. Align the stand bracket to the monitor groove.
- 2. Tighten the stand bracket with screws.
- 3. Connect the base to the stand and tighten the base screw to secure the base.
- **4.** Make sure the stand assembly is properly installed before setting the AIO PC upright.




Connecting the Power

Connect the adapter to the AIO PC and plug in the power cord. Press the power button to power on the AIO PC.

- External Power Supply 120W
 - Input: 100-240V~, 50-60Hz
 - Output: 19.5V === 6.15A








- The illustrations are for reference only. Your AIO PC may vary in appearance.
- Please make sure the AIO PC has been grounded to earth through the AC power cord and the electrical outlet before powering on the AIO PC.


Adjusting the Monitor

This AIO PC is designed to maximize your viewing comfort with its adjustment capabilities.

Modern AM273Q AI 1UM, Modern AM273Q AI 1UMG









- Do not use any sharp objects on the display panel.
- Avoid pressing the display panel when adjusting.


Connect Your Peripheral Devices to Suitable Ports

Important


- For detailed instructions on how to connect, please refer to the manuals of your peripheral devices.
- Reference image only. Appearance will vary.

Connecting Thunderbolt Devices via Daisy-chain (Optional)

Daisy-chain is a method of connecting multiple devices to a PC with only one output terminal. Daisy-chain allows you to connect multiple Thunderbolt devices to a single Thunderbolt port on the IO panel.



If you want to connect USB devices, please place them at the end of the chain.



OSD Setup


This chapter provides you with essential information on OSD Setup.

Important


All information is subject to change without prior notice.

Navi Key

The AIO comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



Modern AM273QP AI 1UM, Modern AM273QP AI 1UMG



Up/Down/Left/Right:

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus

Press (Menu):

- launching the On-Screen Display (OSD)
- entering submenus
- confirming a selection or setting

Hot Key

• Users may enter into Volume, Brightness, Mode and Input Source function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.

OSD Setup via Navi Key

Press the Middle button of Navi Key to launch the On-Screen Display (OSD) main menu. Use the Up, Down, Left, Right buttons to tune the desired function menus to suit your personal preferences. Press Menu 3 seconds to shut the panel off. Press Menu again to wake it up.

MSi	1920 x 1080	60 HZ	SRGB		PC	FW0.03a
	Mode	4	SRGB	Þ		
Image	Brightness		100			
	Contrast		100			
Ð	Sharpness	4	5	Þ		
Input Source	Eye Saver		OFF	•		
<u>بر</u> کې	Color Temperature		Normal			
کرے۔ Setting	Screen Size		16:9	•		
		(a)	()	(a).	
		Exit		Move	Er	ter

Image

1st Level Menu	2nd/ 3rd Level Menu	Description
Mode	User	• Default is User.
	Reader	While sRGB mode is selected, the color space will shaped to standard sPCP from
	Cinema	space will changed to standard sRGB from original panel gamut.
	Designer	
	sRGB	
Brightness	0-100	 Properly adjust Brightness according to the surrounding lighting.
		• Brightness will be grayed out in PC Mode.
Contrast	0-100	• Properly adjust Contrast to relax your eyes.
Sharpness	0-5	 Sharpness improves clarity and details of images.
Eye Saver	OFF	• Eye Saver has to be enabled in Reader
	ON	Mode.

1st Level Menu	2nd/ 3rd Level Menu		Description
Color Temperature	Cool		Use Up or Down Button to select and
	Normal	preview mode effects.	
	Warm		 Press the Menu Button to confirm and apply your mode type.
	Customization	R (0-100)	Color Temperature will be grayed out when POP mode is selected
		G (0-100)	sRGB mode is selected.
		B (0-100)	
Screen Size	Screen Size 4:3 16:9		• Default is 16:9. (AF82)

Input Source

1st Level Menu	Description
PC	User can use Navi Key, and OSD Menu to adjust the Input Source in any Mode.
Туре-С	
HDMI™	


Setting

1st Level Menu	2nd Level Menu	Description
Language	English	• Default is English.
	繁體中文	 Language is an independent setting. User's own language setting will override the factory default. When user sets
	简体中文	Reset to Yes, Language will not be changed.
	Italiano	
	Español	
	Français	
	Português	
	Deutsch	
	日本語	
	Русский	
Transparency	0-5	• Default is 0.
OSD Time Out	5-30	• Default is 20s.
Audio Volume	0-100	• Default is 50.
Reset	YES	 User can Reset the settings to original OSD default in any Mode.
	NO	אוטעצ.


Component Replacement & Upgrade

Please note that certain components preinstalled in the product may be upgradable or replaceable by user's request depending on the models users purchased.

Modern AM273Q AI 1UM, Modern AM273Q AI 1UMG



Modern AM273QP AI 1UM, Modern AM273QP AI 1UMG



For any further information on the product users purchased, please contact the local dealer. Do not attempt to upgrade or replace any component of the product if you are not an authorized dealer or service center, since it may cause the warranty void. It is strongly recommended that you contact the authorized dealer or service center for any upgrade or replace service.

Windows 11 System Operations



All information and Windows screenshots are subject to change without prior notice.

Power Management

Power management of personal computers (PCs) and monitors has the potential to save significant amounts of electricity as well as deliver environmental benefits.

To be energy efficient, turn off your display or set your PC to sleep mode after a period of user inactivity.

- 1. Right-click [Start] and select [Power Options] from the list.
- 2. Adjust [Screen and sleep] settings and select a power mode from the list.
- **3.** To choose or customize a power plan, type control panel in the search box and select [Control Panel].
- 4. Open up [All Control Panel Items] window. Select [Large icons] under [View by] drop-down menu.
- 5. Select [Power Options] to continue.
- 6. Select a power plan and fine-tune the settings by clicking [Change plan settings].
- 7. To create your own power plan, select (Create a power plan).
- 8. Select an existing plan and give it a new name.
- 9. Adjust settings for your new power plan.
- **10.**The [Shut down or sign out] menu also presents power saving options for rapid and easy management of your system power.

Energy Savings

The power management feature allows the computer to initiate a low-power or "Sleep" mode after a period of user inactivity. To take advantage of these potential energy savings, the power management feature has been preset to behave in the following ways when the system is operating on AC power:

- Turn off the display after 10 minutes
- Initiate Sleep after 30 minutes

Waking the System Up


The computer shall be able to wake up from power saving mode in response to a command from any of the following:

- the power button,
- the network (Wake On LAN),
- the mouse,
- the keyboard.




• Turn off the monitor by pressing the monitor power button after a period of user inactivity.

- Tune the settings in Power Options under Windows OS to optimize your PC's power management.
- Install power saving software to manage your PC's energy consumption.
- Always disconnect the AC power cord or switch the wall socket off if your PC would be left unused for a certain time to achieve zero energy consumption.



← Settings		- 🗆 ×
3 Shotmail.com	System > Power	
control panel × P	Screen and skeep	^
i .	When plugged in, turn off my screen after	10 minutes ~
 Bluetooth & devices Network & internet 	When plugged in, put my device to sleep after	30 minutes v
Personalization	Power mode Optimite your device based on power use and performance	Balanced v
Apps 📔		
Accounts	Get help	
3 Time & language	Give feedback	
Gaming		
* Accessibility		
Privacy & security		
Windows Update		



😵 Create a Power Plan			- 0	×
← → · ↑ 🍓 → Control Pan	N > All Control Panel Items > Power Options > Create a Power Plan	~ C	Search Control Panel	,ο
8	Create a power plan Stat with an exhibiting ylen and ylive it e name. Exhibition of the examination of the experiment of the energy consumption on capable hardware. Adventisely balance particimance with energy consumption on capable hardware. O how some Since energy by relationing your computer's performance where possible. O high performance, but may use more energy. Plan name: Mp Custom Pin 1			
	Next	Cancel		
😵 Edit Plan Settings			- 0	×
\leftarrow \rightarrow \checkmark \uparrow 论 \rightarrow Control Par	el > All Control Panel Items > Power Options > Edit Plan Settings	~ C	Search Control Panel	Q,
9	Change settings for the plan: My Custom Plan 1 Choose the skeep and display settings that you want your computer to use.			
	Turn off the display: 10 minutes Turn off the display: 30 minutes			

Create Cancel




Network Connections

Wi-Fi

- 1. Right-click [Start] and select [Network Connections] from the list.
- 2. Select and turn on [Wi-Fi].
- **3.** Select [Show available networks]. A list of available wireless networks pops up. Choose a connection from the list.
- 4. To establish a new connection, select [Manage known networks].
- 5. Select [Add network].
- **6.** Enter information for the wireless network you intend to add and click [Save] to establish a new connection.

Apps and Features	← Settings		- 🗆 X
Power Options Dewer Manager Network Connections	Ghotmal.com	Network & internet	
Disk Management	Find a setting	You aren't connected to any networks	Iroubleshoot
Computer Management	System	·	
Task Manager Settings	8 Bluetooth & devices 2	Wi-Fi Connect, manage known networks, metered network	On 💽
File Explorer	 Network & internet 		
Search	Personalization	Ethernet Authentication, IP and DNS settings, metered network	>
Run	🖬 Apps		
Shut down or sign out \rightarrow	💄 Accounts	UPN Add. connect, manage	>
Desktop	I ime & language	(m) Mubile hotspot	off (
📕 Q 📕	🥶 Gaming	Share your Internet connection	
	Accessibility Privacy & security	By Airplane mode Stop all wireless communication	< 💽 no
	 Privacy & security Windows Update 	Proxy Proxy Proxy server for Wi-Ti and Ethernet connections	>
		Pial-up Set up a dial-up internet connection	>
		Advanced network settings View all network adapters, network reset	>




← Settings		-		×
@hotmail.com	Network & internet > Wi-Fi			
Find a setting	帝 Wi-Fi 2	On		
System	戦 Show available networks		~	
Bluetooth & devices Network & internet	:= Manage known networks Add, remove, and edit networks		>	
Personalization Apps	Hardware properties Vew and manage W-H adapter properties		>	
 Accounts Iime & language 	Random hardware addresses Help protect your privacy by making it harder for people to track your device location.	Off	•	
Gaming	👰 Getheip			
Accessibility Privacy & security	Control = Co			
Windows Update				


← Settings		- 🗆 X
Chotmail.com	Network & internet > Wi-Fi > Mai	nage known networks
Find a setting P	Search known networks .0	Sort by: Preference $ \lor $ — Filter by: All $ \lor $
System	Add a new network	5 Add network
Bluetooth & devices	No known networks yet. Connect to a network then check back here.	
Network & internet Personalization	Get help	
Apps 4		
Accounts		
Iime & language		
🗐 Gaming		
★ Accessibility		
Privacy & security		
Windows Update		

← Setting	gs			- 🗆 ×
	Shotmail.com	Network & internet > Wi-Fi > Man	age known networks	
Find a set	tting P	Search known networks	Sort by: Preference $$	Filter by: All \smallsetminus
💻 Syste	tem	Add a ne		Add network
Blue	etooth & devices	No known		
I 🗢 Netv	work & internet	Add a new network		
🖌 Persi	sonalization	Get h Network name		
📑 App:	5	win		
💄 Acco	ounts	Security type		
🔊 lime	e & language	Open ~		
📾 Gam	ning			
🕇 Acce	essibility	Connect automatically Connect even if this network is not broadcasting		
Priva	racy & security	Connect even if this network is not broadcasting		
😏 Wind	dows Update			
		Save Cancel		

Ethernet

- 1. Right-click [Start] and select [Network Connections] from the list.
- 2. Select [Ethernet].
- The [IP assignment] and [DNS server assignment] are automatically set as [Automatic (DHCP)].
- 4. For a Static IP connection, click [Edit] of [IP assignment].
- 5. Select [Manual].
- 6. Switch on the [IPv4] or [IPv6].
- 7. Type the information from your Internet Service Provider and click [Save] to establish a Static IP connection.





← Settings		-	٥	×
	Network & internet > Ethernet			
Find a setting	Gal Frhemet 3 Net connected		^	
System	Authentication settings	Edit		
8 Bluetooth & devices	Metered connection Some apps might work differently to reduce data usage when you're connected to this network	Off 🖲		
🔷 Network & internet	Set a data limit to help control data usage on this network			
/ Personalization				
👪 Apps	IP assignt	Edit		
Accounts	Edit IP settings DNS serv Automatic (DHCP)	Edit		
Iime & language	Marta Manual	Carry		
📾 Gaming	Description	Сору		
1 Accessibility	Driver ver Physical = Save Cancel			
Privacy & security				
O Windows Update	Get help			
	Give feedback			


← :	Settings		-	۰	×
	Photmail.com	Network & internet > Ethernet			
Find	a setting P	Fthernet 3 Not connected		^	
-	System	Authentication settings	Edit		
0	Bluetooth & devices	Metered connection Some gaps minister work of filements to endure data users when we re gennected to this network	Off 🖲		
1 🕶	Network & internet				
1	Personalization	Children Settings			
	Apps	IP assign	Edit		
:	Accounts	DNS serv IPv4	Edit		
3	Time & language	Manufaci			
•	Gaming	Descripti IPv6 oller	Сору		
×	Accessibility	Driver ve Off Physical Off			
۲	Privacy & security				
6	Windows Update	Get help Save Cancel			
		Give feedbac			


← Settings		•		- 🗆 ×
Shotmail.com	Network a	Uternet > Ethernet		
Find a setting	C Ethernet Not conne	Edit IP settings Manual v		^
System	Authentic	IPv4		Edit
Bluetooth & devices	Metered Some appr	On On	connected to this network	Off
Vetwork & internet	Set a dati	IP address		
 Personalization Apps 	IP assigni			Edit
Accounts	DNS serv	Subnet mask		Edit
Time & language	Manufact	Gateway		Сору
 Gaming Accessibility 	Description Driver ver		oller	
Privacy & security	Physical t	Preferred DNS		
Windows Update	 Get help Give feedbact 	Preferred DNS encryption Unencrypted only ~		
		Alternate DNS		
			-	
		Save Cancel		

Dial-up

- 1. Right-click [Start] and select [Network Connections] from the list.
- 2. Select [Dial-up].
- 3. Select [Set up a new connection].
- 4. Choose [Connect to the Internet] and click [Next].
- Select [Broadband (PPPoE)] to connect using DSL or cable that requires a user name and password.
- **6.** Type the information from your Internet Service Provider (ISP) and click [Connect] to establish your LAN connection.

Apps and Features	← Settings		- 0	×
Power Options Manager	@hotmail.com	Network & internet		
Network Connections Disk Management	Find a setting P	You aren't connected to any networks	Iroubleshoot	
Computer Management	System			
Task Manager Settings	8 Bluetooth & devices	Wi-Fi Connect, manage known networks, metered network	On 💽 >	
File Explorer	Network & internet			
Search	Personalization	Lithernet Authentication, IP and UNIS settings, metered network	>	
Run	Apps			
Shut down or sign out	Accounts	VPN Add, connect, manage	>	
Desktop	I ime & language	(y) Mobile hotspot	Off (
📕 Q 📕	10 Gaming	Share your Internet connection	011 ()	
	* Accessibility	Airplane mode Stop all wireless communication	on 💽 >	
	Privacy & security			
	Windows Update	Proxy Proxy Proxy server for Wi-ti and Ethernet connections	>	
	2	Pial-up Set up a dial-up internet connection	>	
		R Advanced network settings View all network adapters, network reset	>	





System Recovery

The purposes for using the System Recovery Function may include:

- Restore the system back to the initial status of original manufacturer's default settings.
- When some errors have occurred to the operating system in use.
- When the operating system is affected by virus and is not able to work normally.
- When you want to install the OS with other built-in languages.


Before using the System Recovery Function, please back up the important data saved on your system drive to other storage devices.

If the following solution fails to recover your system, please contact the authorized local distributor or service center for further assistance.

Reset this PC

- 1. Right-click [Start] and select [Settings] from the list.
- 2. Select [Recovery] under [System].
- 3. Click [Reset PC] to start the system recovery.
- **4.** The [Choose an option] screen pops up. Choose between [Keep my files] and [Remove everything] and follow the on-screen instructions to complete your system recovery.

Apps and Features Power Options Event Viewer	Settings	System	-	٥	×
Device Manager Network Connections	Chotmail.com	Image: Sound Volume levels, output, input, sound devices		>	
Disk Management	System	Notifications Alerts from apps and system		>	
Settings File Explorer	 Bluetooth & devices Network & internet 	D Focus assist Notification, automatic rules		>	
Search Run	Personalization Apps	(1) Power Steep, battery usage, battery usage		>	
Shut down or sign out Desktop	 Accounts Time & language 	Storage Storage space, drives, configuration rules		>	
📕 Q 📕	 Gaming Accessibility 	Nearby sharing Discovershills, received files location Multitasking		>	
	 Privacy & security Windows Update 	Multitasking Snap windows, desktops, task switching Activation Activation		>	
		Activation state, subscriptions, product lay Iroubleshoot Recommended toubleshooten; preferences, history		, ,	
	2	Recovery Best, solanced startup, go back		>	
		Projecting to this PC Permissions, paring PIN, discoverability		>	
		Remote Desktop Remote Desktop users connection permissions		>	



	Reset this PC
	Additional settings Current settings: • Kestore apps and settings which came with this PC. <u>Charge settings</u>
Choose an option Keep my file Removes appa and settings, but keeps your personal files.	Learn more Back Next Cancel
Remove everything Removes all of your personal files, apps, and settings.	Additional settings
Help me choose Cance	Current setting: • Remove apps and files. Do not clean the drive • Delete all files only from Windows drive <u>Change setting:</u>
	Learn more Back Next Cancel

F3 Hotkey Recovery (Optional)

Precautions for Using the System Recovery Function

- 1. If your hard drive and system encountered non-recoverable problems, please use the F3 Hotkey recovery from the Hard Drive first to perform the System Recover Function.
- **2.** Before using the System Recovery Function, please back up the important data saved on your system drive to other storage devices.

Recovering the system with the F3 Hotkey

Follow the instructions below to continue:

- 1. Restart the PC.
- 2. Press the F3 hotkey on the keyboard promptly when the MSI greeting appears on the display.
- 3. On the [Choose an option] screen, select [Troubleshoot].
- **4.** On the [Troubleshoot] screen, select [Restore MSI factory settings] to reset the system to the default settings.
- 5. On the [RECOVERY SYSTEM] screen, select [System Partition Recovery].
- 6. Follow the on-screen instructions to continue and complete the Recovery Function.

Troubleshooting

My system does not start.

- Check if the system is connected to an electrical outlet and it is turned on.
- Check if the power cord and all cables are connected firmly.

When I turn on my computer, the message "Operating System not found" appears or Windows does not start.

- Check if there is a non-bootable CD/ DVD inside the optical disk drive. If so, remove the CD/ DVD then restart the computer.
- Check Boot Device Priority settings in the BIOS Setup.

The system can not be shut down.

It is best to shut down your computer using the Shut Down icon in the operating system. Using other methods, including those listed below, may result in data failure. If the Shut Down procedure does not work, choose one of the following steps:

- Press Ctrl+Alt+Del keys, then choose Shut Down.
- Press and hold the power button till the system is off.
- Unplug the power cable from the system.

My microphone does not work.

- For built-in microphone, please go to Start > Control Panel > Sounds and Audio Devices > Audio to check if it is muted.
- If you are using an external microphone, check that the microphone is plugged into the Microphone jack.

The Internet connection has problems.

- If you are having a problem connecting to your Internet Service Provider (ISP), check if the ISP is experiencing technical problems.
- Check the Network settings and connection and make sure the system is properly configured to Internet access.
- The wireless LAN data transfer speed is affected by distance and obstructions between devices and access points. To maximize the data transfer speed, choose the access point closest to your system.

System speakers do not work.

- Check the master volume setting in the Audio Mixer.
- If you are using an application that has its own volume control, check if the volume is muted.
- If you have connected an audio cable to the Headphone jack, disconnect it.
- If the system has OSD function, please adjust the volume of OSD.

System monitor does not display anything.

- Check if the system is connected to an electrical outlet and it is turned on.
- The system may be in Standby mode. Press any key to activate the Display.

Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always unplug the power cord before installing any add-on card or module to the device.
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

Battery

Please take special precautions if this device comes with a battery.

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.
- Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, which can result in an explosion.
- Avoid leaving a battery in an extremely high temperature or extremely low air pressure environment that can result in an explosion or the leakage of flammable liquid or gas.
- Do not ingest battery. If the coin/button cell battery is swallowed, it can cause severe internal burns and can lead to death. Keep new and used batteries away from children.

European Union:



Batteries, battery packs, and accumulators should not be disposed of as unsorted household waste. Please use the public collection system to return, recycle, or treat them in compliance with the local regulations.

BSMI:



廢電池請回收

For better environmental protection, waste batteries should be collected separately for recycling or special disposal.

California, USA:



The button cell battery may contain perchlorate material and requires special handling when recycled or disposed of in California. For further information please visit: https://dtsc.ca.gov/perchlorate/

Environment

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below 0°C, which may damage the device.
- The maximum operating temperature is around 35°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.
- If any of the following situations arises, get the device checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the device.
 - The device has been exposed to moisture.
 - The device does not work well or you can not get it working according to the User Guide.
 - The device has dropped and damaged.
 - The device has obvious sign of breakage.

TÜV Rheinland Certification

TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.

- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eve level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.

TÜV Rheinland Flicker Free Certification

- TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eves of users.
- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on

internationally applicable standards or standards common within the industry and exceeds these requirements.

- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 - 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by products.)

ENERGY STAR Certification

ENERGY STAR is a program run by the U.S. Environmental Protection Agency (EPA) and U.S. Department of Energy (DOE) to promote energy efficiency. This product qualifies for ENERGY STAR in the "factory default" settings through which power savings will be achieved. Changing the factory default picture settings or enabling other features will increase power consumption, which could exceed the limits necessary to qualify for ENERGY STAR rating.

For more information on ENERGY STAR, refer to https://www.energystar.gov/.





Low Blue Light (Hardware Solution)



Regulatory Notices

CE Conformity

Products bearing the CE marking comply with one or more of the following EU Directives as may be applicable:

CE

- RED 2014/53/EU
- Low Voltage Directive 2014/35/EU
- EMC Directive 2014/30/EU
- RoHS Directive 2011/65/EU
- ErP Directive 2009/125/EC

Compliance with these directives is assessed using applicable European Harmonized Standards.

The point of contact for regulatory matters is MSI-Europe: Eindhoven 5706 5692 ER Son.

Products with Radio Functionality (EMF)

This product incorporates a radio transmitting and receiving device. For computers in normal use, a separation distance of 20 cm ensures that radio frequency exposure levels comply with EU requirements. Products designed to be operated at closer proximities, such as tablet computers, comply with applicable EU requirements in typical operating positions. Products can be operated without maintaining a separation distance unless otherwise indicated in instructions specific to the product.

Restrictions for Products with Radio Functionality (select products only)



CAUTION: IEEE 802.11x wireless LAN with 5.15~5.35 GHz frequency band is restricted for indoor use only in all European Union member states, EFTA (Iceland, Norway, Liechtenstein), and most other European countries (e.g., Switzerland, Turkey, Republic of Serbia). Using this WLAN application outdoors might lead to interference issues with existing radio services.



Radio frequency bands and maximum power levels

- Features: Wi-Fi 6E/ Wi-Fi 7, BT
- Frequency Range:
 2.4 GHz: 2400~2485MHz
 5 GHz: 5150~5350MHz, 5470~5725MHz, 5725~5850MHz
 6 GHz: 5955~6415MHz
- Max Power Level:
 2.4 GHz: 20dBm
 5 GHz: 23dBm
 6 GHz: 23dBm

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy



and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- this device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA

(626) 913-0828

www.msi.com

WEEE Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

RoHS Statement

Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017, \mathbb{N}° 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

Vietnam RoHS

As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.

Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.
- Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.

Warning!

Overuse of screens is likely to affect eyesight.

Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

Upgrade and Warranty

Please note that certain components preinstalled in the product may be upgradable or replaceable by user's request. For any further information about the product users purchased, please contact the local dealer. Do not attempt to upgrade or replace any component of the product if you are not an authorized dealer or service center, since it may cause the warranty void. It is strongly recommended that you contact the authorized dealer or service center for any upgrade or replace service.

Acquisition of Replaceable Parts

Please be noticed that the acquisition of replaceable parts (or compatible ones) of the product users purchased in certain countries or territories may be fulfilled by the manufacturer within 5 years at most since the product has been discontinued, depending on the official regulations declared at the time. Please contact the manufacturer via https://www.msi.com/support/ for the detailed information about the acquisition of spare parts.



Copyright and Trademarks Notice

Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.

The terms HDMITM, HDMITM High-Definition Multimedia Interface, HDMITM Trade dress and the HDMITM Logos are trademarks or registered trademarks of HDMITM Licensing Administrator, Inc.

Technical Support

If a problem arises with your system and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please try the following help resources for further guidance. Visit the MSI website for technical guide, BIOS updates, driver updates and other information via https://www.msi.com/support/