




All-in-One Collaborative Touch Panel

Quick Start Guide



NovoTouch
BK Series



Vivitek America
Vivitek Service Center
14910 Summit Drive
EASTVALE, CA. 92880
U.S.A
Tel: 855-885-2378 (Toll-Free)
Email : T.services1@vivitekc corp.com

Vivitek Asia
7F, No. 186, Ruey Kuang Road, Neihu, Taipei 11491,
Taiwan R.O.C.
T: +886-2-8797-2088
F: +886-2-6600-2358

Vivitek Europe
Zandsteen 15, 2132 MZ Hoofddorp
The Netherlands
T: +31-20-800-3960
F: +31-20-655-0999



For more information, please visit
the NovoTouch support website.

www.vivitekc corp.com

A brand of DELTA

Package Contents


Display	Wi-Fi Antenna x 3	Stylus x 2

Remote Control	Batteries

HDMI Cable	Power Cable	USB Cable


Quick Start Guide	Wall Mount (Including Screws)

Display Overview (Front)



- | | | | | | |
|---|-------------------------|----|--------------------------------|----|--------------------|
| 1 | USB-C Port | 6 | Speakers | 11 | Volume Down Button |
| 2 | HDMI Port | 7 | IR Sensor (for Remote Control) | 12 | Volume Up Button |
| 3 | Touch (USB-B) Port | 8 | Home Button | 13 | Power Button |
| 4 | USB-A 3.0 Ports x 2 | 9 | Back Button | | |
| 5 | Magnetic Stylus Holders | 10 | Settings Button | | |


Display Overview (Rear)




- | | | | |
|---|------------------------|---|--------------------------|
| 1 | Handles | 4 | Power Switch |
| 2 | Wall Mount Screw Holes | 5 | Wi-Fi Antenna Connectors |
| 3 | Power Socket | 6 | 80-Pin OPS Slot |

Ports and Connectors

Left



Bottom



- 1

HDMI In Port 3 (with ARC)
- 2

HDMI In Port 2
- 3

HDMI In Port 1
- 4

Touch (USB-B) Port
- 5

USB 2.0 Port
- 6

USB 3.0 Ports x 2
- 7

RS-232 In Port
- 8

Microphone In Jack
- 9

Line Out Jack
- 10



SPDIF Port
- 11

HDMI Out Port
- 12


LAN Out Port
- 13

LAN In Port

Connections



Remote Control



- 1

Power
- 2

Input Source
- 3

Navigation Buttons
- 4

OK
- 5

Back
- 6

Volume Down
- 7


Home
- 8

Mute
- 9


Volume Up

Getting Started

Insert the Wi-Fi antennas onto the connectors, rotate them clockwise, and then turn the antennas inwards.



Plug the power cable into the display and a power source, turn the power switch on, and then press the power button.



Home Screen

