

OWNER'S MANUAL

LG Digital Signage

(MONITOR SIGNAGE)

Please read the user manual before using this product to ensure safe and convenient use

75UP5Q-E 86UP5Q-E

TABLE OF CONTENTS

BASIC	3
- Checking the Accessories	3
- Learning the Buttons	4
GETTING READY	5
- Connecting the IR Sensors	5
- Kensington Lock Device	6
CHECKING BEFORE	
INSTALLATION	7
- Installation Orientation	
- Installation Location	8
- Wall Mount Holder	9
PRECAUTIONS FOR USE	10
- Dust	
- Afterimage	10 10
Artermage	10
PRODUCT	
SPECIFICATIONS	12
LICENCE	17

WARNING - This product is not intended for household use.


BASIC



NOTE

- The accessories provided with your product may vary depending on the model or region.
- Product specifications or contents in this manual may be changed without prior notice due to upgrade of product functions.
- · SuperSign Software & Manual
 - Visit https://partner.lge.com to download the latest SuperSign software and manual.


Checking the Accessories



Depending upon country

Learning the Buttons

The illustrations may differ depending on the model.



- 1 When the monitor is turned on, press the () button one time.
- 2 You can use the function when you control menu.
- 3 All running apps will close.

Quick Menu




GETTING READY

Connecting the IR Sensors

Connecting the cable to the product allows it to receive signals from the remote control.

Rotate the IR sensor according to horizontal or vertical use.


- The illustrations may differ depending on the model.
- Remove the protective cable film before use.



Horizontal Use (Default Mount)

Vertical Use

You can hide the IR sensor.




Kensington Lock Device

(This feature applies only to some models.)

The Kensington lock device connector is located on the back of the monitor. For more information on installation and use, refer to the user manual provided with the locking device.

Connect the Kensington security system cable between the monitor and a table.





NOTE

- The Kensington lock device is an optional specification.
- This is a general illustration of installation and may look different from the product held by the customer.

CHECKING BEFORE INSTALLATION

We are not responsible for product damage caused by failure to follow the guide.

Installation Orientation

Using Vertically


When installing vertically, rotate the monitor 90 degrees anti-clockwise while facing the front of the screen.



Tilt Angle



Ceiling, Floor Orientation



Installation Location


We are not responsible for product damage caused by failure to follow the guide.

Indoor

Installing on a Wall

LSW640*

Ensure there is a clearance of at least 54.5 mm (2.1 inches) when using LG's wall mount






A:50 mm (1.9 inches) or more

- The warranty will not cover any damage caused by using the product in direct sunlight on the front panel.
- Leave sufficient space around the product so that the ventilation vents of the product are not blocked.

Installing on a Recessed Wall





A:50 mm (1.9 inches) or more

B:50 mm (1.9 inches) or more

C:70 mm (2.7 inches) or more

 The warranty will not cover any damage caused by using the product in direct sunlight on the front panel.

Outdoor

Outdoor Enclosed




Wall Mount Holder

To install the monitor on a wall, attach a wall mount holder (optional) to the back of the monitor.

Take caution, and ensure that the wall mount holder (optional) is securely fixed to the monitor and to the wall.

The VESA dimensions of the wall mount by model are as follows.





CAUTION

- Disconnect the power cord first, and then move or install the monitor. Otherwise, it may result in electric shock.
- If the monitor is installed on a ceiling or inclined wall, it may fall and result in injury.
- Damage to the monitor by tightening the screws too tightly may void your warranty.
- Use screws and wall mount plates conforming to VESA standards. Breakage or personal injury due to use or misuse of inappropriate components is not covered by the warranty of this product.



NOTE

- Using screws longer than the indicated depth may damage the inside of the product. Be sure to use the proper length.
- · For more information on installation, please refer to the user manual for the wall mount.

PRECAUTIONS FOR USE

Dust


The warranty will not cover any damage caused by using the product in an excessively dusty environment.

Afterimage

- · After-image appears when the product is turned off.
- Pixels may be damaged rapidly if a still image is displayed on the screen for a long period of time. Use the screen-saver function.
- Switching from a screen with high differences in luminance (black and white or grey) to a darker screen may cause an afterimage. This is normal due to the display characteristics of this product.
- When the LCD screen is in a still pattern for extended periods of use, a slight voltage difference may
 occur between the electrodes that operate the liquid crystal (LC). The voltage difference between the
 electrodes increases over time and tends to keep the liquid crystal aligned in one direction. At this time,
 the previous image remains, which is called an afterimage.
- Afterimages do not occur when continuously changing images are used but take place when a certain screen is fixed for a long time. The following are operational recommendations for reducing the occurrence of afterimages when using a fixed screen. The maximum recommended time for switching the screen is 12 hours. Shorter cycles are better for preventing afterimages.

- Recommended Usage Condition
 - 1 Change the background color and text color at equal intervals.
 - Afterimages occur less when the colors to be changed are complementary to one another.





ITO or MoTi Pixel Layer

- 2 Switch the screen at equal time intervals.
- Take caution, and ensure that text or images from before the screen change are not left in the same location after the screen change.



PRODUCT SPECIFICATIONS

Without prior notice, all product information and specifications contained in this manual are subject to change to improve the performance of the product.

Input/Output Ports	LAN IN, HDMI™ IN 1, HDMI™ IN 2, HDMI™ IN 3, DP IN, RS-232C IN, IR&LIGHT SENSOR, USB 2.0 IN, USB 3.0 IN, RS-232C OUT, AUDIO OUT		
Resolution	Recommended Resolution Max Resolution	olution - This may not be supported on some OS or graphics	
Embedded battery	Applied		
Environmental Conditions	Operating Temperature Operating Humidity Storage Temperature Storage Humidity	0 °C to 40 °C (32 °F to 104 °F) 10 % to 80 % (Condition for preventing condensation) -20 °C to 60 °C (-4 °F to 140 °F) 5 % to 85 % (Condition for preventing condensation) * Product box packaging storage conditions	

75UP5Q-E

Power Voltage		100-240 V~ 50/60 Hz 2.5 A
Size (Width x Height x Depth) / Weight	Without packing	1679.5 mm x 958.7 mm x 29.7 mm / 35.7 kg (66.1 inches x 37.7 inches x 1.1 inches / 78.7 lbs)
	With packing	1820 mm x 1115 mm x 200 mm / 44 kg (71.6 inches x 43.8 inches x 7.8 inches / 97 lbs)

86UP5Q-E

Power Voltage		100-240 V~ 50/60 Hz 3.0 A
Size (Width x Height x Depth) / Weight	Without packing	1928.8 mm x 1099.8 mm x 29.7 mm / 53 kg (75.9 inches x 43.2 inches x 1.1 inches / 116.8 lbs)
	With packing	2100 mm x 1250 mm x 253 mm / 66.7 kg (82.6 inches x 49.2 inches x 9.9 inches / 147 lbs)

HDMI / DisplayPort (Normal Mode)

Resolution	Horizontal frequency (kHz)	Vertical frequency (Hz)	Remark
800 x 600	37.879	60.317	
1024 x 768	48.363	60	
1280 x 720	44.772	59.855	
1280 x 1024	63.981	60.02	HDMI1/2/3, DisplayPort
1920 x 1080	67.5	60	
3840 x 2160	67.5	30	
3840 x 2160	135	60	

HDMI / DisplayPort (Video Mode)

Resolution	Horizontal frequency (kHz)	Vertical frequency (Hz)	Remark
480/60p	31.5	60	
576/50p	31,25	50	
720/50p	37.5	50	
720/60p	45	60	
1080/50i	28.1	50	
1080/60i	33.75	60	HDMI1/2/3, DisplayPort
1080/50p	56.25	50	
1080/60p	67.432	59.94	
1080/60p	67.5	60	
2160/30p	67.5	30	
2160/50p	112.5	50	
2160/60p	135	60	



- Horizontal frequency: The horizontal interval is the time taken to display one horizontal line. When
 1 is divided by the horizontal interval, the number of horizontal lines displayed every second can be
 tabulated as the horizontal frequency. The unit is kHz.
- Vertical frequency: The product display functions by the screen image changing dozens of times every second like a fluorescent lamp. The vertical frequency or refresh rate is the number of image displays per second. The unit is Hz.

Wireless module (LGSBWAX12) Specifications		
Wireless LAN (IEEE 802.11a/b/g/n/ac/ax)		
Frequency range (MHz)	Output power (Max.) (dBm)	
2400 to 2472	17	
5150 to 5725	15	
5725 to 5850	15	
5945 to 7125	11	

Bluetooth		
Frequency range (MHz)	Output power (Max.) (dBm)	
2400 to 2483.5	9	

- As band channels can vary per country, the user cannot change or adjust the operating frequency. This
 product is configured for the regional frequency table.
- For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm (7.8 inches) between the device and the body.
- 1) FCC regulations restrict the operation of this device to indoor use only.
- 2) Operation prohibited on all platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet.
- FCC ID: BEJLGSBWAX12 / IC: 2703H-LGSBWAX12

LICENCE

Supported licenses may differ by model. For more information of the licenses, visit www.lg.com.



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Vision, Dolby Vision IQ, Dolby Audio, Dolby Atmos, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by LG Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.





Supplier's Declaration of Conformity

Trade Name LG

Address 111 Sylvan Avenue, North

Building, Englewood Cliffs, NJ 07632

E-mail lg.environmental@lge.com

The model and serial number of the product are located on the back and on one side of the product. Record them below in case you ever need service.



This product qualifies for ENERGY STAR®.

Changing the factory default configuration and settings or enabling certain optional features and functionalities may increase energy consumption beyond the limits required for ENERGY STAR® certification.

Refer to ENERGYSTAR.gov for more information on the ENERGY STAR® program.

MODEL

SERIAL NO.

Temporary noise is normal when powering ON or OFF this device.