

Product information**A:** Speakers**B:** Indicator**C:** On/off**D:** Volume low**E:** Volume high**F:** MP3-in**G:** Audio-in**H:** Power-in**I:** Battery compartment**J:** Power adapter**K:** Audio cable**L:** Double side mini plug**M:** iPod holder**N:** Mini iPod holder**UK****Installation**

- 1 Connect PC or MP3 player to either 'MP3-in' or 'Audio-in', using audio cable or mini plug.

 If both inputs simultaneously connected: MP3 input has preference.

- 2 1) Connect power adapter to mains and to power-in.

OR

2) Place batteries in compartment.

Use

- 3 1) Press ON.

2) Indicator lights up. Product is ready to use.

Note**Use**

- Control volume using buttons D and E. If no sound during first use: Press E until you hear sound.
- Volume will return to factory settings when turned off.

**Safety instructions**

- Never open or repair the device.
- Never use the device in a damp environment. Clean the device with a dry cloth.

Go to www.trust.com/14578 (EU model) or www.trust.com/14579 (UK model) for up-to-date FAQs and instruction manuals.



- This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14578/ce.



- If possible, dispose of the device at a recycling centre. Do not dispose of the device with the household waste.

Warranty & copyright

- This device has a two-year product warranty which is valid from the date of purchase. See www.trust.com/warranty for more information.
- It is forbidden to reproduce any part of this instruction manual without the permission of Trust International B.V.