


## Product information





- A: Left button
- B: Right button
- C: Scroll-wheel and third button
- D: Battery compartment cover
- E: Connect button
- F: On/Off switch
- G: Motion sensor

## Installation



Insert batteries





Switch on The motion sensor (G) will be lit \* My Bluetooth Places
File Edit View Bluetooth Favorites



3



Press connect button (E)

Device will be in discoverable mode

Follow the instructions of your Bluetooth dongle to connect the mouse to your system.

# For example, when use with Trust Bluetooth dongle (software version 1.4.3.4 or higher)

⚠ Use current system mouse to make the Bluetooth connection

1

2



Double click this icon on the desktop

Address My Bluetooth Places

Bluetooth Tasks

Bluetooth Setup Wizard

View My Bluetooth services

Wew devices in range

Shows Bluetooth devices that currently can be accessed.

Click to View the device in range

3



Trust Bluetooth Mouse is found



Right click on the mouse and choose to **Connect Device** 

Click Yes

6



Mouse is ready to use

## Reminders

))) Less wireless performance Batteries (almost) empty Another wireless device is close by Max. 10 m



# General usage

⚠ It is necessary to connect the device again if you press the connect button (E)

It is not necessary to connect the device again when switch on/off the system or the mouse.

Wake up from sleep mode depends on the support of the Bluetooth dongle. Please contact the manufacturer of the Bluetooth dongle for a firmware update if it's needed.

If this mouse does not response after waking up from standby to restart the system can resolve it

If you have any problems, go to www.trust.com/14231 for FAQ, drivers and manuals.

Trust also provides Bluetooth dongle in our product range:

- 13853 Trust BT180 Class 1 USB Bluetooth Adapter

Trust also provides rechargeable batteries with battery chargers in our product range:

- 13596 Trust 220BS Battery Charger
- 14023 Trust 223BS Battery Charger
- 13957 Trust 410BQ Compact Quick Battery Charger
- 13595 Trust 420BQ Quick Battery Charger
- 13955 Trust 430BQ Quick Battery Charger
- 13881 Trust 440PQ Portable Quick Battery Charger



### Safety

- Do not open or repair this device.
- . Keep this device away from liquids, such as water.
- The alkaline batteries supplied with the product are not rechargeable. Do not attempt to recharge these batteries. There is a danger of them exploding.
- · Never throw the batteries onto an open fire. The batteries may explode.
- · Never drill holes into the batteries.
- Keep the batteries out of the reach of small children.
- Use only alkaline or rechargeable NiMH batteries with this product.
- . When the batteries are empty, ask your local authority where you can dispose of them.

Note: Do not use old and new batteries at the same time, because the old batteries may deplete the new

# **(€ 0470 ①**

 This device meets the essential requirements and other relevant conditions of the applicable European directives. The Declaration of Conformity (DoC) is available at www.trust.com/14231/ce

#### Wireless

- This wireless device works at a frequency of 2.4GHz. It meets the essential requirements and other relevant
  conditions of R&TTE Directive 1999/5/EC and can be used in EU countries plus: RU/NO/TR/HU. There are
  no limitations per channel for the above-mentioned countries. Go to www.trust.com/14231 for an updated list
  of the countries where the use of this device is permitted.
- There may be restrictions for the use of this device outside of the EU. If this device is used outside of the EU, check whether this device meets local regulations. Frequency: 2400~2483MHz, Bandwidth: +/-1 MHz, Power: 1mW.
- Nowadays, there are an increasing number of wireless products (video, audio, computer, etc.) which work in
  the same frequency range as this device. It may, therefore, be possible that the functionality of this product is
  limited by or is limiting for other wireless products. This can only be avoided by paying attention to the
  distance between products and, where possible, by chanqing channels.
- Be careful when using wireless devices if you have a pacemaker or are dependent on other life-saving, sensitive electronic equipment, because this product transmits radio signals.

#### Warranty & copyright

- This product has a two-year manufacturer's warranty which is effective from the date of purchase. For more
  information see <a href="https://www.trust.com/warranty">www.trust.com/warranty</a>
- Reproduction of this manual or any part of it is prohibited without permission from Trust International B.V.