

To install the shoulder strap to A140:

NOTE: If you are also installing the rotatable hand strap, install the hand strap first before installing this shoulder strap.

1. The shoulder strap includes a long strap and two short straps at both ends. For the installation, you need to temporarily detach the short straps. Open the snap buttons to detach the short strap.
2. Using the supplied wire as a tool, pull the loop of the short strap through the holder at one corner of A140 (as indicated by ❶). Then, insert the strap through the loop (as indicated by ❷) and pull it tight.
3. Insert the short strap through the bracket of the long strap and button up the short strap. Make sure that the two buttons click into place.



4. Follow the same procedure to secure the strap to the other side of A140.
5. You can adjust the strap length using the slide adjusters.



NOTE: If you want to detach the shoulder strap from A140, simply unbutton the short straps to release the long strap. The red line on the short strap helps you quickly locate where to unbutton.



5 6 1 8 1 4 0 1 0 0 0 3 R 0 2