

Introduction

This hand strap provides three functions for A140: rotatable hand grip, kickstand, and pen holder.

Installation

NOTE: If you are also installing the shoulder strap, install this hand strap first before installing the shoulder strap.

1. Align the hand strap with A140 so that the Getac logo is in the upright position and the four belts point to the four corners of A140.

Insert each belt to the corresponding corner holder of A140. Make sure the hand strap is positioned at the center.



2. To fasten each belt:

Fold the belt over and insert it through the slide adjuster, going from underneath the inner side of the adjuster (❶).

Fold the belt over, insert it through the outer side of the slide adjuster, and pull it tight (❷).



3. If the hand strap is not centered, adjust the belts until it is.

Applications

Hand Grip

Insert your fingers through the hand grip to hold A140.



This imprint indicates the surface on which you put your hand.

The hand grip is rotatable. The tightness can be adjusted.

Kickstand

1. Rotate the hand grip sideways as shown below.
2. Pull apart to open the hook-and-loop fastener.



3. Extend the hand grip to form a triangle.



NOTE: When closing the hand grip, be sure to fold up the flexible band properly. Keep the folded band inside the hand grip in a flat and smooth condition.

See reverse side for more information.

Pen Holder

Use the pen holder to store the stylus.



5 6 1 5 1 4 0 1 0 0 0 5 R 0 0