Canon

Online Manual

PosterArtist Guide

Contents

Symbols Used in This Document	7
Trademarks	8
Licenses	9
Cautions, Limitations, and Restrictions (PosterArtist)	35
License Authentication	40
What Is PosterArtist?	46
What You Can Do with PosterArtist. Starting PosterArtist.	
Creating and Printing Posters	54
Creating and Printing Enlarged Copies of Photos and Documents	56
PosterArtist QuickCopy Screen	59
Various Functions for Creating Posters	63
Templates	64
Selecting Templates	65
Displaying All Templates	
Searching Templates	67
Using Existing Posters	68
Downloading Templates	69
Performing a Design Check	70
Freely Designing	71
Using Auto Design	72
Adjusting Designs	75
Specifying Size and Paper	77
When Printing on Roll Paper	78
When Printing on Cut Sheets.	85
When Printing to Scale.	87
When Printing Entire Poster Within Printable Area.	89
Adding Crop Marks	91
Specifying Non-Standard Page Sizes	92
Inserting Images and Materials	93
Inserting Images in Posters.	94
Adding QR Codes	97

Editing Photos	98
Adding, Replacing and Removing Photos	99
Using Temporary Tray when Editing Photos	101
Trimming Photos.	103
Applying Gradation to Photos	105
Applying Transparency to Photos (Opacity).	107
Correcting Slant.	108
Applying Frames to Photos	110
Editing Clipart.	111
Adding, Replacing and Removing Clipart	112
Using Temporary Tray when Editing Clipart	113
Changing Clipart Colors.	115
Retouching Images.	116
Auto Color Correction.	117
Color Adjustment.	118
Color Point Correction.	119
Backlight Correction	120
Sharpness	121
Soft Focus.	122
Monochrome/Sepia	123
Logo Color Adjustment.	124
Cut Out.	125
Editing Shapes	127
Adding and Removing Shapes	128
Changing Shape Styles	130
Editing Text.	136
Adding, Changing, and Removing Text	137
Changing the Text Format.	139
Applying Text Graphics.	147
Editing Backgrounds.	148
Adding Backgrounds	149
Setting Background Image	150
Specifying Background Margins	151
Working with Objects	152

Selecting Objects		153
Cutting, Copying, and Pas	sting Objects	154
Moving, Enlarging, Reduc	ing, and Rotating Objects	155
Specifying Size, Position,	or Orientation Numerically	160
Locking Object Positions.		162
Aligning Objects		164
Making Multiple Objects th	ne Same Size	167
Grouping Objects		168
Reordering Objects		169
Printing Posters		170
Printing Posters		171
Test Printing		172
Ambient Light Setting		173
Saving		180
Saving in a PosterArtist Fi	le Format	181
Saving in JPEG Format		182
Using Variable Printing		183
Preparing Data		184
Starting Variable Printing.		186
Managing Artwork		189
Adding Artwork to Library.		190
Importing and Exporting		192
Organizing Artwork in Libr	ary	196
Downloading Artwork at O	Once	199
Preparing the Same Artwo	ork Environment on Other Computers	200
Using Cloud		201
Downloading Posters and	Materials from Cloud	202
Uploading Current Poster	to Cloud	204
Uploading Export Files to	Cloud	206
Using Translation Templates		209
Exporting Posters for Use in Ea	asy-PhotoPrint Editor	211
Creating Vivid Posters Using Fl	luorescent Colors	212
Making the Entire Poster N	More Vibrant (Vivid mode)	213
Making Colors of Specific	Areas Vivid (Spot mode)	214
Specifying Fluoresce	nt Colors for Specified Areas	216

Pos	terArtist Screens	219
	Main Screen	221
	Select Template Screen	224
	Auto Design Screen	226
	View All Templates Dialog Box	230
	Find Template Dialog Box	231
	Saving Artwork Dialog Box (Templates)	232
	Design Assist Dialog Box	234
	Paper Options Screen	235
	Set Custom Size Dialog Box	238
	Edit Screen (Photos)	240
	Edit Screen (Clipart)	243
	Edit Screen (Text).	245
	Edit Screen (Shapes)	248
	Edit Screen (Backgrounds).	252
	Edit Screen (Variable Data)	254
	Saving Artwork Dialog Box (Images).	256
	Cut Out Dialog Box	258
	Fill Dialog Box	262
	Edit Image Dialog Box (Trim).	265
	Edit Image Dialog Box (Gradation)	268
	Edit Image Dialog Box (Slant Correction).	271
	Retouch Image Dialog Box	273
	Color Adjustment Dialog Box	275
	Color Point Correction Dialog Box	277
	Backlight Correction Dialog Box	279
	Sharpness Dialog Box	281
	Soft Focus Dialog Box	282
	Logo Color Adjustment Dialog Box	283
	Fill and Stroke Dialog Box	285
	Set Shaded Text Dialog Box	287
	Set Shadow Dialog Box	289
	Print Screen.	291
	Ambient Light Setting Dialog Box	293
	Managing Ambient Light Settings Dialog Box	296
	Export Dialog Box	298
	Set Grid and Guide Dialog Box	300

	Preferences Dialog Box	30	1
	Properties Dialog Box	30	3
	Customize Toolbar Dialog Box	30	6
	Artwork Manager Dialog Box	30	7
	Align and Distribute Objects Dialog Box	31	0
	Guide Position Dialog Box	31	3
	QR code Dialog Box.	31	4
Cor	mmands	31	5
FAC	Q	33	1

Symbols Used in This Document

Marning

Instructions that, if ignored, could result in death, serious personal injury, or property damage caused by incorrect operation of the equipment. These must be observed for safe operation.

⚠ Caution

Instructions that, if ignored, could result in personal injury or property damage caused by incorrect operation of the equipment. These must be observed for safe operation.

>>>> Important

Instructions including important information that must be observed to avoid damage and injury or improper use of the product. Be sure to read these instructions.

Note

Instructions including notes for operation and additional explanations.

WBasics

Instructions explaining basic operations of your product.

Note

· Icons may vary depending on your product.

Trademarks

Microsoft, Excel, Internet Explorer, Microsoft Edge, Microsoft Store, OneDrive, PowerPoint, Windows and Windows Vista are trademarks of the Microsoft group of companies.

Mac, Mac OS, macOS, OS X, AirPort, App Store, AirPrint, the AirPrint logo, Safari, Bonjour, iPad, iPad Air, iPad mini, iPadOS, iPhone and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

The Mopria® word mark and the Mopria® Logo are registered and/or unregistered trademarks of Mopria Alliance, Inc. in the United States and other countries. Unauthorized use is strictly prohibited.

IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Google Cloud Print, Google Chrome, Chrome OS, Chromebook, Android, Google Drive, Google Apps and Google Analytics are either registered trademarks or trademarks of Google LLC.

Google Play and Google Play Logo are trademarks of Google LLC.

Adobe, Acrobat, Flash, Photoshop, Illustrator, Adobe RGB and Adobe RGB (1998) are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries. Adobe, Acrobat, Flash, Photoshop, Photoshop Elements, Lightroom, Adobe RGB and Adobe RGB (1998) are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

USB Type-C™ is a trademark of USB Implementers Forum.

Amazon, Echo and Alexa are trademarks of Amazon.com, Inc. or its affiliates.

Google, Google Home, and YouTube are trademarks of Google LLC.

LINE is a registered trademark or trademark of LY Corporation.

LINE Clova is a registered trademark of LY Corporation.

Google Docs, and Google Drive are trademarks of Google LLC.

App Store is a trademark of Apple Inc., registered in the U.S. and other countries.

AOSS™ is a trademark of BUFFALO INC.

Autodesk and AutoCAD are registered trademarks or trademarks of Autodesk, Inc., and/or its subsidiaries and/or affiliates in the USA and/or other countries.

QR Code is a registered trademark of DENSO WAVE INCORPORATED in Japan and in other countries.

HP-GL and HP-GL/2 are either registered trademarks or trademarks of HP Inc. in the United States and/or other countries.

Mozilla Firefox is a trademark or registered trademark of Mozilla Foundation in the U.S. and/or other countries.

Wi-Fi, WPA, WPA2 and WPA3 are either registered trademarks or trademarks of Wi-Fi Alliance.

All other company names and products mentioned in this guide may be registered trademarks or trademarks of their respective companies.

Licenses

Copyright (c) 2003-2015 Apple Inc. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name of Apple Inc. ("Apple") nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY APPLE AND ITS CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL APPLE OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Apache License

Version 2.0, January 2004

http://www.apache.org/licenses/

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

- 2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.
- 3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.
- 4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
 - 1. You must give any other recipients of the Work or Derivative Works a copy of this License; and
 - 2. You must cause any modified files to carry prominent notices stating that You changed the files; and

- 3. You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
- 4. If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

- 5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
- 6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.
- 7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
- 8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.
- 9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any

such warranty or additional liability. END OF TERMS AND CONDITIONS

---- Part 1: CMU/UCD copyright notice: (BSD like) -----

Copyright 1989, 1991, 1992 by Carnegie Mellon University

Derivative Work - 1996, 1998-2000

Copyright 1996, 1998-2000 The Regents of the University of California

All Rights Reserved

Permission to use, copy, modify and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appears in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the name of CMU and The Regents of the University of California not be used in advertising or publicity pertaining to distribution of the software without specific written permission.

CMU AND THE REGENTS OF THE UNIVERSITY OF CALIFORNIA DISCLAIM ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL CMU OR THE REGENTS OF THE UNIVERSITY OF CALIFORNIA BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM THE LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

---- Part 2: Networks Associates Technology, Inc copyright notice (BSD) -----

Copyright (c) 2001-2003, Networks Associates Technology, Inc

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of the Networks Associates Technology, Inc nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 3: Cambridge Broadband Ltd. copyright notice (BSD) -----

Portions of this code are copyright (c) 2001-2003, Cambridge Broadband Ltd.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * The name of Cambridge Broadband Ltd. may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 4: Sun Microsystems, Inc. copyright notice (BSD) -----

Copyright c 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Use is subject to license terms below.

This distribution may include materials developed by third parties.

Sun, Sun Microsystems, the Sun logo and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of the Sun Microsystems, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR

SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 5: Sparta, Inc copyright notice (BSD) -----

Copyright (c) 2003-2012, Sparta, Inc

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of Sparta, Inc nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 6: Cisco/BUPTNIC copyright notice (BSD) -----

Copyright (c) 2004, Cisco, Inc and Information Network Center of Beijing University of Posts and Telecommunications.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of Cisco, Inc, Beijing University of Posts and Telecommunications, nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE

ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 7: Fabasoft R&D Software GmbH & Co KG copyright notice (BSD) -----

Copyright (c) Fabasoft R&D Software GmbH & Co KG, 2003 oss@fabasoft.com

Author: Bernhard Penz

bernhard.penz@fabasoft.com>

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * The name of Fabasoft R&D Software GmbH & Co KG or any of its subsidiaries, brand or product names may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 8: Apple Inc. copyright notice (BSD) -----

Copyright (c) 2007 Apple Inc. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name of Apple Inc. ("Apple") nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY APPLE AND ITS CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES

OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL APPLE OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 9: ScienceLogic, LLC copyright notice (BSD) -----

Copyright (c) 2009, ScienceLogic, LLC

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of ScienceLogic, LLC nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 10: Lennart Poettering copyright notice (BSD-like) -----

Copyright 2010 Lennart Poettering

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

---- Part 11: IETF copyright notice (BSD) -----

Copyright (c) 2013 IETF Trust and the persons identified as authors of the code. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of Internet Society, IETF or IETF Trust, nor the names of specific contributors, may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 12: Arista Networks copyright notice (BSD) ----

Copyright (c) 2013, Arista Networks, Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of Arista Networks, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 13: VMware, Inc. copyright notice (BSD) -----

Copyright (c) 2016, VMware, Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

* Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of VMware, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 14: USC/Information Sciences Institute copyright notice (BSD) -----

Copyright (c) 2017-2018, Information Sciences Institute All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of Information Sciences Institue nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO,

PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

MIT License

Copyright (c) 1998, 1999, 2000 Thai Open Source Software Center Ltd

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Copyright 2000 Computing Research Labs, New Mexico State University

Copyright 2001-2015 Francesco Zappa Nardelli

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE COMPUTING RESEARCH LAB OR NEW MEXICO STATE UNIVERSITY BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Written by Joel Sherrill <joel@OARcorp.com>.

COPYRIGHT (c) 1989-2000.

On-Line Applications Research Corporation (OAR).

Permission to use, copy, modify, and distribute this software for any purpose without fee is hereby granted, provided that this entire notice is included in all copies of any software which is or includes a copy or modification of this software.

THIS SOFTWARE IS BEING PROVIDED "AS IS", WITHOUT ANY EXPRESS OR IMPLIED WARRANTY. IN PARTICULAR, THE AUTHOR MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND CONCERNING THE MERCHANTABILITY OF THIS SOFTWARE OR ITS FITNESS FOR ANY PARTICULAR PURPOSE.

(1) Red Hat Incorporated

Copyright (c) 1994-2009 Red Hat, Inc. All rights reserved.

This copyrighted material is made available to anyone wishing to use, modify, copy, or redistribute it subject to the terms and conditions of the BSD License. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY expressed or implied, including the implied warranties of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. A copy of this license is available at http://www.opensource.org/licenses. Any Red Hat trademarks that are incorporated in the source code or documentation are not subject to the BSD License and may only be used or replicated with the express permission of Red Hat, Inc.

(2) University of California, Berkeley

Copyright (c) 1981-2000 The Regents of the University of California.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The FreeType Project LICENSE		
2006-Jan-27		
Copyright 1996-2002, 2006 by		

David Turner, Robert Wilhelm, and Werner Lemberg

========

Introduction

The FreeType Project is distributed in several archive packages; some of them may contain, in addition to the FreeType font engine, various tools and contributions which rely on, or relate to, the FreeType Project.

This license applies to all files found in such packages, and which do not fall under their own explicit license. The license affects thus the FreeType font engine, the test programs, documentation and makefiles, at the very least.

This license was inspired by the BSD, Artistic, and IJG (Independent JPEG Group) licenses, which all encourage inclusion and use of free software in commercial and freeware products alike. As a consequence, its main points are that:

- o We don't promise that this software works. However, we will be interested in any kind of bug reports. (`as is' distribution)
- o You can use this software for whatever you want, in parts or full form, without having to pay us. ('royalty-free' usage)
- o You may not pretend that you wrote this software. If you use it, or only parts of it, in a program, you must acknowledge somewhere in your documentation that you have used the FreeType code. (`credits')

We specifically permit and encourage the inclusion of this software, with or without modifications, in commercial products.

We disclaim all warranties covering The FreeType Project and assume no liability related to The FreeType Project.

Finally, many people asked us for a preferred form for a credit/disclaimer to use in compliance with this license. We thus encourage you to use the following text:

....

Portions of this software are copyright © <year> The FreeType

Project (www.freetype.org). All rights reserved.

.....

Please replace <year> with the value from the FreeType version you actually use.

Legal Terms

0. Definitions

Throughout this license, the terms `package', `FreeType Project', and `FreeType archive' refer to the set of files originally distributed by the authors (David Turner, Robert Wilhelm, and Werner Lemberg) as the `FreeType Project', be they named as alpha, beta or final release.

'You' refers to the licensee, or person using the project, where 'using' is a generic term including compiling the project's source code as well as linking it to form a 'program' or 'executable'.

This program is referred to as `a program using the FreeType engine'.

This license applies to all files distributed in the original FreeType Project, including all source code, binaries and documentation, unless otherwise stated in the file in its original, unmodified form as distributed in the original archive.

If you are unsure whether or not a particular file is covered by this license, you must contact us to verify this.

The FreeType Project is copyright (C) 1996-2000 by David Turner, Robert Wilhelm, and Werner Lemberg. All rights reserved except as specified below.

1. No Warranty

THE FREETYPE PROJECT IS PROVIDED 'AS IS' WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL ANY OF THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY DAMAGES CAUSED BY THE USE OR THE INABILITY TO USE, OF THE FREETYPE PROJECT.

2. Redistribution

This license grants a worldwide, royalty-free, perpetual and irrevocable right and license to use, execute, perform, compile, display, copy, create derivative works of, distribute and sublicense the FreeType Project (in both source and object code forms) and derivative works thereof for any purpose; and to authorize others to exercise some or all of the rights granted herein, subject to the following conditions:

o Redistribution of source code must retain this license file (`FTL.TXT') unaltered; any additions, deletions or changes to the original files must be clearly indicated in accompanying documentation. The copyright notices of the unaltered, original files must be preserved in all copies of source files.

o Redistribution in binary form must provide a disclaimer that states that the software is based in part of the work of the FreeType Team, in the distribution documentation. We also encourage you to put an URL to the FreeType web page in your documentation, though this isn't mandatory.

These conditions apply to any software derived from or based on the FreeType Project, not just the unmodified files. If you use our work, you must acknowledge us. However, no fee need be paid to us.

3. Advertising

Neither the FreeType authors and contributors nor you shall use the name of the other for commercial, advertising, or promotional purposes without specific prior written permission.

We suggest, but do not require, that you use one or more of the following phrases to refer to this software in your documentation or advertising materials: `FreeType Project', `FreeType Engine', `FreeType library', or `FreeType Distribution'.

As you have not signed this license, you are not required to accept it. However, as the FreeType Project is copyrighted material, only this license, or another one contracted with the authors, grants you the right to use, distribute, and modify it.

Therefore, by using, distributing, or modifying the FreeType Project, you indicate that you understand and accept all the terms of this license.

4. Contacts

There are two mailing lists related to FreeType:

o freetype@nongnu.org

Discusses general use and applications of FreeType, as well as future and wanted additions to the library and distribution.

If you are looking for support, start in this list if you haven't found anything to help you in the documentation.

o freetype-devel@nongnu.org

Discusses bugs, as well as engine internals, design issues, specific licenses, porting, etc.

Our home page can be found at

http://www.freetype.org

--- end of FTL.TXT ---

The TWAIN Toolkit is distributed as is. The developer and distributors of the TWAIN Toolkit expressly disclaim all implied, express or statutory warranties including, without limitation, the implied warranties of merchantability, noninfringement of third party rights and fitness for a particular purpose. Neither the developers nor the distributors will be liable for damages, whether direct, indirect, special, incidental, or consequential, as a result of the reproduction, modification, distribution or other use of the TWAIN Toolkit.

JSON for Modern C++

Copyright (c) 2013-2017 Niels Lohmann

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Copyright (c) 2011 - 2015 ARM LIMITED

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of ARM nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL COPYRIGHT HOLDERS AND CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2014, Kenneth MacKay

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2006, CRYPTOGAMS by <appro@openssl.org> All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain copyright notices, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of the CRYPTOGAMS nor the names of its copyright holder and contributors may be used to endorse or promote products derived from this software without specific prior written permission.

ALTERNATIVELY, provided that this notice is retained in full, this product may be distributed under the terms of the GNU General Public License (GPL), in which case the provisions of the GPL apply INSTEAD OF those given above.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

ISC License

Copyright (c) 2013-2017

Frank Denis < j at pureftpd dot org>

Permission to use, copy, modify, and/or distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS" AND THE AUTHOR DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Copyright (c) 2008 The NetBSD Foundation, Inc.

All rights reserved.

This code is derived from software contributed to The NetBSD Foundation by Lennart Augustsson (lennart@augustsson.net) at Carlstedt Research & Technology.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE NETBSD FOUNDATION, INC. AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR

PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2000 Intel Corporation

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither name of Intel Corporation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL INTEL OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Lua

Copyright © 1994–2014 Lua.org, PUC-Rio.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated

documentation files (the "Software"), to deal in the Software without restriction, including without limitation the

rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to

permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of

the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED.

INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN

ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH

THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

LuaSocket

LuaSocket 2.0.2 license Copyright © 2004-2007 Diego Nehab

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

LuneScript

Copyright (c) 2018 ifritJP

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Copyright (c) 2002-2019, Jouni Malinen <j@w1.fi> and contributors All Rights Reserved.

This software may be distributed, used, and modified under the terms of BSD license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (C) 2019, Broadcom Corporation. All Rights Reserved.

Permission to use, copy, modify, and/or distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS" AND THE AUTHOR DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

The certificate files "Amazon Root CA 1", "Amazon Root CA 2", "Amazon Root CA 4" are licensed under a Creative Commons Attribution-NoDerivatives 4.0 International License.

This software is licensed under the MIT License.

Copyright Fedor Indutny, 2018.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

The following applies only to products supporting Wi-Fi.

(c) 2009-2013 by Jeff Mott. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions, and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions, and the following disclaimer in the documentation or other materials provided with the distribution.
- * Neither the name CryptoJS nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS," AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE,

ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright 2008, Google Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of Google Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 1998-2010, Brian Gladman, Worcester, UK. All rights reserved.

The redistribution and use of this software (with or without changes) is allowed without the payment of fees or royalties provided that: source code distributions include the above copyright notice, this list of conditions and the following disclaimer; binary distributions include the above copyright notice, this list of conditions and the following disclaimer in their documentation.

This software is provided 'as is' with no explicit or implied warranties in respect of its operation, including, but not limited to, correctness and fitness for purpose.

Disclaimer: IMPORTANT: This Apple software is supplied to you, by Apple Inc. ("Apple"), in your capacity as a current, and in good standing, Licensee in the MFi Licensing Program. Use of this Apple software is governed by and subject to the terms and conditions of your MFi License, including, but not limited to, the restrictions specified in the provision entitled "Public Software", and is further subject to your agreement to the following additional terms, and your agreement that the use, installation, modification or redistribution of this Apple software constitutes acceptance of these additional terms. If you do not agree with these additional terms, please do not use, install, modify or redistribute this Apple software.

Subject to all of these terms and in consideration of your agreement to abide by them, Apple grants you, for as long as you are a current and in good-standing MFi Licensee, a personal, non-exclusive license, under Apple's copyrights in this original Apple software (the "Apple Software"), to use, reproduce, and modify the Apple Software in source form, and to use, reproduce, modify, and redistribute the Apple Software, with or without modifications, in binary form. While you may not redistribute the Apple Software in source form, should you redistribute the Apple Software in binary form, you must retain this notice and the following text and disclaimers in all such redistributions of the Apple Software. Neither the name, trademarks, service marks, or logos of Apple Inc. may be used to endorse or promote products derived from the Apple Software without specific prior written permission from Apple. Except as expressly stated in this notice, no other rights or licenses, express or implied, are granted by Apple herein, including but not limited to any patent rights that may be infringed by your derivative works or by other works in which the Apple Software may be incorporated.

Unless you explicitly state otherwise, if you provide any ideas, suggestions, recommendations, bug fixes or enhancements to Apple in connection with this software ("Feedback"), you hereby grant to Apple a non-exclusive, fully paid-up, perpetual, irrevocable, worldwide license to make, use, reproduce, incorporate, modify, display, perform, sell, make or have made derivative works of, distribute (directly or indirectly) and sublicense, such Feedback in connection with Apple products and services. Providing this Feedback is voluntary, but if you do provide Feedback to Apple, you acknowledge and agree that Apple may exercise the license granted above without the payment of royalties or further consideration to Participant.

The Apple Software is provided by Apple on an "AS IS" basis. APPLE MAKES NO WARRANTIES, EXPRESS OR

IMPLIED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY

AND FITNESS FOR A PARTICULAR PURPOSE, REGARDING THE APPLE SOFTWARE OR ITS USE AND OPERATION ALONE OR

IN COMBINATION WITH YOUR PRODUCTS.

IN NO EVENT SHALL APPLE BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES

(INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR

PROFITS; OR BUSINESS INTERRUPTION) ARISING IN ANY WAY OUT OF THE USE, REPRODUCTION, MODIFICATION

AND/OR DISTRIBUTION OF THE APPLE SOFTWARE, HOWEVER CAUSED AND WHETHER UNDER THEORY OF CONTRACT, TORT

(INCLUDING NEGLIGENCE), STRICT LIABILITY OR OTHERWISE, EVEN IF APPLE HAS BEEN

ADVISED OF THE

POSSIBILITY OF SUCH DAMAGE.

Copyright (C) 2009 Apple Inc. All Rights Reserved.

Copyright (c) 2012-2013 Apple Inc. All rights reserved.

Copyright (C) 2013 Apple Inc. All Rights Reserved.

The following applies only to products supporting the cloud service (formerly known as PIXUS Cloud Link, PIXMA Cloud Link, or MAXIFY Cloud Link).

THE BASIC LIBRARY FUNCTIONS

Written by: Philip Hazel Email local part: ph10

Email domain: cam.ac.uk

University of Cambridge Computing Service, Cambridge, England.

Copyright (c) 1997-2012 University of Cambridge

All rights reserved.

PCRE JUST-IN-TIME COMPILATION SUPPORT

Written by: Zoltan Herczeg
Email local part: hzmester
Emain domain: freemail.hu

Copyright(c) 2010-2012 Zoltan Herczeg

All rights reserved.

STACK-LESS JUST-IN-TIME COMPILER

Written by: Zoltan Herczeg Email local part: hzmester Emain domain: freemail.hu

Copyright(c) 2009-2012 Zoltan Herczeg

All rights reserved.

THE C++ WRAPPER FUNCTIONS

Contributed by: Google Inc.

Copyright (c) 2007-2012, Google Inc.

All rights reserved.

THE "BSD" LICENCE

-----Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of the University of Cambridge nor the name of Google Inc. nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This software is based in part on the work of the Independent JPEG Group.

Cautions, Limitations, and Restrictions (PosterArtist)

PosterArtist is subject to the following restrictions. Keep these points in mind.

System Requirements

Access our website for products supporting PosterArtist.

The functions that can be used and the items that can be configured vary depending on your scanner or printer.

This guide primarily refers to the Windows 10 operating system (hereafter, Windows 10) interface. Apply the latest Windows Update.

Restrictions on Using PosterArtist Lite

PosterArtist Lite has the following limitations compared to PosterArtist (Production Version).

The following functions are not available.

- Auto Design
- · Guide, Grid, and Ruler
- Variable Print
- Some functions of Retouch Image
- Artwork Security Settings (settings for usage period and editing restrictions)
- Ambient Light Correction
- · Design Check
- · Design Assist
- Quick Exchange
- Saving and updating of Artwork Snapshots

PosterArtist Lite contains fewer pieces of artwork than PosterArtist (Production Version).

This guide describes how to use PosterArtist (Production Version).

Usage Restrictions

You must log on to Windows as an administrator before the installation.

Please check the following points before installing this software.

- 1. Shut down all other open applications.
- 2. If a document is currently being printed out, then cancel printing or wait until printing ends.
- 3. Check that the printer driver required by the target printer has been installed.

If the installer screen is not displayed, double-click the CD-ROM icon in **Computer**, and then double-click "presetup.exe".

Colors are preset in clipart, photo frames, and text graphics. If a color cannot be changed, then the control for changing that color is disabled.

Resizing clipart in the horizontal or vertical direction using • (Resize handle) may cause partial deformation of the clipart.

The printed result may differ from the monitor display if you select a square paper format created with the Custom Paper Size function of the printer driver and then print in cut sheet mode. In such cases, resize one of the sides by 0.1 mm or more to form a rectangle, and then try printing again.

In some cases, it may take some time to import posters created in PosterArtist 1.x.

In some cases, layout of posters created in PosterArtist 1.x may not appear correctly when importing the file.

In some cases, the italicized and bold fonts of posters created in PosterArtist 1.x may not appear correctly when the data is imported.

With some fonts, the effect of italics may not be apparent.

Vertical text in certain fonts may be truncated or misaligned. (For example, in the case of DynaFont of DFG.)

Depending on the selected font type, text may be displayed outside the text box.

Depending on the selected font type, outlined text may not be displayed correctly.

In variable data print, if double-byte text is inserted to a text object created with single-byte text on a poster, the result may not appear as expected. In that case, change the font type to one that will correctly display the text.

Printing cannot be performed via a print server.

If you delete artwork on the Artwork Manager screen while an installer for other software is running, the artwork may not be deleted correctly. Thus, before deleting artwork, make sure no installers for other software are running.

Artwork can be copied from the Artwork Manager dialog box; however, copies of artwork with a lock icon cannot be deleted.

Administrator rights are needed in order to delete artwork in Artwork Manager.

When importing poster data that has been created using PosterArtist, a warning message will appear for data containing library images that are not provided with PosterArtist Lite. The images will not appear on the poster.

Some of the templates on the PosterArtist template download page use content (images) that is not included in PosterArtist Lite. If you download any of these templates, a warning message will appear and its content (images) will not appear on the template.

When importing poster data that has been created using PosterArtist, poster data for which a variable data print has been specified will be handled as normal poster data. When you save the poster data, the link to the variable data will be lost.

Data for large size paper may fail to print. If this occurs, try printing after performing the following.

Exit PosterArtist, and then open the properties for the printer you want to use.

Open the Layout tab, and then click the Special Settings button.

Deselect the Fast Graphic Process checkbox. After that, restart PosterArtist, and then try printing again.

When printing is finished, select the **Fast Graphic Process** checkbox again.

For some models, **Minimal Margin Printing** is displayed instead of **Borderless Printing**. When **Minimal Margin Printing** is displayed, printouts will have slight margins on the left and right sides.

With Design Assist, created designs may include multiple copies of the same design depending on the specified images and selected area.

Unicode supplementary characters (surrogate pairs) are not supported. If a Unicode supplementary character is entered, "?" appears instead.

In a 64-bit version OS environment, some functions may not be available.

Poster files created with or exported from PosterArtist version 3.0 or later cannot be opened in earlier versions of PosterArtist.

If a message prompting you to update the root certificate appears at startup of an application, connect to the Internet, and then restart the application.

In an environment where you cannot connect to the Internet, obtain and apply an "Update for Root Certificates" of Microsoft.

In environments where the 64-bit version of Microsoft Office 2007 or later is installed on a 64-bit version OS, you may not be able to use xlsx or other formats as database files for variable printing. In that case, the files can be used by converting them to xls format or CSV format.

Supported File Formats

Supported file formats are as follows.

JPEG

TIFF (without LZW compression)

BMP

PNG

SVG

WMF/EMF

JPEG and TIFF images are inserted as images in the sRGB color space. TIFF and PNG images are processed as 8-bit images. SVG images do not appear correctly depending on the embedded commands.

Trademarks and Copyrights

© CANON INC. 2016

Canon, the Canon logo, imagePROGRAF, and PosterArtist are trademarks or registered trademarks of Canon Inc.

Microsoft is a registered trademark of Microsoft Corporation.

Windows is a registered trademark or trademark of Microsoft Corporation in the U.S. and/or other countries.

Excel and Internet Explorer are registered trademarks or trademarks of Microsoft Corporation, in the U.S. and other countries.

Third party acknowledgments:

This software is based in part on the work of the Independent JPEG Group.

PosterArtist and PosterArtist Lite contain third party software licensed under the following terms:

TIFF:

Copyright © 1988-1997 Sam Leffler

Copyright © 1991-1997 Silicon Graphics, Inc.

Permission to use, copy, modify, distribute, and sell this software and its documentation for any purpose is hereby granted without fee, provided that: (i) the above copyright notices and this permission notice appear in all copies of the software and related documentation; and (ii) the names of Sam Leffler and Silicon Graphics may not be used in any advertising or publicity relating to the software without the specific, prior written permission of Sam Leffler and Silicon Graphics.

THE SOFTWARE IS PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EXPRESS, IMPLIED OR OTHERWISE, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IN NO EVENT SHALL SAM LEFFLER OR SILICON GRAPHICS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER OR NOT ADVISED OF THE POSSIBILITY OF DAMAGE, AND ON ANY THEORY OF LIABILITY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

ICC:

Copyright (c) 1994-1996 SunSoft, Inc.

Rights Reserved

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. IN NO EVENT SHALL SUNSOFT, INC. OR ITS PARENT COMPANY BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of SunSoft, Inc. shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without written authorization from SunSoft Inc.

JSON for Modern C++

Copyright (c) 2013-2017 Niels Lohmann

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Images and templates in this software are subject to copyright as follows:

The copyright of some of the templates and images included in PosterArtist and PosterArtist Lite is owned by Design Exchange Co., Ltd. and the creators and suppliers of those templates and images.

Third party services

If you use third-party services through PosterArtist or PosterArtist Lite, use of the services are subject to the conditions below.

When you access and/or obtain some third party content (such as text, images, videos, audios, or software) through PosterArtist or PosterArtist Lite, except as expressly permitted by the content owner or by applicable law, you may not

- (a) scrape, build databases or otherwise create permanent copies of such content, or keep cached copies longer than permitted by the cache header;
- (b) copy, translate, modify, create a derivative work of, sell, lease, lend, convey, distribute, publicly display or sublicense to any third party;
- (c) misrepresent the source or ownership;
- and (d) remove, obscure, or alter any copyright, trademark or other proprietary rights notices, falsify or delete any author attributions, legal notices or other labels of the origin or source of material.

License Authentication

When starting PosterArtist for the first time, enter the License Access Number. PosterArtist cannot be used unless you authenticate the license. You will be required to reauthenticate the license when replacing your computer or hard disk.

To reauthenticate the license, follow either of the procedures below.

Transfer your license to the destination computer and reauthenticate it.

Transferring the License

Return your license to the server temporarily and reauthenticate it on the destination computer.

Returning the License

>>>> Important

 To transfer or return the license, Internet connection and Internet Explorer 6 or later are required. For details, refer to the License Authentication Guide supplied with PosterArtist.

Transferring the License

Before transferring the license, install PosterArtist on the destination computer. Then, create the request data file in the **License Authentication** screen of PosterArtist. For instructions on creating the request data file, see <u>Creating Request Data</u>.

1. Select License Information Management as follows.

Windows 10:

From the Start menu, select (All apps >) Canon LMS > License Information Management.


Windows 8.1/Windows 8:

From the **Search** charm, search for Canon LMS, and then select **License Information Management**.


Windows 7/Windows Vista:

From the Start menu, select All Programs > Canon LMS > License Information Management.

- 2. In the License Information Management screen, click Transfer.
- Specify the request data file of the destination computer, and then click Next.



4. Click Close.



5. Reauthenticate the license on the destination computer.

>>> Note

• For how to authenticate the license, refer to the License Authentication Guide supplied with PosterArtist.

Creating Request Data

1. Select License Information Management as follows.

Windows 10:

From the Start menu, select (All apps >) Canon LMS > License Information Management.


Windows 8.1/Windows 8:

From the Search charm, search for Canon LMS, and then select License Information Management.

Windows 7/Windows Vista:


From the Start menu, select All Programs > Canon LMS > License Information Management.

- 2. In the License Authentication Wizard screen, select the Offline Authentication and Create Request Data checkboxes, and then click Next.
- **3.** Enter the License Access Number of your PosterArtist, and then click **Next**.




Note

- Enter the **License Access Number** using 16 single-byte letters and/or numbers (four characters in four fields).
- 4. Specify the location to save the request data file, and then click Next.



5. Check the displayed message, and then click Exit.



Returning the License

1. Select License Information Management as follows.

Windows 10:

From the Start menu, select (All apps >) Canon LMS > License Information Management.


Windows 8.1/Windows 8:

From the Search charm, search for Canon LMS, and then select License Information Management.


Windows 7/Windows Vista:

From the Start menu, select All Programs > Canon LMS > License Information Management.

- 2. In the License Information Management screen, click Return.
- **3.** Check the displayed message, and then click **Return License**.



4. Click Close.



5. Reauthenticate the license on another computer as needed.

>>> Note

• For how to authenticate the license, refer to the License Authentication Guide supplied with PosterArtist.

What Is PosterArtist?

- ➤ What You Can Do with PosterArtist
- ➤ Starting PosterArtist

What You Can Do with PosterArtist


PosterArtist is an application for creating professional-looking posters even without professional knowledge or experience. Simply select a design from a variety of templates and then insert and edit text, photos, clipart, and other materials.

Features at a Glance

- → Poster Elements (Objects)
- ➡ Printing Posters Using a Variety of Templates and Materials
- → Adding Items to Your Library
- ➡ Creating Enlarged Copies for Printing Posters
- ➡ Inserting Your Own Materials
- → Variable Printing
- → Importing and Exporting Templates
- Using Cloud Services
- ➡ Retouching Images Effectively
- Creating and Adjusting Designs Automatically
- ➡ Exporting Posters for Use in Easy-PhotoPrint Editor

Poster Elements (Objects)

The following objects can be inserted in posters you create with PosterArtist.



1. Photos

- 2. Clipart
- 3. Vector based images (WMF, EMF)
- 4. QR Code
- 5. Text
- 6. Shapes
- 7. Backgrounds

Printing Posters Using a Variety of Templates and Materials

PosterArtist provides templates covering many categories and business field, as well as a wide range of clipart, photos, and other materials. Create and print unique posters easily from templates by changing the clipart and photos or inserting text.


Creating and Printing Posters



Creating Multilingual Posters

Use multilingual templates and translations provided with PosterArtist to quickly create a multilingual poster.

■ Using Translation Templates



Adding Items to Your Library

Add posters you have created and images on your computer to the library. Added posters can also be used as templates for creating new posters.


Adding Artwork to Library



Creating Enlarged Copies for Printing Posters

Use PosterArtist QuickCopy to scan photos and documents and then print enlarged copies of them at poster sizes.

Creating and Printing Enlarged Copies of Photos and Documents




Inserting Your Own Materials

In addition to the materials provided in the library, images on your computer such as those from digital cameras or scanners can be directly inserted in posters.

Documents, tables, and graphs created with Microsoft Word, Microsoft PowerPoint, or Microsoft Excel can also be inserted in posters by importing them to PosterArtist via the printer driver.


➡ Inserting Images in Posters



Variable Printing

Automatically substitute text on the poster when printing by using tabular format data. This can also be used to substitute images automatically.

Using Variable Printing



Importing and Exporting Templates

Export custom poster templates along with the contained images as a single file. Other users can import the templates to their computers.

Artwork other than templates can also be imported or exported.

➡ Importing and Exporting

Using Cloud Services

Share created poster files, image files, and artwork export data with other computers and users by uploading them to or downloading them from cloud services.

→ Using Cloud



Retouching Images Effectively

Correct image color levels, trim photos, or apply a gradation to match the poster's mood.

- ➡ Editing Photos
- Retouching Images

Creating and Adjusting Designs Automatically

Use the Auto Design function to automatically create designs by simply entering titles and text, and then selecting your favorite images.

Even if you are not an experienced designer, you can create highly original posters by using the Design Assist function for automatically adjusting poster layout, and the Quick Exchange function for easily swapping the positions of images and text.

- Using Auto Design
- Adjusting Designs

Exporting Posters for Use in Easy-PhotoPrint Editor

Export poster data for editing and printing with Easy-PhotoPrint Editor.

Use Easy-PhotoPrint Editor to print the same posters even from computers and smartphones on which PosterArtist is not installed.

→ Exporting Posters for Use in Easy-PhotoPrint Editor



Starting PosterArtist

PosterArtist can be started as follows.



Double-click PosterArtist PosterArtist on the desktop Start from the Programs folder

Windows 10:

From the Start menu, select (All apps >) Canon Utilities > PosterArtist.

Windows 8.1:

Select PosterArtist on the Start screen to start PosterArtist.

If **PosterArtist** is not displayed on the Start screen, select the **Search** charm, and then search for "PosterArtist."

Windows 7:

From the Start menu, select All Programs > Canon PosterArtist > PosterArtist.

>>> Note

- Multiple instances of PosterArtist can run simultaneously, and materials can be copied and pasted between these windows. When multiple instances of PosterArtist are running, you cannot use Artwork Manager, import and save artwork, or open files.
- When starting PosterArtist for the first time, the License Access Number must be entered. For details, see <u>License Authentication</u>.
- To exit PosterArtist, click (Close) in the upper right of the window, or select **Exit** from the **File** menu.

Creating and Printing Posters

Create posters easily from the templates provided with PosterArtist and print them directly.

- 1. Starting PosterArtist.
- 2. In the task area, click Select Template.

>>> Note

- For details on the Select Template screen, see Select Template Screen.
- **3.** In **Category**, select the category of poster you want to create.
- 4. Select a template from the thumbnails, and then double-click it.

>>> Note

- You can also select a template by dragging and dropping it from Category to the poster design area.
- If the (Download) icon is displayed on the thumbnail of a template, click the icon to download the template.
- For instructions on selecting templates, see Templates.
- To design posters freely without using a template, see Freely Designing.
- 5. In the task area, click Paper Options.

The view switches to the **Paper Options screen**.

6. Specify Page Size, Poster Orientation, the printer to use, and other settings.

>>> Note

- · Available settings vary depending on the selected printer.
- For paper settings, see Specifying Size and Paper.
- 7. In the task area, click Edit.

The view switches to the **Edit** screen.

Note

- · For details on the Edit screen, see the following.
 - ➡ Edit Screen (Photos)
 - ➡ Edit Screen (Clipart)
 - Edit Screen (Text)
 - ➡ Edit Screen (Shapes)
 - ➡ Edit Screen (Backgrounds)
 - ➡ Edit Screen (Variable Data)
- 8. Edit photos and text as needed.

>>> Note

- For details on editing photos and text, see the following.
 - → Editing Photos
 - → Retouching Images
 - ➡ Editing Clipart
 - ➡ Editing Text
 - Editing Shapes
 - ➡ Editing Backgrounds
- 9. In the task area, click Print.

The view switches to the **Print screen**.

10. Specify Print Quality, Matching Method, Copies, and other settings.

>>> Note

- Available settings vary depending on the selected printer.
- To test print your poster on A4 or Letter size paper, click **Test Print**. For details, see <u>Test Printing</u>.

11. Click Print.

Printing starts.

>>> Note

- For printing, see **Printing Posters**.
- You can also save posters you have created. For details, see Saving.

Creating and Printing Enlarged Copies of Photos and Documents

Use PosterArtist QuickCopy to print posters by enlarging scanned photos and documents. Scanned items can also be inserted as objects in posters.

>>>> Important


· The scanner's calibration function cannot be used.

>>>> Note

- PosterArtist QuickCopy is installed automatically when PosterArtist is installed.
- · Access our website for information on scanners and All-In-One printers supporting PosterArtist QuickCopy.
- For details on PosterArtist QuickCopy, see PosterArtist QuickCopy Screen.
- If you plan to edit the scanned item, using a TWAIN device will allow you to make more detailed settings for importing images than with PosterArtist QuickCopy.
 - 1. Connect computer and scanner.



2. Double-click QuickCopy PosterArtist QuickCopy on the desktop.



>>> Note

· You can also start PosterArtist QuickCopy in the following ways.

Windows 10:

From the Start menu, select (All apps >) Canon Utilities > PosterArtist QuickCopy.

Windows 8.1:

Select PosterArtist QuickCopy on the Start screen to start PosterArtist QuickCopy.

If **PosterArtist QuickCopy** is not displayed on the Start screen, select the **Search** charm, and then search for "PosterArtist QuickCopy."

Windows 7:

From the Start menu, select All Programs > Canon PosterArtist > PosterArtist QuickCopy.

3. Click **Detailed settings...**, and then in the displayed screen, specify the scanner and printer to use.

>>> Note

- Images can be retouched as needed when scanning them. For details, see <u>Detailed settings...</u> in **PosterArtist QuickCopy** Screen.
- 4. Specify Media Source, Media Type, Copies, and other settings.

>>> Note

- The displayed paper types vary depending on the selected printer.
- For borderless printing, specify the settings as follows.

Media Source: Roll Paper

Media Type: Paper that supports borderless printing

Copy Size: Fit to Roll Width

Long Side and Short Side: Select either checkbox

- **5.** Place the original.
- 6. Click Preview.

The image appears in the preview area. The scan area is indicated by a dashed outline. Change the scan area as needed.

>>> Note

· Preview can be skipped.

7. Click Copy.

Scanning starts. When scanning is completed, printing starts automatically.

>>> Note


• To cancel printing, click **Stop**, and then click **Cancel** in the displayed screen.

>>> Note

• To send scanned images to PosterArtist, click **Edit with PosterArtist**. Sent images appear in the poster design area of PosterArtist. For instructions on creating posters, see <u>Creating and Printing Posters</u>.

PosterArtist QuickCopy Screen

This is PosterArtist QuickCopy's main screen for selecting the scanner and printer to use, specifying the printing method, and more.



- A: Preview Area
- **▶** B: Edit with PosterArtist
- C: Settings Area
- D: Buttons Area

A: Preview Area

Displays a preview of the scanned image. The scan area is indicated by an outline and can be adjusted.

Resizing the scan area

Point to the outline of the scan area to display one of these cursors: \longleftrightarrow , \updownarrow , or \swarrow . Drag the cursor to adjust the scan area.

Moving the scan area

Move the pointer inside the outlined scan area to display (Move pointer). Drag the outlined area with (Move pointer) to move the scan area.

B: Edit with PosterArtist

Opens the scanned image in PosterArtist for editing.

C: Settings Area

Specify the printer and scanner to use, paper source, paper type, size, and other settings for printing.

Scanner

Displays the scanner to be used.

Printer

Displays the printer to be used.

Detailed settings...

Displays the **Detailed settings** dialog box for changing the scanner and printer to use and for making advanced settings for scanning.



Scanner

Select the scanner to use. The list displays only scanners supporting PosterArtist QuickCopy among scanners installed on your computer.

Moire reduction

Moire is image distortion (uneven, lighter areas or striped patterns) that may occur when scanning photos or pictures. Select this checkbox to reduce moire.

Note

· Some moire effects may remain when the Edge enhancement checkbox is selected.

Edge enhancement

Select this checkbox to enhance the outline and increase sharpness.

Set-off reduction

When the original is double-sided, images or text on the reverse side may be scanned inadvertently. Select this checkbox to reduce this show-through effect.

Background color removal

When paper of the original is light-colored, select this checkbox to correct the base color and make it white.

>>> Note

- Correction may not be applied if the original is dark-colored or includes many photos.
- Background color removal cannot be set when Set-off reduction is set.

Printer

Select the printer to use. The list displays only printers supporting PosterArtist among printers installed on your computer.

Properties...

Displays the selected printer's **Properties** dialog box for specifying the print settings.

Print Quality

Select the print quality. Available options vary depending on the selected paper type.

Matching Method

Select a rendering intent.

Auto

Print in natural color tones.

Perceptual / Perceptual (Photo)

Print with natural color tones and gradations. Suitable for photos.

Colorimetric

Reduces color differences between the original document and the print result.

Saturation / Saturation (Poster)

Performs color matching while emphasizing vividness.

Free Layout

Select this checkbox to enable the Free Layout function of the printer driver.

Media Source

Select the paper source.

Media Type

Select the type of paper you want to use.

Copy Size

Select the size for the enlarged copy.

Long Side

Select this to print by enlarging the original so that the length of the poster's long side will be the same as the paper width.

Short Side

Select this to print by enlarging the original so that the length of the poster's short side will be the same as the paper width.

Copies

Set the number of copies to print.

D: Buttons Area

Preview

Scans the original to display the print area.

Copy

Scans the original to print an enlarged copy.

Stop

Cancels printing.

Various Functions for Creating Posters

- Templates
- Freely Designing
- Specifying Size and Paper
- Inserting Images and Materials
- Editing Photos
- Editing Clipart
- Retouching Images
- Editing Shapes
- Editing Text
- **▶** Editing Backgrounds
- Working with Objects
- Printing Posters
- Saving
- Using Variable Printing
- Managing Artwork
- Using Cloud
- Using Translation Templates
- Exporting Posters for Use in Easy-PhotoPrint Editor
- Creating Vivid Posters Using Fluorescent Colors

Templates

PosterArtist provides a spectrum of poster templates to support many business fields and operations, and new templates will be distributed in the future. Since the templates are categorized by different subjects, it is easy to find templates of the design that suits your particular needs.

Templates can also be searched by specifying the search criteria such as poster orientation or the number of photos that can be inserted.

Templates come complete with sample photos, text, backgrounds clipart, etc., which can be replaced or edited to create your own design.

- Selecting Templates
- Displaying All Templates
- Searching Templates
- Using Existing Posters
- Downloading Templates
- Performing a Design Check

>>> Note

- You can also create completely original posters without using a template. For details, see <u>Using Auto Design</u>.
- Created posters can be added to the library as templates. For details, see Adding Artwork to Library.

Selecting Templates

1. In the task area, click Select Template.

>>> Note

- For details on the **Select Template** screen, see <u>Select Template Screen</u>.
- 2. In Category, select a template category.

>>> Note

- To view all templates, click View All Templates.... For details, see Displaying All Templates.
- Templates can be searched by poster orientation or the number of photos that can be inserted. For details, see <u>Searching Templates</u>.
- **3.** Select a template from the thumbnails, and then double-click it.

The template appears in the poster design area.

>>> Note

- If the (Download) icon is displayed on the thumbnail of a template, click the icon to download the template.
- To try out different templates, you can place other templates in the temporary tray.

Displaying All Templates

1. In the task area, click Select Template.

Note

- For details on the **Select Template** screen, see <u>Select Template Screen</u>.
- 2. Click View All Templates....

The View All Templates dialog box appears.

3. In Category, select a template category.

>>> Note

- To download new templates to the library at once, click **Download**.
- 4. Select the template you want to use and click OK.

The template appears in the poster design area.

Note

- To view all provided templates, photos, clipart, photo frames, text graphics, and backgrounds, refer to Template Guide.
- To add the selected template to the temporary tray, click Add to Temporary Tray.

Searching Templates

Templates can be searched by poster orientation or the number of photos that can be inserted.

1. In the task area, click Select Template.

>>> Note

• For details on the **Select Template** screen, see <u>Select Template Screen</u>.

2. Click Find Template....

The Find Template dialog box appears.

3. Select search criteria.

To search by poster orientation:

In Orientation, select Vertical or Horizontal.

To include all target templates, select Vertical and Horizontal.

To search by number of photos that can be inserted:

Select a number in No. of Photos.

To include all target templates, select All.

>>> Note

- Orientation and No. of Photos can be specified at the same time.
- To download new templates to the library at once, click **Download**.
- 4. Select the template you want to use and click OK.

The template appears in the poster design area.

>>> Note

• To add the selected template to the temporary tray, click Add to Temporary Tray.

Using Existing Posters

Create a new poster using a poster you have created and saved.

1. In the task area, click Select Template.

>>> Note

- For details on the **Select Template** screen, see <u>Select Template Screen</u>.
- 2. Click Open Poster....

The **Open Poster** dialog box appears.

>>> Note

- In the **Open Poster** dialog box, PosterArtist files (with a ".cpf,".cpfx,".cpfx2," or ".cpfx3" file extension) are displayed.
- **3.** Specify the location of the poster file you want to use.
- **4.** Select a poster file, and then click **Open**.

The poster appears in the poster design area.

Downloading Templates

Download templates from our website.

1. In the task area, click Download Contents.

Our website appears.

- 2. From the PosterArtist download page, download a template file (*.cpt file or *.cptx file).
- **3.** Import the downloaded template file.

>>>> Note

• For instructions on importing template files, see Importing Artwork.

Performing a Design Check

Automatically check the font, superimposed objects, etc. for created posters.

A warning will appear if there is a problem or if there is a high chance that the print result will be unsatisfactory.

Follow the message in the warning to correct and improve the poster.

>>>> Important

- · A warning may appear even for intentional designs.
 - 1. On the toolbar, click (Design Check).

A (Warning) symbol appears where there is a problem or where there is a high chance that the print result will be unsatisfactory.

2. On the poster, click the (Warning) symbol.

The reason for the warning and a preventive method for the problem appear.

On the toolbar, click (Design Check) again.
 Design Check ends.

Freely Designing

- Using Auto Design
- ➤ Adjusting Designs

Using Auto Design


Auto Design is a function to automatically design posters by simply entering titles and text, and then selecting your favorite images.

From created designs, select the one you like.

- 1. In the task area, click Select Template.
- 2. Click Auto Design....

The Auto Design screen appears.

- 3. Select the type of poster you want to create, and then click Next.
- **4.** In **Design Image**, select a design theme.



5. Enter the Title, Subtitle, Body, and Organization.

>>>> Important

- If Long/Horizontal Banners is selected in poster type, the Body cannot be entered.
- Advanced Settings... may not be displayed depending on your language.

>>> Note

- Enter up to 60 characters for **Title**, **Subtitle**, and **Organization**.
- Enter up to 200 characters for **Body**.
- Click **Advanced Settings...** to display the <u>Advanced Settings dialog box</u> for setting a monospaced font for the title, body, and other text.
- 6. Select the Paper Orientation.

7. Select the images you want to use in the poster as follows.

To use images saved on computer:

Click From File... to display the Insert Image dialog box, and then select image(s).

Note

- To select multiple files, hold down the Ctrl or Shift key as you click the thumbnails.
- Image files can also be added by dragging and dropping them from Windows Explorer.
- For supported file formats, see Supported File Formats.

To use photos or clipart in temporary tray:

Click From Temp. Tray... to display the Show Images in the Temporary Tray dialog box, and then select image(s).

>>> Note

• To select multiple files, hold down the Ctrl or Shift key as you click the thumbnails.

To use photos in library:

Click From Photo Library... to display the View All Photos dialog box, and then select image(s).

>>> Note

• To select multiple files, hold down the Ctrl or Shift key as you click the thumbnails.

To use clipart in library:

Click From Clipart Library... to display the View All Clipart dialog box, and then select image(s).

>>> Note

• To select multiple files, hold down the Ctrl or Shift key as you click the thumbnails.

>>> Note

• When **Photos/Illustration Focus** is selected in poster type, specify up to eight photos or up to two clipart items.

When a poster type other than **Photos/Illustration Focus** is selected, specify up to two photos or two clipart items.

- To delete images from the image list, select one and click **Delete**.
- To use a selected image multiple times, select it again.

8. Click Next.

Designs are created automatically and their thumbnails appear.

>>> Note

- The number of designs to be created varies depending on the number of selected images, paper orientation, and design theme.
- Changing the order of thumbnails in Photos/Clipart by dragging and dropping them recreates the
 design. To select multiple files and change the order, hold down the Ctrl or Shift key as you click the
 thumbnails.

9. In Color Patterns, select color.

>>> Note

- Choices in Color Patterns are determined by the selected design theme.
- 10. In Text Color, select color.
- **11.** Select your favorite design from the thumbnails, and then click **OK**.

The design is inserted in the poster area.

Note

• Add designs to the temporary tray when you are not sure which design to use. Click **Add to Temporary Tray** to use them as replacements even after ending Auto Design.

>>> Note

• For details on the **Auto Design** screen, see <u>Auto Design Screen</u>.

Adjusting Designs

Use the Design Assist and Quick Exchange functions to produce even higher quality designs from a created design.

- Design Assist (Rearranging Objects)
- Quick Exchange (Swapping Objects)

Design Assist (Rearranging Objects)

Design Assist is a function to adjust poster layouts by automatically rearranging objects in the selected area.

From created design patterns, select the one you like.

1. On the toolbar, click (Design Assist Area Set Mode).

Design Assist Area Set mode is activated.

2. Click and drag to select the area you want to change.

A selection box (framed in orange) appears around each object in the dragged area.

Note

- The number of objects that can be selected at one time is as follows.
- A total of eight photos and clipart items
- Four text items
- 3. Click Generate Design displayed in the lower right of the selected area.

Designs are created automatically and their thumbnails appear.

Note

- The number of designs created varies depending on the size of the selected area and the number of objects.
- Changing the order of thumbnails in Photos/Clipart by dragging and dropping them recreates the
 design. To select multiple files and change the order, hold down the Ctrl or Shift key as you click the
 thumbnails.
- Add designs to the temporary tray when you are not sure which design to use. Click Add to Temporary Tray to use them as replacements even after ending Design Assist.
- **4.** Select your favorite design, and then click **OK**.

The selected design appears in the poster design area.

- Use the Design Check function to automatically check the font, superimposed objects, etc. for created posters. For details, see Performing a Design Check.
- For details on the **Design Assist** dialog box, see <u>Design Assist Dialog Box</u>.

Quick Exchange (Swapping Objects)

Quick Exchange is a function for easily swapping the positions of objects.

This function is useful when you want to create an improved poster design from a created design.

1. On the toolbar, click (Quick Exchange).

Quick Exchange mode is activated.

2. Select one or more objects.

A selection box (framed in orange) appears around the selected object.

3. Move the pointer inside the selection box, and then use (Hand Tool) on the toolbar to drag the object over the object you want to swap positions with.

The objects are swapped.

>>> Important

- When the (Hand and Arrow) pointer is displayed, the object can be swapped with the one below the pointer.
- When the (Hand and X) pointer is displayed, the object cannot be swapped with the one below the pointer.

>>>> Note

- To move an object vertically or horizontally, drag it while holding down the Shift key.
- **4.** When finished swapping, click (Quick Exchange) again on the toolbar.

Quick Exchange mode is canceled.

Note

• Use the Design Check function to automatically check the font, superimposed objects, etc. for created posters. For details, see <u>Performing a Design Check</u>.

Specifying Size and Paper

Print created posters on paper of various sizes and types.

Print to scale or without borders as needed.

Note

- · Available settings vary depending on the selected printer.
- Since the poster paper size and orientation are already set in templates, if you change the paper size or orientation, the objects may be resized. Adjust the size and position of objects as needed.

When Printing on Roll Paper

- Roll Paper Settings
- Printing Borderless Posters Filling the Entire Roll Paper Width
- Printing Bordered Posters Filling the Entire Roll Paper Width
- Printing Without Borders on Three Sides
- Large-Format Printing
- Printing Larger than Roll Paper Size
- When Printing on Cut Sheets
- When Printing to Scale
- When Printing Entire Poster Within Printable Area
- Adding Crop Marks
- Specifying Non-Standard Page Sizes

When Printing on Roll Paper

When printing on roll paper, you can print at non-standard sizes such as for horizontal or vertical banners. Borderless printing is also available.

For instructions on printing on roll paper, see the following.

- ➡ Roll Paper Settings
- ➡ Printing Borderless Posters Filling the Entire Roll Paper Width
- → Printing Bordered Posters Filling the Entire Roll Paper Width
- ➡ Printing Without Borders on Three Sides
- ▶ Large-Format Printing
- ➡ Printing Larger than Roll Paper Size

>>> Important

- · Roll paper printing is available only on printers that support roll paper.
- Supported paper sizes and roll paper widths vary depending on your model. For details, click Home to return to the top page of the Online Manual for your model and search for "Paper Sizes."

Note


• For some models, **Minimal Margin Printing** is displayed instead of **Borderless Printing**. When **Minimal Margin Printing** is displayed, printouts will have slight margins on the left and right sides.

Roll Paper Settings

When printing on roll paper, complete the following settings first.

1. In the task area, click Paper Options.


The view switches to the Paper Options screen.



2. In Page Size, select the page size of the poster.

Note

- Non-standard page sizes can be specified as well. For details, see <u>Specifying Non-Standard Page</u> <u>Sizes</u>.
- The poster page size is displayed in the status bar.



- 3. In Poster Orientation, select Portrait or Landscape.
- **4.** In **Printer**, select the printer to use.

>>> Important

- · Only printers compatible with PosterArtist are displayed in the list.
- Settings in Paper Options are automatically reflected in the printer driver.
- 5. In Media Source, select roll paper.
- 6. In Media Type, select the paper type for printing.

- · Supported paper types vary depending on your model.
- 7. In Roll Paper Width, select the width of roll paper loaded in printer.

>>> Important

- If the **Roll Paper Width** is different from the length of the long side or short side of the page, margins may be created. Printing is not possible if the settings would results in a portion of the image being cut off
- When roll paper is selected, the poster design being edited is printed with margins to prevent it from being cut off.
 - In the following cases, margins are not added to printouts.
- When printing without borders
- When printing without scaling, and the length of the long side or short side of the page matches the Roll
 Paper Width
- When printing to scale with Fit Long Side to Roll Width or Fit Short Side to Roll Width selected
 If the media size is larger than the selected roll paper width, a warning message appears before printing starts.

Printing Borderless Posters Filling the Entire Roll Paper Width

Print borderless posters filling the entire roll paper width.


 Complete the <u>roll paper settings</u>, and then select the Borderless Printing (or Minimal Margin Printing) checkbox.

>>> Important

- Depending on your model, you will need to prepare roll paper whose width and paper type support borderless printing.
- 2. Select the Enlarged/Reduced Printing checkbox.
- **3.** Select whether to fit the long side or short side of the page size to the roll paper width.


Fit Long Side to Roll Width:

The poster will be printed to scale so that the length of its long side will be the same as the width of the roll paper loaded in the printer. If the poster is in portrait orientation, the poster height will match the roll paper width.



Fit Short Side to Roll Width:

The poster will be printed to scale so that the length of its short side will be the same as the width of the roll paper loaded in the printer. If the poster is in portrait orientation, the poster width will match the roll paper width.



>>> Note

When Borderless Printing (or Minimal Margin Printing) is selected and the roll paper width
matches the length of the page size's long side or short side, you do not need to perform steps 2
and 3. The poster is printed filling the entire roll width automatically. To change the printing orientation
relative to the roll paper width, select the Enlarged/Reduced Printing checkbox, and then select Fit
Long Side to Roll Width or Fit Short Side to Roll Width.


Printing Bordered Posters Filling the Entire Roll Paper Width

Print bordered posters filling the entire roll paper width.

- Complete the <u>roll paper settings</u>, and then select the Enlarged/Reduced Printing checkbox.
- 2. Select whether to fit the long side or short side of the page size to the roll paper width.


Fit Long Side to Roll Width:

The poster will be printed to scale so that the length of its long side will be the same as the width of the roll paper loaded in the printer. If the poster is in portrait orientation, the poster height will match the roll paper width.



Fit Short Side to Roll Width:

The poster will be printed to scale so that the length of its short side will be the same as the width of the roll paper loaded in the printer. If the poster is in portrait orientation, the poster width will match the roll paper width.




Printing Without Borders on Three Sides

Print posters disregarding the roll paper width, without borders on three sides of the paper.

>>> Note

· After printing, trim the right edge of the paper.



- Complete the <u>roll paper settings</u>, and then select the Borderless Printing (or Minimal Margin Printing) checkbox.
- **2.** Specify as follows according to the preferred output size.

To print at page size:

Deselect the Enlarged/Reduced Printing checkbox.

To scale to media size:

Select the **Enlarged/Reduced Printing** checkbox, select **Fit in Printable Area**, and then specify **Media Size**.

>>> Important

· Printing without borders on three sides may not be available depending on your model.

Large-Format Printing

Print non-standard size posters such as horizontal or vertical banners filling the entire roll paper width without borders.

 Complete the <u>roll paper settings</u>, and then select the Borderless Printing (or Minimal Margin Printing) checkbox.

>>> Important

- Depending on your model, you will need to prepare roll paper whose width and paper type support borderless printing.
- 2. Select the Enlarged/Reduced Printing checkbox.
- 3. Select whether to fit the long side or short side of the page size to the roll paper width.

Fit Long Side to Roll Width:

The poster size is scaled so that the width (indicated by W in the figure) fills the width of the roll paper.



Fit Short Side to Roll Width:


The poster size is scaled so that the width (indicated by W in the figure) fills the width of the roll paper.



Printing Larger than Roll Paper Size

To print in a larger size than the roll paper, use Free Layout plus and freely adjust the layout before printing.

1. Complete the <u>roll paper settings</u>, and then select the **Edit layout with Free Layout plus** checkbox.



>>> Important

- This function may not be available depending on your model.
- This function is available only when the Free Layout plus application is installed.
- When you use this function, you cannot configure output media in PosterArtist. Specify the media size in Free Layout plus.

When Printing on Cut Sheets


1. In the task area, click Paper Options.

The view switches to the **Paper Options screen**.

2. In Page Size, select the page size of the poster.

>>> Note

- Non-standard page sizes can be specified as well. For details, see <u>Specifying Non-Standard Page</u>
 Sizes.
- The poster page size is displayed in the status bar.



- 3. In Poster Orientation, select Portrait or Landscape.
- **4.** In **Printer**, select the printer to use.

>>> Important

- Only printers compatible with PosterArtist are displayed in the list.
- Settings in Paper Options are automatically reflected in the printer driver.
- **5.** In **Media Source**, select source other than roll paper.

>>> Note

- · Supported paper sources vary depending on your model.
- **6.** In **Media Type**, select the paper type for printing.

Note

- · Supported paper types vary depending on your model.
- **7.** To print on cut sheets that are different in size from the page size, in **Media Size**, select the size of the paper to load in the printer.

>>> Note

- · Supported paper sizes vary depending on your model.
- For non-standard size posters, click **Set Custom Size...**. For details, see <u>Specifying Non-Standard Page Sizes</u>.

>>>> Important

• If the **Page Size** is larger than the **Media Size**, the poster may not be printed because portions around its edges will be cut off if printed. In that case, select the **Enlarged/Reduced Printing** checkbox, and then set

<u>/ 11 0 4</u> .		

to fit the entire poster within the printable area. For details, see When Printing Entire Poster Within Printable

When Printing to Scale

Print created posters in an enlarged or reduced scale.


1. In the task area, click Paper Options.

The view switches to the Paper Options screen.

2. In Page Size, select the page size of the poster.

>>> Note

- Non-standard page sizes can be specified as well. For details, see <u>Specifying Non-Standard Page</u> Sizes.
- The poster page size is displayed in the status bar.



- 3. In Poster Orientation, select Portrait or Landscape.
- **4.** In **Printer**, select the printer to use.

>>> Important

- · Only printers compatible with PosterArtist are displayed in the list.
- Settings in Paper Options are automatically reflected in the printer driver.
- **5.** In **Media Source**, select paper source.
- **6.** In **Media Type**, select the paper type for printing.

Note

- · Supported paper types vary depending on your model.
- 7. If Roll Paper is selected in Media Source, select the width of the roll paper loaded in the printer in Roll Paper Width.

- · Supported roll paper types vary depending on your model.
- 8. If Roll Paper is selected in Media Source, deselect the Borderless Printing (or Minimal Margin Printing) checkbox.
- 9. Select the Enlarged/Reduced Printing checkbox.
- 10. Click Scaling, and then specify scale for printing.

11. If **Cut Sheet** is selected in **Media Source**, select the size of the paper to load in the printer in **Media Size**.

>>> Note

- Supported paper sizes vary depending on your model.
- For non-standard size posters, click **Set Custom Size...**. For details, see <u>Specifying Non-Standard Page Sizes</u>.
- For some models, **Minimal Margin Printing** is displayed instead of **Borderless Printing**. When **Minimal Margin Printing** is displayed, printouts will have slight margins on the left and right sides.

When Printing Entire Poster Within Printable Area

When the page size is larger than the size of the paper loaded in the printer, reduce the scale to print the entire poster on the paper.


1. In the task area, click Paper Options.

The view switches to the **Paper Options screen**.

2. In Page Size, select the page size of the poster.

Note

- Non-standard page sizes can be specified as well. For details, see <u>Specifying Non-Standard Page</u>
 Sizes.
- The poster page size is displayed in the status bar.



- 3. In Poster Orientation, select Portrait or Landscape.
- 4. In **Printer**, select the printer to use.

>>> Important

- · Only printers compatible with PosterArtist are displayed in the list.
- Settings in Paper Options are automatically reflected in the printer driver.
- 5. In Media Source, select paper source.
- **6.** In **Media Type**, select the paper type for printing.

Note

- · Supported paper types vary depending on your model.
- 7. Select the Enlarged/Reduced Printing checkbox.
- 8. Click Fit in Printable Area.
- **9.** In **Media Size**, select the size of the paper to load in the printer.

Note

- Supported paper sizes vary depending on your model.
- For non-standard size posters, click Set Custom Size.... For details, see <u>Specifying Non-Standard</u>
 Page Sizes.


Note

• The poster will be printed in an appropriate orientation so that margins will be smaller.



Adding Crop Marks

Print crop marks in the margins of posters to indicate the cutting positions.



1. In the task area, click Paper Options.

The view switches to the Paper Options screen.

- 2. Specify Page Size, Poster Orientation, Printer, Media Source, Media Type, and other settings.
- 3. Select the Crop Marks checkbox.


>>> Important

- · Crop marks cannot be printed in the following cases.
- When performing borderless printing (or minimal margin printing)
- When printing on cut sheets without scaling with the same paper size set in Page Size and Media Size
- When printing on roll paper without scaling with the same size set in Page Size and Roll Paper Width

Specifying Non-Standard Page Sizes

Create non-standard size posters such as horizontal or vertical banners by specifying a page size of your choice.

Click **Paper Options** in the <u>task area</u>, click **Set Custom Size...**, and then in the <u>Set Custom Size dialog box</u>, enter the values in **Short Side** and **Long Side**.



- To set the same length for the poster's short side or long side as the roll paper width, click **Set to Roll Width**.
- When **Short Side** or **Long Side** is set, the value for the other is set automatically to maintain the aspect ratio. To change the aspect ratio, deselect the **Maintain Aspect Ratio** checkbox.
- For details on the **Set Custom Size** dialog box, see <u>Set Custom Size Dialog Box</u>.

Inserting Images and Materials

In PosterArtist, various photos, clipart and templates are available. These materials are referred to as "library."

Combine materials in the library as desired to create posters.

In addition, images saved on your computer or CD-ROMs as well as images from digital cameras or scanners can be directly inserted in posters.

You can also save inserted images to the library.

Inserting Images in Posters

Adding QR Codes

>>> Note

- Once images are inserted, modifying them in PosterArtist does not alter the original images.
- For supported image formats, see **Supported File Formats**.

Inserting Images in Posters

In addition to photos and clipart provided in the PosterArtist library, you can also insert your favorite images in posters.

Note

- Inserted images can be resized, rotated, moved, etc. as desired. For details, see Working with Objects.
 - ➡ Inserting from PosterArtist Library
 - ➡ Inserting from Computers or CD-ROMs
 - Inserting from Scanners and Other TWAIN Devices
 - ➡ Inserting from Scanners Using PosterArtist QuickCopy
 - ➡ Inserting from Digital Photo Front-Access
 - ➡ Inserting Print Images from Other Applications
 - Copying and Pasting from Other Applications

Inserting from PosterArtist Library

Insert templates and images from the PosterArtist library.

Note

- For instructions on inserting templates and images in posters, see the following.
 - Selecting Templates
 - Adding, Replacing and Removing Photos
 - Adding, Replacing and Removing Clipart

Inserting from Computers or CD-ROMs

1. Click **Edit** in the task area, and then click **Photos**.

The view switches to the Edit screen (Photos).

2. Click Add / Replace....

The Insert Image dialog box appears.

Note

- In the **Insert Image** dialog box, only files in formats supported by PosterArtist are displayed. For supported file formats, see <u>Supported File Formats</u>.
- 3. Select the image you want to add, and then click Open.

The image is inserted in the poster.

>>> Note

- You can also select multiple files at one time.
- To replace images, right-click an image on the poster, and then select **Replace Image > From File...**.

Inserting from Scanners and Other TWAIN Devices

Use a TWAIN device to insert images directly in posters.

>>> Important

- · Before acquiring images, check that the TWAIN device is connected correctly.
- For details on TWAIN device connection, driver installation, and screen operations, see the manual for the TWAIN device.
 - 1. From the Insert menu, select Add / Replace Image > Read from (Device Name)....

The screen for the TWAIN device appears.

2. Follow the instructions on the screen for the TWAIN device to acquire the image.

The acquired image is inserted in the poster.

Note

• Images can also be acquired from a TWAIN device when you right-click an image on the poster, and then select **Replace Image > Read from (Device Name)...**.

Inserting from Scanners Using PosterArtist QuickCopy

PosterArtist QuickCopy is an application to print enlarged copies of photos, documents, and other originals scanned with a scanner connected to a computer.

You can also send photos and documents scanned with a scanner to PosterArtist. Sent data is inserted in posters as a single image, and can be edited in the same way as other images.

Note

• For details on PosterArtist QuickCopy, see <u>Creating and Printing Enlarged Copies of Photos and</u> Documents.

Inserting from Digital Photo Front-Access

Use Digital Photo Front-Access to easily link photos from Canon digital cameras and other images on your computer with other applications.

Send images from Digital Photo Front-Access to PosterArtist as follows.

- 1. In Digital Photo Front-Access, select an image.
- **2.** Select the menu to start PosterArtist or drag and drop the image to the PosterArtist icon. The image is placed in PosterArtist's temporary tray.

Inserting Print Images from Other Applications

Send documents and graphs created with Microsoft Office or other applications from the printer driver to PosterArtist to insert them in posters.

>>> Important

- Requires installation of imagePROGRAF Printer Driver Ver. 3.50 or later.
 - 1. In application's menu, click Print.
 - 2. In the displayed dialog box, select printer, and then select Properties.

The printer driver's Properties dialog box appears.

- **3.** Click the **Layout** tab.
- 4. On the Layout tab, select the Page Layout checkbox, and then in the list, click Edit Using PosterArtist.
- **5.** In the Properties dialog box, click OK.
- 6. In the Print dialog box, click OK.

The Page Capture window appears, showing thumbnails of the print image.

Note

- · PosterArtist starts automatically even if it was not running.
- **7.** Select the page to send to PosterArtist, and then click **Load**.

Note

· To send all pages, click Select All.

You can also select multiple pages at one time.

The print image is sent to PosterArtist and inserted in the poster.

Copying and Pasting from Other Applications

Copy data (tables, graphs, etc.) created in other applications to paste into posters.

- **1.** In application, right-click object, and then click **Copy**.
- 2. Right-click anywhere in the poster design area, and then click Paste.

The object is pasted onto the center of the poster; move it as needed.

© CANON INC. 2024


Adding QR Codes

Add QR codes to posters.

Add QR codes to convey additional information that cannot be conveyed by a poster alone.

1. From the Insert menu, select Add / Replace Image > QR Code....

The QR code dialog box appears.



2. In QR code, enter text such as email address and URL, and then click OK.

The QR code is added to the poster. It can be placed as desired in the same way as other objects.

>>>> Important

- If a large number of characters is entered, a warning message may appear depending on the scanning device used. The approximate number of characters that can be entered in **QR code** is as follows.
- Numbers only: 513 characters or less
- Letters and numbers: 311 characters or less
- The number of characters that can be entered in a single QR code is as follows.
- Numbers only: 7089 characters or less
- Letters and numbers: 4296 characters or less

Editing Photos

- > Adding, Replacing and Removing Photos
- ➤ Trimming Photos
- ➤ Applying Gradation to Photos
- ➤ Applying Transparency to Photos (Opacity)
- ➤ Correcting Slant
- ➤ Applying Frames to Photos

Adding, Replacing and Removing Photos

Add photos from the library to your poster or replace a photo on your poster with another photo.

- Adding Photos
- Replacing Photos
- Removing Photos

Use the temporary tray to add or replace photos easily.

➡ Using Temporary Tray when Editing Photos

Adding Photos

1. Click Edit in the task area, and then click Photos.

The view switches to the Edit screen (Photos).

- 2. Click the Photos tab.
- 3. In Category, select a photo category.
- 4. Select a photo from the thumbnails, and then double-click it.

The selected photo is added to the poster.

Note

- Selected photos can also be added by dragging and dropping them to the poster design area.
- · Alternatively, right-click a photo in the thumbnails, and then click Insert to Poster to add it.
- · Added images can be resized, rotated, moved, etc. as desired. For details, see Working with Objects.

Replacing Photos

- **1.** On the poster, click the photo you want to replace.
- 2. Click the Photos tab.
- 3. Select a photo from the thumbnails, and then double-click it.

The photo on the poster is replaced with the new one.

- Alternatively, right-click a photo in the thumbnails, and then click Replace to replace the photo on the
 poster with the new photo.
- Photos can also be replaced with other photos, for example from folders on your computer or from a scanner. For details, see Inserting Images in Posters.

Removing Photos

- **1.** On the poster, click the photo you want to remove.
- 2. Press the Delete key.

The selected photo is removed from the poster.



• Even after removing photos from the poster, the original photos remain on your computer.

Using Temporary Tray when Editing Photos

Place photos you are not sure whether to use or frequently used photos in the temporary tray.

- ➡ Adding Photos to Temporary Tray from Thumbnails
- ➡ Adding Photos to Temporary Tray from View All Photos Dialog Box
- ➡ Adding Photos to Posters from Temporary Tray

Adding Photos to Temporary Tray from Thumbnails

1. Click Edit in the task area, and then click Photos.

The view switches to the Edit screen (Photos).

- 2. Click the Photos tab.
- **3.** In **Category**, select a photo category.
- **4.** Select the photo you want to add from the thumbnails, and then drag and drop it to the temporary tray.

The selected photo is added to the temporary tray.



• Alternatively, right-click a photo in the thumbnails, and then click Add to Temporary Tray to add it.

Adding Photos to Temporary Tray from View All Photos Dialog Box

1. Click Edit in the task area, and then click Photos.

The view switches to the Edit screen (Photos).

- 2. Click the Photos tab.
- 3. Click (View All Photos).

The View All Photos dialog box appears.

- 4. In Category, select a photo category.
- Select the photo you want to add from the thumbnails, and then click Add to Temporary Tray.

The selected photo is added to the temporary tray.

>>> Note

- To show or hide the temporary tray, click (Arrow) on the right (or at the bottom if the poster is in landscape orientation).
- Photos can also be added directly to the temporary tray by dragging and dropping them from folders on your computer. For supported file formats, see <u>Supported File Formats</u>.
- To remove photos from the temporary tray, select one and press the Delete key. Even after removing photos from the temporary tray, the original photos remain on your computer.

Adding Photos to Posters from Temporary Tray

1. Drag and drop a photo from the temporary tray to the poster.


The photo is added to the poster.

>>> Note

• To replace a photo on the poster with another photo in the temporary tray, select the photo on the poster, and then drag and drop a photo from the temporary tray to the photo on the poster.

Trimming Photos

Select the area you want to keep in a photo and discard the rest.



1. Click Edit in the task area, and then click Photos.

The view switches to the Edit screen (Photos).

- 2. On the poster, click the photo you want to trim.
- 3. In Edit Image, click (Trim)


The **Edit Image** dialog box and preview panel appear.

4. Drag + (Crosshair pointer) across the portion you want to keep.

The portion inside the orange frame will be retained, and the portion outside will be hidden.



• To remove trimming, in the **Edit Image** dialog box, click **Reset Trim**.



- To resize the orange frame for the trimming area, drag \(^{\subset}\) (Resize handle) in the corners.
- To move the orange frame for the trimming area, drag (Move pointer) that appears when you point inside the frame.
- To change the frame orientation from portrait to landscape and vice versa, rotate the orange frame by clicking \bigcirc (Rotation handle).

>>> Important

• Trimming is canceled if the photo is replaced with another photo.

>>> Note

• For details on the Edit Image dialog box, see Edit Image Dialog Box (Trim).

Applying Gradation to Photos

Apply a gradation to photos. Specify the direction of the gradation, opacity of the starting point and ending point, etc. as desired.

1. Click Edit in the task area, and then click Photos.

The view switches to the Edit screen (Photos).

- **2.** On the poster, click the photo to which you want to apply a gradation.
- 3. In Edit Image, click (Gradation).


The **Edit Image** dialog box and preview panel appear.

- **4.** In **Gradation Orientation**, select the direction of the gradation.
- **5.** In the preview panel, select the starting point and ending point of the gradation.

Applying gradation with midpoints:

Gradations can be more variable by using midpoints.

1. In Number of Points in Gradation, click Three Points.



In the preview, midpoints (C1 and C2) appear between the starting point (A) and ending point (B).

2. For Point A Opacity, Point B Opacity, and Point C Opacity, enter the value directly or click ∧ (Up Arrow) or ∨ (Down Arrow) on the right to increase or decrease the value.

The gradation level is set.



- Increase the value to increase opacity and decrease the value to increase transparency.
- 3. In the preview, drag the starting point (A), ending point (B), and midpoints (C1 and C2).


This will set the direction of the gradation.

>>> Note

• To adjust the spacing, move the midpoints (C1 and C2) on the line connecting the starting point (A) and ending point (B).

Applying gradation without midpoints:

1. In Number of Points in Gradation, click Two Points.



In the preview, the starting point (A) and ending point (B) appear.

2. For Point A Opacity and Point B Opacity, enter the value directly or click ∧ (Up Arrow) or ∨ (Down Arrow) on the right to increase or decrease the value.

The gradation level is set.

>>> Note

- Increase the value to increase opacity and decrease the value to increase transparency.
- **3.** In the preview, drag the starting point (A) and ending point (B). This will set the direction of the gradation.

- To remove the gradation, in the Edit Image dialog box, click the selected Gradation Orientation again.
- For details on the Edit Image dialog box, see Edit Image Dialog Box (Gradation).

Applying Transparency to Photos (Opacity)

Apply transparency to make photos translucent.

1. Click Edit in the task area, and then click Photos.

The view switches to the Edit screen (Photos).

- **2.** On the poster, click the photo to which you want to apply transparency.
- 3. In Edit Image, click (Gradation)

The **Edit Image** dialog box and preview panel appear.

- 4. Click (Set Opacity to Background).
- **5.** In **Opacity**, enter the value directly or click \land (Up Arrow) or \land (Down Arrow) on the right to increase or decrease the value.

The opacity is set for the photo.

>>> Note

• To increase opacity, increase the value.



· To increase transparency, decrease the value.



- To remove transparency, in the **Edit Image** dialog box, click (Set Opacity to Background) again.
- For details on the Edit Image dialog box, see Edit Image Dialog Box (Gradation).

Correcting Slant

Correct slant of photos automatically, manually, or by specifying an angle.

1. Click **Edit** in the <u>task area</u>, and then click **Photos**.

The view switches to the Edit screen (Photos).

- 2. On the poster, click the photo for which you want to correct slant.
- 3. In Edit Image, click (Trim)

The **Edit Image** dialog box and preview panel appear.

- 4. Click (Slant Correction).
- 5. Select a correction method.


Correcting automatically:

- 1. In Slant Correction Method, click Auto.
- 2. Using (Slant Correction pointer), click the line (horizon, pillar, etc.) you want to make horizontal or vertical.

A green line appears, and the slant is corrected so that the line is horizontal or vertical.

>>> Important

• To correct slant more than 5 degrees in either direction, select **Specify Angle** in **Slant Correction Method**, and then enter the value directly in **Offset Angle** or click ∧ (Up Arrow) or ∧ (Down Arrow) on the right to increase or decrease the value.



· Slant cannot be corrected unless a line is detected.

Correcting manually:

- 1. In Slant Correction Method, click Manual.
- 2. Drag the photo in the preview to adjust slant.

Correcting by specifying an angle:

- 1. In Slant Correction Method, click Specify Angle.
- 2. In Offset Angle, enter a value between -45.0 and 45.0 or click ∧ (Up Arrow) or ∧ (Down Arrow) on the right to increase or decrease the value.

>>>> Important

- When slant is corrected, trimming is performed automatically according to the specified angle.
- Slant correction is canceled if the photo is replaced with another photo.

>>> Note

- To cancel slant correction, in the Edit Image dialog box, click Reset Slant Correction.
- For details on the Edit Image dialog box, see Edit Image Dialog Box (Slant Correction).

Applying Frames to Photos

1. Click Edit in the task area, and then click Photos.

The view switches to the Edit screen (Photos).

- 2. Click the Frames tab.
- 3. On the poster, click the photo to which you want to apply a frame.
- **4.** In **Category**, select a frame category.
- **5.** Select a frame from the thumbnails, and then double-click it.

The frame is applied to the photo.

Changing frame colors:

- 1. On the poster, click a photo to which a frame is applied.
- 2. In Frame Color, select the color you want to use.

>>> Important

- Some frame colors cannot be changed, depending on the frame design. Frame colors can only be changed when **Frame Color** is selectable.
- The new color may only be applied to some portions of the frame, depending on the frame design.

Note

• In **Frame Color**, the current frame color and basic colors are displayed. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.

Removing photo frames:

- 1. On the poster, click a photo to which a frame is applied.
- 2. Select No Frame from the thumbnails, and then double-click it.

The frame is removed from the photo.

>>> Important

· Frames cannot be applied to clipart.

Editing Clipart

- ➤ Adding, Replacing and Removing Clipart
- ➤ Changing Clipart Colors

Adding, Replacing and Removing Clipart

Add clipart from the library to your poster or replace clipart on your poster with other clipart.

- Adding Clipart
- → Replacing Clipart
- Removing Clipart

Use the temporary tray to add or replace clipart easily.

➡ Using Temporary Tray when Editing Clipart

Adding Clipart

1. Click Edit in the task area, and then click Clipart.

The view switches to the Edit screen (Clipart).

- 2. In Category, select a clipart category.
- 3. Select clipart from the thumbnails, and then double-click it.

The selected clipart is added to the poster.

Note

- The selected clipart can also be added by dragging and dropping it to the poster design area.
- · Alternatively, right-click clipart in the thumbnails, and then click Insert to Poster to add it.
- Added clipart can be resized, rotated, moved, etc. as desired. For details, see Working with Objects.

Replacing Clipart

- 1. On the poster, click the clipart you want to replace.
- 2. Select clipart from the thumbnails, and then double-click it.

The clipart on the poster is replaced with the new one.



Alternatively, right-click clipart in the thumbnails, and then click Replace to replace the clipart on the
poster with the new clipart.

Removing Clipart

- **1.** On the poster, click the clipart you want to remove.
- 2. Press the Delete key.

The selected clipart is removed from the poster.

Using Temporary Tray when Editing Clipart

Place clipart you are not sure whether to use or frequently used clipart in the temporary tray.

- → Adding Clipart to Temporary Tray from Thumbnails
- → Adding Clipart to Temporary Tray from View All Clipart Dialog Box
- Adding Clipart to Posters from Temporary Tray

Adding Clipart to Temporary Tray from Thumbnails

1. Click Edit in the task area, and then click Clipart.

The view switches to the Edit screen (Clipart).

- 2. In Category, select a clipart category.
- **3.** Select the clipart you want to add from the thumbnails, and then drag and drop it to the temporary tray.

The selected clipart is added to the temporary tray.



• Alternatively, right-click clipart in the thumbnails, and then click Add to Temporary Tray to add it.

Adding Clipart to Temporary Tray from View All Clipart Dialog Box

1. Click Edit in the task area, and then click Clipart.

The view switches to the Edit screen (Clipart).

2. Click (View All Clipart).

The View All Clipart dialog box appears.

- 3. In Category, select a clipart category.
- Select the clipart you want to add from the thumbnails, and then click Add to Temporary
 Tray.

The selected clipart is added to the temporary tray.



- To show or hide the temporary tray, click (Arrow) on the right (or at the bottom if the poster is in landscape orientation).
- Clipart can also be added directly to the temporary tray by dragging and dropping it from folders on your computer. For supported file formats, see <u>Supported File Formats</u>.

• To remove clipart from the temporary tray, select clipart and press the Delete key. Even after removing clipart from the temporary tray, the original clipart remains on your computer.

Adding Clipart to Posters from Temporary Tray

1. Drag and drop clipart from the temporary tray to the poster.

The clipart is added to the poster.

>>> Note

• To replace clipart on the poster with another clipart in the temporary tray, select the clipart on the poster, and then drag and drop clipart from the temporary tray to the clipart on the poster.

Changing Clipart Colors

1. Click Edit in the task area, and then click Clipart.

The view switches to the Edit screen (Clipart).

- 2. On the poster, click the clipart you want to replace.
- 3. In Clipart Color, select the color you want to use, and then double-click it.

The selected color is applied to the clipart on the poster.

Important

- Clipart colors can only be changed when **Clipart Color** is selectable.
- The new color may only be applied to some portions of the clipart, depending on the clipart design.
- For clipart, Trim, Gradation, Slant Correction, Opacity and Retouch Image are not available.

>>> Note

- In **Clipart Color**, the current clipart color and basic colors are displayed. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.
- Elements of clipart in the **Stamps** category are grouped. To change the color or shape of such clipart, right-click it in the poster design area, and then select **Group > Ungroup** to ungroup.

Retouching Images

Correct photo color levels. Apply effects to create a particular mood in photos. Adjust the colors, and use other retouching features to enhance your posters.

Note

- · The following images are supported.
- Images in the photo library (except those with transparent backgrounds)
- Uncompressed TIFF, JPEG, or BMP images you have added to the poster, with the long side measuring
 7200 pixels or less and the aspect ratio less than or equal to 64:1
 - 1. Click Edit in the task area, and then click Photos.

The view switches to the Edit screen (Photos).

- 2. On the poster, click the photo you want to retouch.
- 3. In Edit Image, click (Retouch Image).

The Retouch Image dialog box appears.

4. Select the type of retouching required.

For details, see the corresponding page.

If you click the following buttons, images are retouched instantly and you can check the retouched image.

- Auto Color Correction
- → Monochrome/Sepia

If you click the following buttons, a dialog box appears for making manual adjustments. After applying the adjustments, you can check the retouched image.

- Color Adjustment
- Color Point Correction
- Backlight Correction
- → Sharpness
- ➡ Soft Focus
- ➡ Logo Color Adjustment
- Cut Out
- 5. Click OK.

The image is retouched.

>>> Important

- Even if you retouch an image, the original image itself is not retouched.
- · Clipart cannot be retouched.

Auto Color Correction

Automatically retouch image color levels.

1. In the Retouch Image dialog box, click Auto Color Correction.

The colors are automatically retouched.

>>> Note

• If Auto Color Correction does not produce the desired results, in the **Retouch Image** dialog box, click **Color Point Correction**, and then adjust the colors. For details, see <u>Color Point Correction</u>.

Color Adjustment

Manually retouch image color levels.

1. In the Retouch Image dialog box, click Color Adjustment.

The Color Adjustment dialog box appears.

Under **Original Image**, the original image is displayed and under **Touched Up Image**, the retouched image is displayed.

2. Adjust the Quality and Color Settings as you check the image.



- To enlarge or reduce the view magnification, click (Zoom In) or (Zoom Out). You can also specify the magnification in the drop-down list.
- To restore the original image, click Reset.

3. Click OK.

Color Point Correction

Adjust the overall brightness based on the brightest point in the image (white point), the point of intermediate brightness (gray point), or the darkest point (black point).

1. In the Retouch Image dialog box, click Color Point Correction.

The Color Point Correction dialog box appears.

Under **Original Image**, the original image is displayed and under **Touched Up Image**, the retouched image is displayed.

2. Click the desired brightness for White Point, Gray Point, and Black Point.

>>> Note

- Click Auto to produce the same results as Auto Color Correction in the Retouch Image dialog box.
- To enlarge or reduce the view magnification, click (Zoom In) or (Zoom Out). You can also specify the magnification in the drop-down list.
- To restore the original image, click Reset.

3. Click OK.

Backlight Correction

Correct backlight scenes in which the image is too dark or the background is too bright.

1. In the Retouch Image dialog box, click Backlight Correction.

The Backlight Correction dialog box appears.

Under **Original Image**, the original image is displayed and under **Touched Up Image**, the retouched image is displayed.

2. Adjust the Level as you check the image.

>>>> Note

- If the photo includes people, click Auto Adjust For Faces for automatic adjustment.
- To enlarge or reduce the view magnification, click (Zoom In) or (Zoom Out). You can also specify the magnification in the drop-down list.
- · To restore the original image, click Reset.

3. Click OK.

Sharpness

Sharpen image edges.

1. In the Retouch Image dialog box, click Sharpness.

The **Sharpness dialog box** appears.

Under **Original Image**, the original image is displayed and under **Touched Up Image**, the retouched image is displayed.

2. Adjust the Level as you check the image.



- To enlarge or reduce the view magnification, click (Zoom In) or (Zoom Out). You can also specify the magnification in the drop-down list.
- To restore the original image, click **Reset**.

3. Click OK.

Soft Focus

Blur images to create a softer effect.

1. In the Retouch Image dialog box, click Soft Focus.

The Soft Focus dialog box appears.

Under **Original Image**, the original image is displayed and under **Touched Up Image**, the retouched image is displayed.

2. Adjust the Level as you check the image.



- To enlarge or reduce the view magnification, click (Zoom In) or (Zoom Out). You can also specify the magnification in the drop-down list.
- To restore the original image, click Reset.

3. Click OK.

Monochrome/Sepia

Convert images to monochrome or sepia to create moody photos.

1. In the Retouch Image dialog box, click Monochrome or Sepia.

The image is converted to monochrome or sepia.

Logo Color Adjustment

Adjust a portion of the logo image colors.

1. In the Retouch Image dialog box, click Logo Color Adjustment.

The Logo Color Adjustment dialog box appears.

Under **Original Image**, the original image is displayed and under **Touched Up Image**, the retouched image is displayed.

- 2. Under Color Table or Original Image, click the color you want to adjust.
- **3.** Adjust the levels in **Color Settings**, **Hue**, **Saturation**, and **Luminance** as you check the image in **Touched Up Image**.




- To enlarge or reduce the view magnification, click (Zoom In) or (Zoom Out). You can also specify the magnification in the drop-down list.
- To restore the original image, click Reset.
- 4. Click OK.

The logo is adjusted.

Cut Out

Use the Cut Out function to isolate the area you want to keep in a photo and discard the rest such as the background.

You can cut out images automatically or manually. Even though the results of automatic cut-outs are sufficiently attractive, you can also manually specify the exact details of what you want to cut out.



1. In the Retouch Image dialog box, click Cut Out.

The Cut Out dialog box appears.

2. On the Auto tab, click Auto.

The background is automatically erased.

>>> Note


- Alternatively, move the mouse pointer over the image to display a crosshair pointer, and then drag the cursor around the area to retain.
- To blur the edges of cut out portions, select the Blur edge checkbox.
- To adjust the extent of the area to retain, change the value in Tolerance, and then click Auto again.

To erase a larger area, select a smaller value (because fewer colors are judged similar).

To retain a larger area, select a larger value (because more colors are judged similar).

Note

• To view the original image that has not been cut out, click **Preview**. Preview is canceled and the area to be cut out is shaded in the color displayed in **color of area remain** (indicated in blue in the figure below). Adjust the settings as you compare the original image and the cut out image by clicking **Preview**.



4. Repeat step 3 to specify the area to retain, and then click **OK**.

The image is cut out.

If automatic cut-out is unsatisfactory - if unneeded portions remain in the cut out image or if too much is erased - try using the tools on the **Manual** tab.

- 5. Click the Manual tab.
- 6. Use the cut-out tools to specify the area to retain and the area to erase in great detail.

>>> Note

- It may be easier to work with the tools on the **Manual** tab if you enlarge the view by clicking (Zoom In).
- For details on the cut-out tools, see Cut Out Dialog Box.

7. Click OK.

The image is cut out.

>>>> Note

• If it is easier to specify the area to erase than to specify the area to retain, specify the area to erase instead. On the **Manual** tab, click **Invert Selection** to switch the area to erase and area to retain.

Editing Shapes

- ➤ Adding and Removing Shapes
- ➤ Changing Shape Styles

Adding and Removing Shapes

Add straight lines, rectangles, circles, ellipses, and other shapes to posters.


- → Adding Shapes
- ➡ Removing Shapes

Adding Shapes

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

2. Click one of the following buttons to select a shape.





Add circles or ellipses.

3. Drag + (Crosshair pointer) to specify the size of the shape you want to add.



The shape is added in the specified size.



• You can freely resize, rotate, or move the shapes you added. For details, see Working with Objects.

Removing Shapes

- **1.** On the poster, click the shape you want to remove.
- 2. Press the Delete key.

The selected shape is removed from the poster.

Changing Shape Styles

Change the style of shapes added to your poster.

>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the Edit layout with Free Layout plus checkbox is selected
 in the Paper Options screen.
 - Resizing Shapes
 - → Changing Line Thickness
 - → Applying Transparency to Shapes
 - Changing Line Types
 - Changing Line Colors
 - Specifying Drop Shadows for Shapes
 - ➡ Specifying Shape Colors
 - Changing Rectangle Corner Shapes
 - Changing Types of Line Ends
 - → Resizing Arrows

Resizing Shapes

Change the size of shapes.

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

- 2. Click a shape on poster.
 - (Resize handle) appears on the selected shape.
- 3. Drag (Resize handle).

Note

You can resize lines without changing their angles and center points. You can also resize rectangles
without changing their aspect ratios and center points. For details, see Moving, Enlarging, Reducing,
and Rotating Objects.

Changing Line Thickness

Change the line thickness of shapes.

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

2. Click a shape on poster.

3. In Line Thickness, specify thickness (pt).

Note

Enter a value (1.00 to 500.00) directly in Line Thickness. Alternatively, click ∧ (Up Arrow) or ∨ (Down Arrow) on the right to increase or decrease the value.

Applying Transparency to Shapes

Adjust the opacity to apply transparency to shapes.

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

- 2. Click a shape on poster.
- **3.** In **Opacity**, specify the opacity (%) of the shape.

>>> Note

- Enter a value (100 to 0) directly in **Opacity**. Alternatively, click ∧ (Up Arrow) or ∨ (Down Arrow) on the right to increase or decrease the value.
- To decrease opacity (increase transparency), decrease the value.
- To increase opacity (decrease transparency), increase the value.

Changing Line Types

Change the shape line to a dashed or dotted line.

1. Click **Edit** in the <u>task area</u>, and then click **Shapes**.

The view switches to the Edit screen (Shapes).

- 2. Click a shape on poster.
- 3. In Line Type, select line type.

Changing Line Colors

Change the line color of shapes.

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

- 2. Click a shape on poster.
- **3.** When a rectangle, circle, or ellipse is selected, select the **Line Color** checkbox.


4. In Line Color, click on a color.



• In **Line Color**, the current color and basic colors are displayed. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.

Specifying Drop Shadows for Shapes

Add drop shadows of several types to shapes.




1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).


- 2. Click a shape on poster.
- 3. Click (Drop Shadow).

The **Set Shadow** dialog box appears.



- 4. Select the Drop Shadow checkbox.
- **5.** To change the shadow color, click **Custom...**, **Change to Spot Color...**, or **Change to Regular Color...** in **Color**, and then select a color in the displayed dialog box.
- 6. Specify Distance, Angle, and Opacity.

Enter the value directly or click \land (Up Arrow) or \lor (Down Arrow) on the right to increase or decrease the value.



7. Click Apply.

The drop shadow is applied to the shape on the poster. Continue adjusting the settings and clicking **Apply** until the drop shadow appears as desired.

8. Click OK.

>>> Important

· Shadows cannot be softened when a fluorescent spot color is specified for the drop shadow color.

Note

- To soften the shadow, select the Fade Shadows checkbox, and then specify the Radius.
- To soften shadows more, increase the value.
- To emphasize shadows, decrease the value.
- The effect can be checked in **Preview**.
- To remove the shadow, deselect the **Drop Shadow** checkbox.

Specifying Shape Colors

Fill shapes with colors or change the colors.

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

- **2.** Click a rectangle, circle, or ellipse on poster.
- 3. Select the Fill-in Color checkbox.
- 4. In Fill-in Color, select color.

Note

• In **Fill-in Color**, the current color and basic colors are displayed. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.

Changing Rectangle Corner Shapes

Change the rectangle corner shape to a round or square shape.

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

- 2. Click a rectangle on poster.
- 3. In Corner Shape, select corner shape.

Note

- When the round shape is selected, enter a value directly in **Radius** to adjust the roundness.
 Alternatively, click \(\text{(Up Arrow)} \) or \(\text{(Down Arrow)} \) on the right to increase or decrease the value.
- To increase roundness, increase the value.
- To decrease roundness, decrease the value.
- The range of values that can be specified in **Radius** varies depending on the rectangle size.

Changing Types of Line Ends

Turn lines into arrows or vice versa by changing the shapes of the starting and ending points of lines. Arrowheads can also be changed to circles or rectangles.

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

- 2. Click a line (or arrow) on poster.
- 3. In Start Point Shape, select the starting point shape.
- **4.** In **End Point Shape**, select the ending point shape.

Resizing Arrows

Change the size of arrowheads.

1. Click Edit in the task area, and then click Shapes.

The view switches to the Edit screen (Shapes).

- **2.** Click an arrow on poster.
- $\textbf{3.} \ \ \textbf{In Size} \ \ \textbf{for the starting point, select Small, Medium, or Large}.$
- **4.** In **Size** for the ending point, select **Small**, **Medium**, or **Large**.

Editing Text

Add text to posters or edit text on posters.

Decorate text by applying a drop shadow or text graphic.

Note

· Use text boxes or editing boxes.

Text box (framed in orange):

When you click text on a poster, an orange frame appears around the text. Change the text format (font, text style, etc.) here.



Editing box (framed in blue):

When you double-click text on a poster, a blue frame appears around the text. Add text here.



- Adding, Changing, and Removing Text
- ➤ Changing the Text Format
- Applying Text Graphics

Adding, Changing, and Removing Text

Add or change text on posters.

- Adding Text
- Changing Text
- Removing Text

Adding Text

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

2. Click (Horizontal Text) or (Vertical Text) to select the text orientation.

>>> Important

- · Vertical text may not be available for your language.
- On the poster, drag to select the area where you want to add text.An editing box appears.
- **4.** Enter text in the editing box.



You can also insert line breaks.

5. Click outside the editing box.

Check the appearance and position of the text on the poster.

>>> Note

- The font type, font size, font color, etc. can be changed as desired. For details, see <u>Changing the</u> Text Format.
- To wrap text at the end of a line automatically, select the **Word Wrap** checkbox.
- To add multilingual text, click [Add Translation Template] on the toolbar or right-click an editing box and select **Add Translation Template**. For details, see <u>Using Translation Templates</u>.

Changing Text

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

2. Right-click text on poster, and then click Edit.

An editing box appears.

>>> Note

- Alternatively, double-click the text to display the editing box.
- 3. Change text in the editing box.
- **4.** Click outside the editing box.

Check the changed text on the poster.

Removing Text

1. Click **Edit** in the <u>task area</u>, and then click **Text**.

The view switches to the Edit screen (Text).

2. Right-click text on poster, and then click **Delete**.

The text is removed.

>>> Note

· Alternatively, click the text and press the Delete key to remove it.

Changing the Text Format

Change the format of text entered on your poster.

>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the Edit layout with Free Layout plus checkbox is selected
 in the Paper Options screen.
 - Changing the Font
 - Resizing Text
 - Aligning Text to the Left, Center, or Right
 - Justifying Text
 - ➡ Changing Kerning and Line Spacing
 - Changing the Text Color
 - ➡ Specifying the Text Style
 - Outlining Text
 - Specifying Drop Shadows for Text
 - Outlining and Drop Shadow Examples

Changing the Font

Change the font (typeface).

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

- 2. Click text on poster.
- 3. In Font, select font.

Note

- Font names in the **Font** list are displayed in the actual font.
- To change the font of a single character or text block, right-click text on the poster and click **Edit**, or double-click text to display an editing box, and then drag the character or text block you want to change to specify the font.

Resizing Text

Change the size of text.

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

2. Click text on poster.

3. In Font Size, select font size.

Note

- You can also enter a value (6 to 5000) directly in Font Size.
- Another way to enlarge or reduce text is to drag (Resize handle) displayed on the text box. For details, see Moving, Enlarging, Reducing, and Rotating Objects.

Aligning Text to the Left, Center, or Right

Specify how to align text.

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

- 2. Click text on poster.
- 3. In Text Alignment, select (Left Align), (Center Align), or (Right Align).



Justifying Text

Position the text evenly across the text box so that all rows are as long as the longest row.



Note

- Justification can be set only when a text box (framed in orange) is displayed.
 - 1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

2. Click text on poster.

3. Under Text Alignment, click (Justify).

Changing Kerning and Line Spacing

Widen or narrow the space between characters or between lines.

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

- 2. Click text on poster.
- 3. In Line Spacing, select line spacing.
- 4. In Character Spacing, set character spacing.

>>> Note

• Enter a value (-1000.00 to 1000.00) directly in **Character Spacing**. Alternatively, click ∧ (Up Arrow) or ∨ (Down Arrow) on the right to increase or decrease the value.

Changing the Text Color

Change the text color.

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

- 2. Click text on poster.
- 3. In Text Color, click on a color.

Note

- In **Text Color**, the current color and basic colors are displayed. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.
- To change the color of a single character or text block, right-click text on the poster and click Edit, or double-click text to display an editing box, and then drag the character or text block you want to change to specify the color.

Specifying the Text Style

Specify the text style (bold, italic, or underline).

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

- 2. Click text on poster.
- 3. In **Text Style**, select B (Bold), (Italic), or U (Underline).

Multiple styles can be specified to the text.

>>> Note


• To change the style of a single character or text block, right-click text on the poster and click **Edit**, or double-click text to display an editing box, and then drag the character or text block you want to change to specify the style.

Outlining Text

Outline the text. The text will be enhanced on the poster.

- 1. Click Edit in the task area, and then click Text.
 - The view switches to the Edit screen (Text).
- 2. Click text on poster.
- 3. In Text Effects, click (Fill and Stroke).

The Fill and Stroke dialog box appears.



Note

• In **Text Color**, the color specified in the settings panel in the <u>Edit screen (Text)</u> is reflected. To change the text color, click **Custom...**, **Change to Spot Color...**, or **Change to Regular Color...**, and then select a color in the displayed dialog box.

- 4. Select the Inner Stroke checkbox.
- 5. In Width, specify the width of the outline.

>>> Note

- Enter a value (0.10 to 100.00) directly. Alternatively, click ∧ (Up Arrow) or ∨ (Down Arrow) on the right to increase or decrease the value.
- 6. In Corner Shape, select Round, Square, or Bevel.
- 7. Specify Color of the outline.
- 8. Click Apply.

The text on the poster is outlined. Continue adjusting the settings and clicking **Apply** until the outlined text appears as desired.

9. Click OK.

Note

- To apply a double outline, select the **Outer Stroke** checkbox and repeat steps 5-7.
- · The effect can be checked in Preview.
- To remove the outline, deselect the Inner Stroke or Outer Stroke checkbox.
- To outline a single character or text block, right-click text on the poster and click **Edit**, or double-click text to display an editing box, and then drag the character or text block you want to outline.

Specifying Drop Shadows for Text


Add drop shadows of several types to text. The text will appear as if it is floating over the poster.

1. Click **Edit** in the <u>task area</u>, and then click **Text**.

The view switches to the Edit screen (Text).

- 2. Click text on poster.
- 3. In Text Effects, click (Shaded Text).

The Set Shaded Text dialog box appears.




4. Select the Drop Shadow checkbox.

To change the shadow color, click **Custom...**, **Change to Spot Color...**, or **Change to Regular Color...** in **Color**, and then select a color in the displayed dialog box.

5. Specify Distance, Angle, and Opacity.

Enter the value directly or click \land (Up Arrow) or \lor (Down Arrow) on the right to increase or decrease the value.



>>>> Important

• Opacity cannot be set when a fluorescent spot color is specified for the drop shadow color.

6. Click Apply.

The drop shadow is applied to the text on the poster. Continue adjusting the settings and clicking **Apply** until the drop shadow appears as desired.

7. Click OK.

>>> Important

· Shadows cannot be softened when a fluorescent spot color is specified for the drop shadow color.

Note

- To soften the shadow, select the **Fade Shadows** checkbox, and then specify the **Radius**.
- To soften shadows more, increase the value.
- To emphasize shadows, decrease the value.
- The effect can be checked in Preview.
- To remove the shadow, deselect the **Drop Shadow** checkbox.
- To apply a drop shadow to a single character or text block, right-click text on the poster and click **Edit**, or double-click text to display an editing box, and then drag the character or text block to which you want to apply a drop shadow.

Outlining and Drop Shadow Examples

Use outlining and drop shadows to decorate text in various ways.

Example of outlined text



Example of settings in the Fill and Stroke dialog box

Text Color		
Color	Black	
Inner Stroke		
Width	6 mm (0.25 in.)	
Corner Shape	Round	
Color	White	
Outer Stroke		
Width	6 mm (0.25 in.)	
Corner Shape	Round	
Color	Black	

Example of drop shadow



Example of settings in the **Set Shaded Text** dialog box

Drop Shadow	
Color	Black
Distance	21 mm (0.8 in.)
Angle	90 degrees
Opacity	10%

Example of outlining combined with drop shadow



Example of settings in the Fill and Stroke and Set Shaded Text dialog boxes

Text Color		
Color	White	
Inner Stroke		
Width	2 mm (0.07 in.)	
Corner Shape	Round	
Color	Black	
Drop Shadow		
Color	Gray	
Distance	3 mm (0.10 in.)	
Angle	135 degrees	
Opacity	50%	

Applying Text Graphics

Decorate text with floral illustrations, apply graphics to transform text into tags or speech callouts, and more, and customize text graphic colors.

1. Click Edit in the task area, and then click Text.

The view switches to the Edit screen (Text).

- 2. Click text in the poster design area.
- 3. Click Text Graphics.
- **4.** In **Category**, select a text graphic category.
- 5. Select a text graphic from the thumbnails, and then double-click it.



- To view all text graphics, click (View All Text Graphics) for displaying the View All Text Graphics dialog box.
- Change text graphic colors from **Text Graphic Color** or **Custom...** as needed.
- To remove the text graphic, select a blank thumbnail and double-click it.

Editing Backgrounds

- ➤ Adding Backgrounds
- ➤ Setting Background Image
- ➤ Specifying Background Margins

Adding Backgrounds

Select a single image in the library to set it as the background.

1. Click **Edit** in the <u>task area</u>, and then click **Backgrounds**.

The view switches to the Edit screen (Backgrounds).

- 2. In Category, select a background category.
- 3. Select a background from the thumbnails, and then double-click it.

The selected background is inserted in the poster.

4. To change the background color, click a color in **Background Color**.

>>> Note

- To remove the background, select No Background in Category, and then double-click the No Background thumbnail.
- To use colors other than those displayed in **Background Color**, click **Custom...**, and then select a color in the displayed dialog box. Some colors cannot be changed, or the new color may only be applied to some portions of the background, depending on the design.
- To use a single color for the background, select **Simple** in **Category**, and then double-click a single-color background. Change the color in **Background Color**.

Setting Background Image

Set the background by filling the poster with an inserted image.

1. Right-click an image on poster, and then click Fit to background (Background setting).

The image is moved to the very back to fill the entire poster area.

Note

- For instructions on inserting images in posters, see <u>Inserting Images in Posters</u>.
- Fit to background (Background setting) can only be applied to the following images.
- Images in the photo library
- Images you have added to the poster
- Images copied and pasted from other applications
 - If background margins have been specified, the image is arranged within those margins. For instructions on specifying background margins, see Specifying Background Margins.
 - If the image has a different aspect ratio than the poster, the image is trimmed to match the poster's aspect ratio. To adjust the trimming area, see <u>Trimming Photos</u>.

Specifying Background Margins


Specify background margins.

1. Click Edit in the task area, and then click Backgrounds.

The view switches to the Edit screen (Backgrounds).

2. Click Set Margins....

The Background Margins dialog box appears.



3. Specify the top, bottom, left, and right margins.

Enter the value directly or click \land (Up Arrow) or \lor (Down Arrow) on the right to increase or decrease the value.

4. Click OK.

Working with Objects

Photos, clipart, text, and other elements you can work with in posters are collectively called "objects."

This section describes various ways of working with objects.

- Selecting Objects
- ➤ Cutting, Copying, and Pasting Objects
- Moving, Enlarging, Reducing, and Rotating Objects
- Specifying Size, Position, or Orientation Numerically
- **▶** Locking Object Positions
- Aligning Objects
- Making Multiple Objects the Same Size
- Grouping Objects
- Reordering Objects

Selecting Objects

To work with objects, you must select the target object.

You can select multiple objects at once.

1. Click an object on the poster.

An orange frame appears around the object, and the object is selected.

2. To select multiple objects, hold down the Ctrl or Shift key as you click the objects.

An orange frame appears around each of the clicked objects, and the objects are selected.

>>>> Note

• The orange frame that appears around text is called a text box.



In a text box, you can change the text format (font color, text style, etc.). However, you cannot edit the text.

• You can also select multiple objects by dragging across the objects as if drawing a box around them.

Cutting, Copying, and Pasting Objects

Cut an object and paste it anywhere on the poster.

Objects can be copied as well.

- → Cutting Objects
- Copying Objects
- → Pasting Objects from Clipboard

Cutting Objects

1. Select one or more objects, right-click any of them, and then click Cut.

The selected object(s) are copied to the clipboard and deleted from the poster.

Note

· Alternatively, select an object, and then press Ctrl+X to cut.

Copying Objects

1. Select one or more objects, right-click any of them, and then click Copy.

The selected object(s) are copied to the clipboard.

>>> Note

- Alternatively, select an object, and then press Ctrl+C to copy.
- When you drag an object while holding down the Ctrl key, the object is copied where it is dragged.
- When multiple instances of PosterArtist are running simultaneously, objects can be copied and pasted between these windows.

Pasting Objects from Clipboard

1. Right-click anywhere on poster, and then click Paste.

The object is pasted from the clipboard onto the center of the poster.

2. Move object as needed.

Note

- Alternatively, select an object, and then press Ctrl+V to paste.
- · When you drag an object while holding down the Ctrl key, the object is copied where it is dragged.
- When multiple instances of PosterArtist are running simultaneously, objects can be copied and pasted between these windows.

Moving, Enlarging, Reducing, and Rotating Objects

Adjust the position, size, and orientation of objects with a mouse.

- Moving Objects
- ➡ Enlarging and Reducing Objects
- Rotating Objects

Moving Objects

1. Select one or more objects.

The object(s) are framed in orange.

2. Drag and move the object using the (Move pointer) that appears inside the orange frame.

Note

- To move an object horizontally or vertically, drag it while holding down the Shift key.
- Use the Quick Exchange function to easily swap the positions of multiple objects. For details, see Quick Exchange (Swapping Objects).

Enlarging and Reducing Objects

1. Select one or more objects.


The object(s) are framed in orange.

- **2.** Point to (Resize handle) on the frame.
- **3.** Drag the pointer to resize the object.



One of these pointers appears when you point to a corner of a frame.


Drag the pointer to resize the object without changing the position of • (Resize handle) in the diagonally opposite corner.





One of these pointers appears when you point to a side of a frame.


Drag the pointer to adjust the height and width of the object freely.



↔ ‡ 5 2 + the Ctrl key


To resize an object without changing its center point, hold down the Ctrl key as you drag the pointer.

When resizing clipart, the line thickness is also maintained.




↔ ‡ ¼ ✓ + the Shift key

To resize an object without changing its aspect ratio, hold down the Shift key as you drag the pointer.



↔ 🕽 🌄 🖍 + the Ctrl key + the Shift key

To resize an object without changing its aspect ratio and center point, hold down the Ctrl and Shift keys as you drag the pointer.



Crosshair pointer

A crosshair pointer appears when you point to either end of a line or arrow.

Drag the pointer to adjust the line or arrow length.




Crosshair pointer + the Ctrl key

To extend or retract both ends of a line or arrow at once, hold down the Ctrl key as you drag (Resize handle).




Crosshair pointer + the Shift key

To extend or retract a line or arrow without changing its orientation, hold down the Shift key as you drag (Resize handle).



Crosshair pointer + the Ctrl key + the Shift key

To extend or retract a line or arrow without changing its center point and orientation, hold down the Ctrl and Shift keys as you drag • (Resize handle).



>>> Note

When a text box is resized, text in the text box is resized accordingly. However, if the Word Wrap
checkbox is selected in the Edit screen (Text), the text will not be resized even when the text box is
resized.

- · When objects are resized, the following are resized accordingly.
- Photo frames of objects with photo frames
- Text graphics of objects with text graphics

Rotating Objects

1. Select one or more objects.


The object(s) are framed in orange.

2. Click ② (Rotation).

The object switches to Rotation mode.

3. Drag • (Rotation handle).

The object rotates.




Note


• To rotate objects 90 degrees, click either of the following buttons on the toolbar to select the rotation direction. The rotation direction can also be selected from **Rotate or Flip** by right-clicking an object.



(Rotate Left 90 degrees): Rotates objects 90 degrees to the left (counter-clockwise).



(Rotate Right 90 degrees): Rotates objects 90 degrees to the right (clockwise).



• To invert objects, click either of the following buttons on the toolbar to select the direction of inversion.

The direction of inversion can also be selected from **Rotate or Flip** by right-clicking an object.



(Flip Vertical): Inverts images so that the top portion is on the bottom and vice versa.





(Flip Horizontal): Inverts images so that the left side is on the right and vice versa.



Specifying Size, Position, or Orientation Numerically


Specify the size, position, or angle of objects by entering a value.

1. Select one or more objects.


The object(s) are framed in orange.

Right-click the selected object, and then select Size and Position... or Properties....The Properties dialog box appears.

For objects other than lines (or arrows):



For lines (or arrows):



3. Enter a value to specify the size, position, or angle of the object.

>>>> Note

- The setting items vary depending on whether the object is a line (or arrow) or not.
- For settings, see <u>Properties Dialog Box</u>.
- 4. Click OK.

Locking Object Positions

Lock objects in position.

Lock an object to prevent it from being accidentally moved when moving another object or other items.


1. Select one or more objects.

The object(s) are framed in orange.


2. Right-click the selected object, and then click **Properties...**.

The **Properties** dialog box appears.

For objects other than lines (or arrows):



For lines (or arrows):



3. Select the Object Locking checkbox.

4. Click OK.

The object is locked.

Note

- Locked objects are outlined in red when you point to them.
- Objects that have been set up for variable printing cannot be locked.

Aligning Objects

Align multiple objects on the poster.

Align objects relative to their positions or with the guide or grid.


1. Select multiple objects.

The selected objects are framed in orange.

Note

- For how to select multiple objects, see <u>Selecting Objects</u>.
- 2. On the toolbar, click (Align and Distribute Objects Dialog).

The Align and Distribute Objects dialog box appears.



Note

- The Align and Distribute Objects dialog box can also be displayed when you right-click any of the selected objects, and then select Align and Distribute Objects > Align and Distribute Objects
 Dialog... For details, see Align and Distribute Objects Dialog Box.
- 3. From the Align, Distribute, and Center buttons, click the one you want to apply.

The objects are aligned accordingly.

>>>> Note

- The objects are aligned based on their orange frames. For images with margins, trim the margins beforehand to align the depicted images. For details, see <u>Trimming Photos</u>.
- **4.** When finished aligning, click (Close).

Using the Guide



- The guide can also be displayed when you right-click outside the poster, and then select Grid and Guide > Guide.
- 2. Drag the guide to the position where you want to adjust an object.
- 3. On the toolbar, click (Down Arrow) to the right of (Guide), and then select to place a checkmark beside **Snap to Guide**.

>>>> Note

- Alternatively, right-click outside the poster, select Grid and Guide, and then select to place a checkmark beside Snap to Guide.
- 4. Drag the object to the position where you want to adjust it.

The object is snapped to the guide when brought closer to it.



- If you prefer not to snap the object to the guide, on the toolbar, click (Down Arrow) to the right of (Guide), and then select to remove the checkmark beside **Snap to Guide**.
- If you press the Alt key when bringing the object closer to the guide, the Snap to Guide setting will be switched while holding down the Alt key.
- To specify the guide position numerically, on the toolbar, click (Down Arrow) to the right of (Guide), and then select **Enter Guide Position...** to display the **Guide Position**. For details, see Guide Position Dialog Box.
- The ruler can be displayed at the top edge and left edge of the poster design area. To display the ruler, select **Ruler** from the **View** menu.

Using the Grid

1. On the toolbar, click (Grid).

The grid appears on the poster.

Note

 The grid can also be displayed when you right-click outside the poster, and then select Grid and Guide > Grid. 2. On the toolbar, click (Down Arrow) to the right of (Grid), and then select to place a checkmark beside **Snap to Grid**.

>>> Note

- Alternatively, right-click outside the poster, select **Grid and Guide**, and then select to place a checkmark beside **Snap to Grid**.
- 3. Drag the object to the position where you want to adjust it.

The object is snapped to the grid when brought closer to it.

>>>> Note

- If you prefer not to snap the object to the grid, on the toolbar, click (Down Arrow) to the right of (Grid), and then select to remove the checkmark beside **Snap to Grid**.
- If you press the Alt key when bringing the object closer to the grid, the Snap to Grid setting will be switched while holding down the Alt key.

Making Multiple Objects the Same Size


Make multiple objects on the poster the same height or width.

- **1.** Click the object of the target size.
- 2. Click multiple objects while holding down the Ctrl or Shift key.

The selected objects are framed in orange.

3. On the toolbar, click (Align and Distribute Objects Dialog).

The Align and Distribute Objects dialog box appears.



Note

- The Align and Distribute Objects dialog box can also be displayed when you right-click any of the selected objects, and then select Align and Distribute Objects > Align and Distribute Objects
 Dialog.... For details, see Align and Distribute Objects Dialog Box.
- 4. Under Match Size, click (Fit Width) or (Fit Height).

Important

- The objects' aspect ratios are not maintained. To maintain the aspect ratios, resize objects one by one. For details, see Moving, Enlarging, Reducing, and Rotating Objects.
- 5. Click (Close).

Grouping Objects

Group multiple objects on the poster to work with the group as if it were a single object. This can help make selecting and moving objects more smoothly.

1. Click multiple objects while holding down the Ctrl or Shift key.

The selected objects are framed in orange.

2. Right-click any of the selected objects, and then click **Group > Group**.

The objects are grouped.

>>>> Note

- To ungroup the objects, right-click the group, and then select **Group > Ungroup**.
- Locked objects cannot be grouped.

Reordering Objects

When you add new objects, they are arranged in front of existing objects. Change the order of overlapping objects as needed.

1. Click object.

The selected object is framed in orange.

2. Right-click the selected object, and then in **Order**, select one of the following menu items.

The object is reordered.

Bring to Front

Moves the selected object to the front.

Send to Back

Moves the selected object to the back.

Bring Forward

Moves the selected object one position forward.

Send Backward

Moves the selected object one position back.



• If the background has been specified in the **Edit** screen (Backgrounds), objects cannot be moved behind the background.

Printing Posters

The posters created with PosterArtist can be printed only on Canon printers or Océ printers.

>>> Important

- Available functions and settings vary depending on your model.
- Printing Posters
- **▶** Test Printing
- Ambient Light Setting

Printing Posters

1. In the task area, click Print.

The view switches to the **Print screen**.

Note

- Before printing your poster you can run a test print on A4 or Letter sized paper. For details, see <u>Test</u>
 Printing.
- 2. Check print settings.

Note

- Specify the printer to use, **Media Type**, **Media Source**, and other settings in **Paper Options** screen. For details, see Specifying Size and Paper.
- 3. Select the Print Quality and Matching Method.
- 4. Specify the number of Copies to print.
- 5. Click Print.

The **Print Progress** dialog box appears.

>>> Note

- To start imagePROGRAF Preview and check the print result in the preview, select the Check Print
 Preview Before Printing checkbox, and then click Print. This is recommended when printing on roll
 paper.
- To check the settings and print result, click Print Preview... in the File menu.
- To import print data from various applications and adjust the layout before printing, select the Use Free Layout checkbox.
- To cancel printing, click Cancel Printing in the Print Progress dialog box.

Test Printing

Perform test printing on A4 or Letter size paper to check the print image before printing on the actual paper.

1. In the task area, click Print.

The view switches to the **Print screen**.

2. Click Test Print.

The **Print Progress** dialog box appears. To cancel printing, click **Cancel Printing**.

>>> Important

- In test printing, the printer's printing features such as borderless printing (or minimal margin printing) and print quality setting are not available.
- · Ambient light settings do not apply.

>>> Note

- You can specify the printer and paper size to use for test printing. For details, see <u>Preferences Dialog</u>
 Box.
- To print all records in the tabular data by using the variable printing function, deselect the **Current Record Only** checkbox.

Ambient Light Setting

Ambient light color and brightness vary by environmental factors such as location (indoors or outdoors) or lighting (fluorescent or incandescent). Therefore the same poster may appear different depending on where it is displayed.

Use the ambient light setting functions to adjust colors automatically according to the environment to visually enhance the poster's color tones.

>>> Important

- This function cannot be used depending on your printer or paper type.
 - Printing the Ambient Light Correction Chart
 - ➡ Printing by Selecting a Chart Number
 - Printing by Specifying Light Source and Color Temperature
 - Printing by Adjusting Monitor and Print Colors

Printing the Ambient Light Correction Chart

Print samples of four prepared ambient light settings (chart printing).

Important

- This function requires the Light Source Check Tool. Download the Light Source Check Tool from our website and install it.
- The Light Source Check Tool may not be available depending on your environment.
 - 1. In the Tool menu, click Print Ambient Light Correction Chart....

The Print Chart dialog box appears.

- 2. Specify the printer to use, Media Type, Paper Source, and other settings.
- 3. Click Print.

The ambient light correction chart is printed.

Printing by Selecting a Chart Number

From the four samples of the ambient light settings (chart printing), select the number of the sample whose color tone matches the environment where the poster is displayed.

1. Print the chart of ambient light settings.

Note

- For chart printing, see Printing the Ambient Light Correction Chart.
- 2. In the task area, click Print.

The view switches to the Print screen.

- 3. In Print Quality, select High or Highest.
- 4. Specify the number of Copies.
- Select the Use Ambient Light Setting checkbox.
- **6.** Check the printed charts, and then select the number of the chart on which colors of four pictures look favorable.

Note

- Check charts in the environment where the poster is displayed.
- 7. In ambient light settings, specify the selected chart number.
- 8. Click Print.

Printing is performed according to the selected ambient light setting.

Printing by Specifying Light Source and Color Temperature

Print posters by specifying the light source and color temperature.

>>> Important

- This function requires the "i1" light meter and the Light Source Measure Tool. Download the "i1" light
 meter or the Light Source Measure Tool from our website, and then install it on the computer used for
 measuring ambient light.
 - **1.** Measure the light source type and color temperature using the "i1" light meter and the Light Source Measure Tool.


Note

- For instructions on measuring the light source type and color temperature, refer to "LightSourceMeasureTool_English.pdf" supplied with the Light Source Measure Tool.
- 2. In the task area, click Print.

The view switches to the **Print screen**.

- 3. In Print Quality, select High or Highest.
- 4. Specify the number of Copies.
- 5. Select the Use Ambient Light Setting checkbox.
- 6. In ambient light settings, click Custom Settings.

The Ambient Light Setting dialog box appears.



- **7.** In **Lighting Source Type**, select the light source type measured with the Light Source Measure Tool.
- **8.** In **Color Temperature**, specify the color temperature measured with the Light Source Measure Tool.
- 9. Click OK.
- 10. Click Print.

Printing is performed according to the selected ambient light setting.

Printing by Adjusting Monitor and Print Colors

Making adjustments so that the colors match between the monitor and print result is called monitor matching.

Use the ambient light settings to make adjustments to print posters with colors that match the monitor colors.

>>> Important

- · Monitor matching requires monitor calibration.
- Your monitor may not support monitor matching, or you may not be able to configure settings or make adjustments.

Printing by Selecting a Chart Number

1. Print samples of ambient light settings.


Note

- · For chart printing, see Printing the Ambient Light Correction Chart.
- 2. In the task area, click Print.

The view switches to the Print screen.

- 3. In Print Quality, select High or Highest.
- 4. In Matching Method, click Monitor Matching.
- **5.** Under **Monitor White Point**, select the color temperature set on the monitor.
- **6.** Specify the number of **Copies**.
- 7. Select the Use Ambient Light Setting checkbox.
- 8. In ambient light settings, click By selecting a chart number.

The Ambient Light Setting dialog box appears.



- **9.** Check the printed charts, and then select the number of the chart on which colors of four pictures look favorable.
- **10.** In **Color Temperature**, specify the color temperature measured at monitor calibration.
- **11.** In **Illuminance**, specify the illuminance measured at monitor calibration.
- 12. Click OK.
- 13. Click Print.

Printing is performed according to the selected ambient light setting.

Printing by Specifying the Light Source, Color Temperature, and Illuminance

>>> Important

- This function requires the "i1" light meter and the Light Source Measure Tool. Download the Light Source Measure Tool from our website, and then install it on the computer used for measuring ambient light.
 - **1.** Measure the light source type and color temperature using the "i1" light meter and the Light Source Measure Tool.


Note

- For instructions on measuring the light source type and color temperature, refer to "LightSourceMeasureTool_English.pdf" supplied with the Light Source Measure Tool.
- 2. In the task area, click Print.

The view switches to the Print screen.

- 3. In Print Quality, select High or Highest.
- 4. In Matching Method, click Monitor Matching.
- 5. Under Monitor White Point, select the color temperature set on the monitor.
- 6. Specify the number of Copies.
- 7. Select the Use Ambient Light Setting checkbox.
- 8. In ambient light settings, click By entering values directly.

The Ambient Light Setting dialog box appears.



- **9.** In **Lighting Source Type**, select the light source type measured with the Light Source Measure Tool.
- **10.** In **Color Temperature**, specify the color temperature measured with the Light Source Measure Tool.
- **11.** In **Illuminance**, specify the illuminance measured with the Light Source Measure Tool.
- 12. Click OK.
- 13. Click Print.


Printing is performed according to the selected ambient light setting.

Managing Ambient Light Settings

Save your ambient light settings. Save frequently used ambient light settings to quickly print posters according to the environment where they are displayed.

1. In the Tool menu, click Managing Ambient Light Settings....

The Managing Ambient Light Settings dialog box appears.



2. In Ambient Light Settings, select Custom Settings, and then specify the light source and color temperature.

Note

- You can also save the default ambient light settings with a new name. In that case, in **Chart Number**, select from **Chart Number 1** to **Chart Number 4**.
- For instructions on measuring the light source type and color temperature, refer to "LightSourceMeasureTool_English.pdf" supplied with the Light Source Measure Tool.

3. In Custom Ambient Light Setting, enter a name.

4. Click Add.

The ambient light setting is added with the specified settings.

>>> Note

- Saved ambient light settings can be selected from Use Ambient Light Setting in the Print screen.
- To delete registered ambient light settings, select the ambient light setting you want to delete, and then click **Delete**.
- Chart Number 1 to Chart Number 4 and Custom Settings cannot be deleted.
- To check the setting list, click **List** for displaying the **Ambient Light Setting List** dialog box.

Saving

- ➤ Saving in a PosterArtist File Format
- ➤ Saving in JPEG Format

Saving in a PosterArtist File Format

Save created posters as ".cpfx2" files, the proprietary PosterArtist format.

1. In the File menu, click Save As....

The **Save As** dialog box appears.

Note

- To overwrite a saved file, select **Save**. The **Save** dialog box appears.
- 2. Specify the save location.
- 3. In File name, enter the file name.
- 4. Click Save As.

The poster is saved as a file exclusively for use with PosterArtist (file extension ".cpfx2").

Note

• Photos, clipart, and other materials in the temporary tray are saved with the poster.

>>> Important

• Templates in the temporary tray are not saved.

Saving in JPEG Format

Save created posters as image files in JPEG format.

1. In the File menu, click Save As JPEG....

The **Save As JPEG** dialog box appears.

- 2. Specify the save location.
- 3. In Size, select the size at which you want to save the poster.

Select Small, Medium, or Large for A5, A4, or A3, respectively; each size is saved at 72 dpi.

Note

- Image files are saved with the poster's long side enlarged/reduced to the paper size specified in **Size**. The short side's length is adjusted to maintain the aspect ratio.
- 4. In File name, enter the file name.
- 5. Click Save As.


The poster is saved in JPEG format.

When saved, the application associated with JPEG files starts and the saved JPEG image appears.

Using Variable Printing

Automatically substitute text, images and other content on the poster for printing by using tabular format data.

A set of posters each suitable for the environment of the place where the poster is posted can also be created automatically for printing according to the tabular data.



- Preparing Data
- Starting Variable Printing

Preparing Data

This section describes tabular data available for variable printing.

Note

- · Use the following files for variable printing.
- Excel format files (.xls, .xlsx, .xlsm, and .xlsb)
- CSV format files (.csv)



- A: Field Name
- → B: Record

A: Field Name

In the first row of the tabular data, enter a field name to indicate the data type.

>>>> Important

• If the field name is blank, an entry in an unintended cell may be recognized as the field name.

Note

• Enter up to 32 characters for the field name.

B: Record

In the second and subsequent rows, enter alternative text data.

To substitute images, enter absolute paths to alternative image files.

To change ambient light setting, enter ambient light setting names.

>>> Important

- In PosterArtist, records of up to 500 rows can be entered. Records in and after the 501st row are not applied.
- Do not use Excel format data with merged rows or columns. Substitution will not work correctly.

Note

 Ambient light setting names can be checked in the Ambient Light Setting List dialog box. For details, see Managing Ambient Light Settings.

>>> Note

• After preparing the data, set up variable printing. For instructions on setting up variable printing, see <u>Starting Variable Printing</u>.

Starting Variable Printing

Use the prepared tabular data to set up and start variable printing.

1. Click Edit in the task area, and then click Variable Data.

The view switches to the Edit screen (Variable Data).

2. Click Connect to....

The Open Data Source dialog box appears.

3. Select the tabular data file to use, and then click **Open**.

The field names in the read tabular data are added to the Connected Data list.

4. On the poster, select the text you want to substitute.

>>>> Note

- To substitute images, select an image on the poster.
- **5.** In **Connected Data**, select the field name of the text string you want to substitute.

The text string is linked to the tabular data, and ¹ (Connect) appears.

Note

- To cancel the link, in Connected Data, select Unselected.
- To substitute images, select the field name of the file paths to the target images. If the image is not

found in the path, the selected image is replaced with



(Invalid Link).

6. In Text alignment, specify the text position.

The substituted text will be printed in the specified position.

Note

• To format the text, enter as follows in **Text format**.

%[1][2][3][4]

- [1] (Optional)
 - -: Text is aligned to the left.
 - +: + is added if the value is 0 or more. Example) 500 > +500
 - , : The thousands separator is used. Example) 1600 > 1,600
- [2] (Optional)

0 or more and 100 or less: Specify the minimum number of characters to be output.

For instance, if this is set to "10," the minimum number of characters output is for 10 characters whether the text is "abc" (3 characters) or "abcdefghij" (10 characters).

- [3] (Optional)

0 or more and 100 or less: If [4] is an integer value (d), the minimum number of digits is specified.

If [4] is a real number (f), the number of digits after the decimal point is specified.

Be sure to enter a value with "." (period), such as ".2".

Example) If ".3" is specified: 5 > 005 (integer value), 500 > 500.000 (real number)

– [4]

- s: The content is treated as text.
- d: The content is treated as an integer value.
- f: The content is treated as a real number.

Example) If "%+.2f" is specified

Tabular data > Substitute to

500 > +500.00

Any text can also be added before or after "%[1][2][3][4]".


Example) If "¥%,d" is specified

Tabular data > Substitute to

1600 > ¥1,600

- To change the ambient light setting, select the **Ambient Light Settings** checkbox, and then in **Ambient Light Field**, select the field name.
- 7. To select the data to be used or specify the number of copies, click Filter Records.

The Filter Records dialog box appears.



To exclude data from the data to be printed:

Deselect the Print checkbox.

To specify the number of prints:

Double-click the number of copies of the record, and then enter the number directly or click \land (Up Arrow) or \lor (Down Arrow) on the right to increase or decrease the number.

- 8. Click OK.
- **9.** In **Record Number**, click (Previous) or (Next) to check that the text string or image is replaced with each record.

>>> Note

- Even when text is replaced, settings such as the font and text color are not changed.
- A text string is replaced in the style of the first character of the text string on the poster.
- 10. In the task area, click Print.

The view switches to the Print screen.

>>> Note

- · When the ambient light setting is enabled, in Print Quality, select High or Highest.
- 11. Click Print Records.

The **Print Progress** dialog box appears.

Note

- To print the currently displayed data only, select the Current Record Only checkbox.
- To cancel printing, click **Cancel Printing** in the **Print Progress** dialog box.
- Posters can also be printed with crop marks or without borders. For details, see Specifying Size and Paper.

>>> Note

• To cancel the variable printing settings, click **Disconnect Data**. The link to the database will be canceled and the variable printing settings will be disabled.

Managing Artwork

Photos, clipart, templates, and other materials used in PosterArtist are referred to as "artwork." PosterArtist provides a wide range of artwork that is categorized and stored in the library.

You can add posters you have created and images on your computer to the library as well. In the library, you can rename categories, change display order, delete unneeded categories and artwork, or add them to the library again.

- Adding Artwork to Library
- Importing and Exporting
- Organizing Artwork in Library
- Downloading Artwork at Once
- Preparing the Same Artwork Environment on Other Computers

Adding Artwork to Library

Add photos, clipart, or created posters to the library to use in PosterArtist.

- ➡ Adding Posters to Template Library
- Adding Images to Library

Adding Posters to Template Library

Created posters can be added to the library as templates.

1. In the File menu, click Add to Templates....

The Artwork Manager dialog box appears.

>>> Note

- Alternatively, add from Add to Templates... in Select Template screen.
- 2. In Category, select a category.

Note

- To add a new category, click **Add new category...**. Enter the name in **Name**, and then click **OK** to add the category to the bottom of the **Category** list.
- You can protect the poster from being edited, or set a time limit for its use as a template. For details, see Saving Artwork Dialog Box (Templates).
- 3. Click OK.

The displayed poster is added to the library.

Note

• The poster and the images used in it are saved in the folder specified in the Preferences dialog box.

Adding Images to Library

Add photos, clipart, and other images to the library.

1. Right-click an image in the poster design area, and then click Add to Photos / Clipart....

The Artwork Manager dialog box appears.

Note

- Alternatively, to display the Saving Artwork dialog box, select an image in the poster design area, display the Edit screen (Photos) or Edit screen (Clipart), and then click Add to Photos / Clipart... or Add to Clipart....
- 2. In Artwork type, select Photos or Clipart.

>>> Note

• Select the **Artwork type** according to the image.

Photos: Photos

Clipart: Photos, clipart, shapes, text, and QR codes

3. In Category, select a category.

>>> Note

- To add a new category, click **Add new category...**. Enter the name in **Name**, and then click **OK** to add the category to the bottom of the **Category** list.
- You can protect the image from being edited, or set a time limit for its use. For details, see <u>Saving Artwork Dialog Box (Images)</u>.


4. Click OK.

The image is added to the library.

Importing and Exporting

Import image files such as JPEG images to the library. Imported image files can be used as photos or clipart.

Artwork added to the library can be saved (exported) as a single file. By importing exported artwork to the library on other computers, the created artwork can be shared with other users.



- ➡ Importing Image Files
- **▶** Importing Artwork
- **▶** Exporting Artwork

Importing Image Files

Import image files such as JPEG images to the library to use as photos or clipart.


1. In the File menu, click Import....

The **Import** dialog box appears.

Note

- File formats of images that can be imported are as follows.
- JPEG (.jpg, .jpeg)
- TIFF (.tif, .tiff)
- PNG (.png)
- BMP (.bmp)
- MF (.?mf)
- SVG (.svg)
- 2. Specify the location of the file.
- 3. Select the file to import.
- 4. Click Open.

The Saving Artwork dialog box (Images) appears.



- 5. In Artwork type, select Photos or Clipart.
- **6.** In **Category**, select a category to import the image to.

Note

• To add a new category, click **Add new category...**. Enter the name in **Name**, and then click **OK** to add the category to the bottom of the **Category** list.

You can protect the image from being edited, or set a time limit for its use. For details, see <u>Saving Artwork Dialog Box (Images)</u>.

7. Click OK.

The image is imported to the library.

Importing Artwork

Import PosterArtist files exported from other computers. The artwork is added to the category specified at the time of export and can be used in the same way as other artwork.

1. In the File menu, click Import....

The Import dialog box appears.

>>> Note

- When importing PosterArtist files exported from other computers, select the following files.
- .cpt
- cptx

- 2. Specify the location of the file.
- 3. Select the file to import.
- 4. Click Open.

The artwork is imported.

Exporting Artwork

Export artwork as a single file.

>>> Note

- An export file can include templates in the library, images used in templates, as well as photos, clipart, and backgrounds in the library.
- Artwork can be exported and uploaded to cloud storage. For details, see Using Cloud.
 - **1.** Add created artwork to the library.
 - 2. In the File menu, click Export....

The Export dialog box appears.


- 3. Click the tab of the library containing the artwork you want to export.
- 4. Select the artwork you want to export, and then click Add.

The selected artwork is added to **Item to be exported**.

Note

- Up to 200 artwork items can be selected from multiple libraries.
- · Multiple artwork items are exported as a single file.
- You can change the thumbnail size. For details, see <u>Export Dialog Box</u>.
- 5. Click Next.

The **Export to** dialog box appears.



6. Enter the destination category name.

>>> Note

• Even if artwork is selected from multiple libraries, only one category name can be entered. A category of the same name is created in the corresponding libraries at the destination.

7. Click Next.

The Save As dialog box appears.

- **8.** Specify the save location.
- **9.** In **File name**, enter the file name.

10. Click Save As.

A PosterArtist export file (file extension ".cptx") is saved.

>>>> Note

• For templates, images inserted by users, image retouching information, etc. are also exported.

>>> Important

• Files exported from PosterArtist V3.0 or later cannot be imported in earlier versions of PosterArtist.

Organizing Artwork in Library

Organize libraries and artwork to make them easier to use by adding categories, renaming categories, or rearranging in descending order of frequency. You can also delete unneeded artwork.

- Organizing Library Categories
- Organizing Artwork in Categories
- ➡ Restoring Removed Artwork

Organizing Library Categories

1. On the toolbar, click (Artwork Manager Dialog).

The Artwork Manager dialog box appears.

- 2. Click the tab of the library whose categories you want to organize.
- 3. Organize the categories in the list.

To add new categories:

- 1. Click New Category.
- 2. Enter a name for the category.

To rename categories:

- 1. In the category list, select a category, and then click Rename.
- 2. Enter a name for the category.

To change the display order:

- 1. Select the category you want to move.
- **2.** Drag the category to the target location.

To delete categories:

- 1. In the category list, select the category you want to delete.
- 2. Click Delete.
- 3. Click OK.

>>>> Important

- Categories with a (Lock) icon cannot be deleted.
- 4. Click OK.

Note

• For details on the Artwork Manager dialog box, see Artwork Manager Dialog Box.

Organizing Artwork in Categories

1. On the toolbar, click (Artwork Manager Dialog).

The Artwork Manager dialog box appears.

- **2.** Click the tab of the library whose artwork you want to organize.
- **3.** Click the category of the artwork you want to organize.
- **4.** Organize artwork.

To move artwork to another category:

- 1. Select the artwork.
- 2. Click Move.

The Move Artwork dialog box appears.

3. In Category, select the destination category, and then click OK.

To change the display order:

- 1. Select the artwork you want to move.
- 2. Drag the artwork to the target location.

To copy artwork from one category to another:

- 1. Select the artwork.
- 2. Click Copy.
- **3.** Select the category where you want to paste the copied artwork.
- 4. Click Paste.

>>> Important

· Artwork you copied can only be pasted within the same library.

To remove artwork from a category:

- 1. Select the artwork you want to remove.
- 2. Click Delete.
- 3. Click OK.

>>>> Important

- Artwork with a (Lock) icon cannot be deleted.
- 5. Click OK.

Note

For details on the Artwork Manager dialog box, see Artwork Manager Dialog Box.

Restoring Removed Artwork

1. On the toolbar, click (Artwork Manager Dialog).

The Artwork Manager dialog box appears.

2. In Category, click Deleted content.

Thumbnails of removed artwork appear.

3. Select the artwork you want to restore, and then click **Restore**.

The restored artwork is added to the library.

Downloading Artwork at Once

Download new artwork to the library at once.

1. On the toolbar, click (Artwork Manager Dialog).

The **Artwork Manager** dialog box appears.

2. Click Download.

The downloaded artwork is added to the corresponding library.

Preparing the Same Artwork Environment on Other Computers

Artwork can be freely added, removed, and sorted. Create an installer file and install it on other computers to use the organized artwork environment in the same state on other computers.

- ★ Creating the Artwork Installer File
- ➡ Installing Artwork

Creating the Artwork Installer File

Create an installer file on the source computer.

1. In the Tool menu, click Artwork Snapshot....

The Artwork Snapshot dialog box appears.

- 2. Specify the save location.
- 3. Click Start Snapshot.

PASnapshot.exe is saved.

>>> Important

· You must be logged on with administrative rights to create an installer file.

Installing Artwork

Install artwork to the computer to which you want to apply the same artwork environment.

- Check that the same version of PosterArtist that was used to create the installer file is installed.
- 2. Double-click the created PASnapshot.exe.

Important

You must be logged on with administrative rights to execute an installer file.

Using Cloud

Share created poster files, image files, and artwork export data with other computers and users by uploading them to or downloading them from cloud services.

- Downloading Posters and Materials from Cloud
- Uploading Current Poster to Cloud
- Uploading Export Files to Cloud

>>> Important

- To use this function, imagePROGRAF Direct Print & Share (hereinafter "Direct Print & Share") V2.0.0 or later must be installed. The latest version can be downloaded from our website. For the operation procedure and supported cloud services, refer to Help of Direct Print & Share.
- When Direct Print & Share is running, PosterArtist cannot be operated.
- To use a cloud service, you must create an account for the cloud service beforehand.

Downloading Posters and Materials from Cloud


Download poster files and image files from cloud storage.

>>>> Important


- To use this function, imagePROGRAF Direct Print & Share (hereinafter "Direct Print & Share") V2.0.0 or later must be installed. For the Direct Print & Share operation procedure and supported cloud services, see Help of Direct Print & Share.
 - 1. In the Cloud sharing menu, click Download poster/material....

The Direct Print & Share screen appears.

2. Click Login, and then select your cloud storage.



- **3.** In **Cloud storage**, select the checkbox of the file you want to download.
- 4. Click Download.



5. Click OK.

Uploading Current Poster to Cloud

Save the current poster and upload it to cloud storage.

>>> Important

- To use this function, imagePROGRAF Direct Print & Share (hereinafter "Direct Print & Share") V2.0.0 or later must be installed. For the Direct Print & Share operation procedure and supported cloud services, see Help of Direct Print & Share.
 - 1. In the Cloud sharing menu, click Upload currently open poster....


The Save As dialog box appears.

- 2. Specify the save location.
- 3. In File name, enter the file name.
- 4. Click Save As.


The created poster is saved as a file exclusively for use with PosterArtist.

The Direct Print & Share screen appears.

5. Click **Login**, and then select your cloud storage.



- **6.** In **Registered file**, select the checkbox of the file you want to upload.
- 7. Click Upload.



8. Click Close.

>>>> Note

• For instructions on downloading posters from cloud storage, see Downloading Posters and Materials from Cloud.

Uploading Export Files to Cloud

Export and upload artwork to cloud storage.

>>> Important

- To use this function, imagePROGRAF Direct Print & Share (hereinafter "Direct Print & Share") V2.0.0 or later must be installed. For the Direct Print & Share operation procedure and supported cloud services, see Help of Direct Print & Share.
 - **1.** Add created artwork to the library.

Note

- For instructions on adding artwork to the library, see Adding Artwork to Library.
- 2. In the Cloud sharing menu, click Upload export file....

The **Export** dialog box appears.


- **3.** Click the tab of the library containing the artwork you want to export.
- **4.** Select the artwork you want to export, and then click **Add**.

The selected artwork is added to Item to be exported.

Note

- Up to 200 artwork items can be selected from multiple libraries.
- · Multiple artwork items are exported as a single file.
- You can change the thumbnail size. For details, see Export Dialog Box.
- 5. Click Next.

The **Export to** dialog box appears.



6. Enter the destination category name.

>>> Note

- Even if artwork is selected from multiple libraries, only one category name can be entered. A category of the same name is created in the corresponding libraries at the destination.
- 7. Click Next.


The Save As dialog box appears.

- 8. Specify the save location.
- 9. In File name, enter the file name.
- 10. Click Save As.


A PosterArtist export file (file extension ".cptx") is saved.

The Direct Print & Share screen appears.

11. Click **Login**, and then select your cloud storage.



- **12.** In **Registered file**, select the checkbox of the file you want to upload.
- 13. Click Upload.



14. Click Close.

Note


• For instructions on downloading posters from cloud storage, see <u>Downloading Posters and Materials</u> <u>from Cloud</u>.

Using Translation Templates

Create posters with multilingual translations just by selecting the text you want to use from the provided samples, and then specifying the language(s) to be used.

1. On the toolbar, click (Add Translation Template).

The Add Translation Template dialog box appears.




>>> Note

- The **Add Translation Template** dialog box can also be displayed when you right-click a text box on the poster, and then select **Add Translation Template**.
- 2. In Category, select a template category.
- **3.** In **Sample type**, select a text type.
- 4. In the list, select sample text.

>>>> Note

· Click the top of the list to switch the sort order (ascending/descending).

Ascending	Descending
Ascending	Descending



- **5.** In **Translations**, select the checkbox(es) of the language(s) you want to use.
- 6. Click OK.

The text in the selected language(s) appears on the poster.

Note

- Samples translated into multiple languages are provided: Japanese, US English, French, Italian, German, Spanish, Simplified Chinese, Korean, Russian, and Portuguese.
- Templates that support multilingual display are also provided.

Exporting Posters for Use in Easy-PhotoPrint Editor

Export posters into files that can be edited and printed with Easy-PhotoPrint Editor.

Easy-PhotoPrint Editor can be used from your computer or smartphone.

>>> Important

- PosterArtist export data can be imported in Easy-PhotoPrint Editor V1.3.0 or later.
 - 1. In the File menu, click Export (for Easy-PhotoPrint Editor).

The Export (for Easy-PhotoPrint Editor) dialog box appears.

- 2. Specify the save location.
- 3. In File name, enter the file name.
- 4. Click Save As.

The file is saved in EPPA format.

>>> Important

• Files exported for Easy-PhotoPrint Editor from PosterArtist can be imported only in Easy-PhotoPrint Editor.

Note

• For instructions on using Easy-PhotoPrint Editor, see the Online Manual for your model.


Creating Vivid Posters Using Fluorescent Colors

Create vivid and eye-catching posters using fluorescent ink.

>>>> Important

• This function is unavailable depending on your model or paper type.

Making the Entire Poster Vivid (Vivid mode)



Make the entire poster bright and vivid using warm fluorescent ink.

This is recommended when a photo or illustration contains multiple warm colors such as pink and orange.

→ Making the Entire Poster More Vibrant (Vivid mode)

Making Specific Portions Vivid by Specifying the Colors and Areas (Spot mode)



Make specific colors bright and vivid using pink or orange fluorescent ink.

This is recommended when you want to enhance text or shapes.

→ Making Colors of Specific Areas Vivid (Spot mode)

Making the Entire Poster More Vibrant (Vivid mode)

Make the entire poster bright and vivid using fluorescent ink.

>>>> Important

- This function is unavailable depending on your model or paper type.
- This function is unavailable when the Edit layout with Free Layout plus checkbox is selected in the Paper Options screen.

Note

- You can even import posters and other items created in an application other than PosterArtist into PosterArtist as images and edit them to make the entire item bright and vivid.
 - 1. In the task area, click Print.

The view switches to the Print screen.

2. Check print settings.

Note

- Specify the printer to use, **Media Type**, **Media Source**, and other settings in **Paper Options** screen. For details, see <u>Specifying Size and Paper</u>.
- 3. In Print Quality, select the Use fluorescent ink checkbox, and then select Vivid mode.

>>> Important

 When printing the poster on water resistant media for outdoor display, deselect the Use fluorescent ink checkbox.

Making Colors of Specific Areas Vivid (Spot mode)


Make specific colors bright and vivid using warm fluorescent ink.

>>>> Important

- This function is unavailable depending on your model or paper type.
- This function is unavailable when the Edit layout with Free Layout plus checkbox is selected in the Paper Options screen.
- Colors similar to the specified color may also be printed using fluorescent ink.
- When printing the poster on water resistant media for outdoor display, deselect the Use fluorescent ink checkbox.

Note

· The following 11 fluorescent colors can be specified.



Fluorescent colors not displayed in the **Spot color** palette can be specified in the **Other Fluorescent Spot Colors** dialog box displayed by clicking **Custom...**.

- Print and check the fluorescent color list as needed. For the printing procedure, click Home to return to the top page of the Online Manual for your model and search for "Test print."
- You can even specify the area to fill with a fluorescent color in images, photos, and other objects created in an application other than PosterArtist by importing them into PosterArtist as images.
- Areas for which a fluorescent color is specified are printed with fluorescent ink. However, colors similar to the specified color may also be printed with fluorescent ink; we recommend that you preview the areas by clicking (Spot Color Area Preview) on the toolbar before printing.

Specifying Fluorescent Colors for Objects and Backgrounds

Enhance specific portions with vivid colors by specifying fluorescent colors for objects (such as clipart, text, and shapes), backgrounds, and drop shadows of objects.

Specify a color in **Spot color** for the object or background you want to enhance.

>>>> Important

- When **Opacity** of an object or background is set to a value other than 100%, a fluorescent spot color cannot be specified for the object's drop shadow color.
- When a fluorescent spot color is specified for an object's color, Opacity and Fade Shadows cannot be set.

Note

- To create a gradation with fluorescent spot colors, use <u>Vivid mode</u>.
 - Changing Clipart Colors
 - Changing the Text Format
 - ➡ Changing Shape Styles
 - ➡ Adding Backgrounds

Specifying Fluorescent Colors for Specified Areas

Fill selected areas with fluorescent colors; select an area based on the color of the position you have clicked on an image or by using **Freehand** or **Shape**.

➡ Specifying Fluorescent Colors for Specified Areas

Note

- To change the colors that appear in the Spot color palette, click Edit Palette... to display the Edit Spot
 Color Palette dialog box, and then edit.
- When saving created posters or other items as .cpfx2 files that are exclusively for use with PosterArtist, information of the used fluorescent spot colors will also be saved.

Specifying Fluorescent Colors for Specified Areas


Change the color of the specified area into a fluorescent color.

>>> Important

- This function is unavailable depending on your model or paper type.
- This function is unavailable when the Edit layout with Free Layout plus checkbox is selected in the Paper Options screen.
- Colors similar to the specified color may also be printed using fluorescent ink.
- When printing the poster on water resistant media for outdoor display, deselect the Use fluorescent ink checkbox.

Note

· The following 11 fluorescent colors can be specified.



Fluorescent colors not displayed in the **Spot color** palette can be specified in the **Other Fluorescent Spot Colors** dialog box displayed by clicking **Custom...**.

- To check the areas for which fluorescent spot colors are specified, click (Spot Color Area Preview) on the toolbar. Colors similar to the specified color may also be printed with fluorescent ink; we recommend that you preview the areas before printing.
- When saving created posters or other items as .cpfx2 files that are exclusively for use with PosterArtist, information of the used fluorescent spot colors will also be saved.
 - Changing Colors Based on the Clicked Position
 - ➡ Changing Colors by Specifying an Area

Changing Colors Based on the Clicked Position

Change the color by automatically selecting an area whose color is similar to the color specified on the image.

1. Open the **Fill** dialog box by one of the following operations.

Click Edit in the task area, click Photos, select the image you want to edit (such as a photo) on the

poster, click (Retouch Image) in **Edit Image**, and then click (Fill) in the displayed **Retouch Image** dialog box.

Right-click the image you want to edit (such as a photo) on the poster, and then click **Retouch Image...** > **Fill**.

Click **Edit** in the task area, click **Clipart**, select the clipart you want to edit on the poster, and then click **Convert to bitmap and edit...**.

Right-click the clipart you want to edit on the poster, and then click Retouch Image....

Note

- You can even change the color of posters or other items created in an application other than PosterArtist by importing them into PosterArtist as images.
- 2. Select the fluorescent color you want to set from Fluorescent spot color in Select color.
- 3. Select (Auto Select Based on Clicked Color), and then set **Tolerance**.

>>>> Important

 If the area cannot be set as expected, see <u>Changing Colors by Specifying an Area</u> and specify the area using **Freehand** or **Shape**.

>>> Note

- Tolerance is set to 15. Set a value between 0 and 100.
- Increase the value in **Tolerance** to expand the range of colors to be selected.
- **4.** Click the position for which you want to use the fluorescent color.

An area is selected based on the clicked position and the color changes into the fluorescent color.

Changing Colors by Specifying an Area

Change the color of the area you outline freehand or by drawing a polygon.

1. Open the **Fill** dialog box by one of the following operations.

Click Edit in the task area, click Photos, select the image you want to edit (such as a photo) on the

poster, click (Retouch Image) in **Edit Image**, and then click (Fill) in the displayed **Retouch Image** dialog box.

Right-click the image you want to edit (such as a photo) on the poster, and then click **Retouch Image...** > **Fill**.

Click **Edit** in the task area, click **Clipart**, select the clipart you want to edit on the poster, and then click **Convert to bitmap and edit...**.

Right-click the clipart you want to edit on the poster, and then click Retouch Image....

>>> Note

- You can even change the color of posters or other items created in an application other than PosterArtist by importing them into PosterArtist as images.
- 2. Select the fluorescent color you want to set from Fluorescent spot color in Select color.
- 3. Click (Select Area Manually), and then select a drawing mode in **Mode**.

>>> Note

- In Mode, select Freehand or Shape.
- **4.** Outline the area for which you want to change the color into a fluorescent color.

Drag on the image to outline the area, or click to specify the vertices of the polygon and double-click when you have finished drawing.

The color of the outlined area is changed.

PosterArtist Screens

Main Screen

Select Template Screen

- Select Template Screen
- Auto Design Screen
- View All Templates Dialog Box
- Find Template Dialog Box
- Saving Artwork Dialog Box (Templates)
- Design Assist Dialog Box

Paper Options Screen

- Paper Options Screen
- Set Custom Size Dialog Box

Edit Screen

- Edit Screen (Photos)
- Edit Screen (Clipart)
- Edit Screen (Text)
- Edit Screen (Shapes)
- Edit Screen (Backgrounds)
- ➤ Edit Screen (Variable Data)
- Saving Artwork Dialog Box (Images)
- Cut Out Dialog Box
- ▶ Fill Dialog Box
- Edit Image Dialog Box (Trim)
- Edit Image Dialog Box (Gradation)
- Edit Image Dialog Box (Slant Correction)
- Retouch Image Dialog Box

- Color Adjustment Dialog Box
- Color Point Correction Dialog Box
- Backlight Correction Dialog Box
- Sharpness Dialog Box
- Soft Focus Dialog Box
- Logo Color Adjustment Dialog Box
- Fill and Stroke Dialog Box
- Set Shaded Text Dialog Box
- Set Shadow Dialog Box

Print Screen

- Print Screen
- Ambient Light Setting Dialog Box
- Managing Ambient Light Settings Dialog Box

Menu

- Export Dialog Box
- Set Grid and Guide Dialog Box
- Preferences Dialog Box
- Properties Dialog Box
- Customize Toolbar Dialog Box

Toolbar Buttons


- Artwork Manager Dialog Box
- Align and Distribute Objects Dialog Box
- Guide Position Dialog Box
- QR code Dialog Box

Main Screen

This is the main screen of PosterArtist. Use various functions in each area to edit posters, print them, and more.

>>>> Important

 Some functions are not available when using PosterArtist Lite. For details, see <u>Restrictions on Using</u> <u>PosterArtist Lite</u>.



- A: Task Area
- → B: Settings Panel for Each Task
- C: Poster Design Area
- → D: Temporary Tray
- ➡ E: Menu Bar
- F: Toolbars
- → G: Status Bar

A: Task Area

The task area contains four separate tasks. Posters can be created easily by completing each task in order.

In addition, view support information and download content from the lower part.

Select Template

➡ Select Template Screen

Paper Options

➡ Paper Options Screen

Edit

- ➡ Edit Screen (Photos)
- **➡** Edit Screen (Clipart)
- ➡ Edit Screen (Text)
- ➡ Edit Screen (Shapes)
- ➡ Edit Screen (Backgrounds)
- ➡ Edit Screen (Variable Data)

Print

➡ Print Screen

imagePROGRAF Support Info.

Displays our website for viewing the latest information for imagePROGRAF printers. Tips on poster creation are also available.

The button may not be displayed depending on the version of the printer driver.

Download Contents

Displays the website for downloading templates.

PosterArtist Manual

Opens this guide.

B: Settings Panel for Each Task

Click each task to switch the settings panel.

Select templates and images, or specify advanced print settings such as the print method and paper to use.

C: Poster Design Area

Displays the layout of the poster you are creating.

Design your poster here by arranging text, images, and other objects. You can also display the guide and ruler.

D: Temporary Tray

Templates and photos that you plan to use can be placed in the temporary tray.

This saves the trouble of searching through thumbnails.

E: Menu Bar

Displays the menu.

For details, see Menus and Commands.

Context menus are also available for efficient editing.

For more information, see Context Menus.

F: Toolbars

Displays buttons for frequently used functions. The toolbar is separated into two sections.

Main toolbar (upper):

Displays toolbar buttons for functions such as Artwork Manager Dialog, Print Preview, Use Image File, Align and Distribute Objects Dialog, and Show / Hide Guide and Grid.

Sub toolbar (lower):

Displays toolbar buttons for functions such as Resize Selection Tool, Rotation Selection Tool, Horizontal Text, Vertical Text, Line, QR Code, and Design Check.

For details, see Main Screen Toolbar.

>>> Important

• The toolbar button for vertical text may not be available for your language.

G: Status Bar

Displays the following.

General status

Displays general information about the status of the application, menus, toolbar buttons, and objects.

Paper size

Displays the paper size for the poster displayed in the poster design area.

Keyboard status

Displays the status of the Caps Lock, Num Lock, and Scroll Lock keys on the keyboard.


Select Template Screen

This is the screen for selecting a template to create your own posters.

To display the screen, click Select Template in the task area.

>>> Important

 Some functions are not available when using PosterArtist Lite. For details, see <u>Restrictions on Using</u> <u>PosterArtist Lite</u>.



>>> Note

For details on other areas of the screen, see <u>Main Screen</u>.

Open Poster...

Displays the Open Poster dialog box for opening posters you have created or you want to edit.

Auto Design...

Displays the <u>Auto Design screen</u> for creating designs automatically by simply entering titles and text, and then selecting your favorite images.

View All Templates...

Displays the View All Templates dialog box for viewing all the thumbnails in all templates by category.

Find Template...

Displays the <u>Find Template dialog box</u> for searching for templates by poster orientation or the number of photos that can be inserted.

Add to Templates...

Displays the <u>Saving Artwork dialog box (Templates)</u> for adding the displayed poster to the template library.




Changes the display size of thumbnails displayed in **Category**.

Category

Displays categories in which templates are saved as well as the thumbnails. Select a category to display the thumbnails.

Auto Design Screen

To display the screen, click **Auto Design...** in the **Select Template** screen. The screen switches three times as you proceed with the poster creation process.




Poster types

Select the type of poster you want to create from four patterns.

Next

Proceeds to the next screen.



Poster Type

Displays the poster type selected in the previous screen.

Design Image

Select the design you want to use from the list. Samples of the design theme appear under **Color** and **Font**.

>>> Note

Selectable items vary depending on the poster type.

Title

Enter the poster title (up to 60 characters).

Subtitle

Enter the poster subtitle (up to 60 characters).

Body

Enter text (up to 200 characters).



• If Long/Horizontal Banners is selected in poster type, text cannot be entered.

Organization

Enter the organization name (up to 60 characters).

Paper Orientation

Select Vertical or Horizontal.

Photos/Clipart

Displays the selected photos and clipart.

From File...

Displays the **Insert Image** dialog box. Select from images and clipart on your computer. To select multiple files, hold down the Ctrl or Shift key as you click them.



For supported file formats, see <u>Inserting Images and Materials</u>.
 In the **Insert Image** dialog box, only supported files are displayed.

From Temp. Tray...

Displays the **Show Images in the Temporary Tray** dialog box. Select the image(s) and clipart you want to use from the temporary tray. To select multiple files, hold down the Ctrl or Shift key as you click the thumbnails.



Changes the display size of thumbnails.

>>> Note

• For instructions on using the temporary tray, see <u>Using Temporary Tray when Editing Photos</u> or <u>Using Temporary Tray when Editing Clipart</u>.

From Photo Library...

Displays the **View All Photos** dialog box. Select the photo(s) you want to use. To select multiple files, hold down the Ctrl or Shift key as you click the thumbnails.



Changes the display size of thumbnails.

Download

Downloads photos that have not been downloaded, at once.

Add to Temporary Tray

Adds the selected photo(s) to the temporary tray. By placing photos in the temporary tray, you can use them as replacements easily. Multiple photos can be added to the temporary tray.

From Clipart Library...

Displays the **View All Clipart** dialog box. Select the clipart you want to use. To select multiple files, hold down the Ctrl or Shift key as you click the thumbnails.



Changes the display size of thumbnails.

Download

Downloads clipart that has not been downloaded, at once.

Add to Temporary Tray

Adds the selected clipart to the temporary tray. By placing clipart items in the temporary tray, you can use them as replacements easily. Multiple clipart items can be added to the temporary tray.

Delete

Deletes the image(s) selected from the **Photos/Clipart** list.

How To Use

Opens the guide that describes how to use the Auto Design function.

Reset

Resets all settings.

Advanced Settings...

Displays the Advanced setting dialog box.

Use fixed width font

From **Title**, **Subtitle**, **Body**, and **Organization name**, select the checkbox(es) of item(s) for which you want to fix the character width. Fixing the character width may improve the readability since single-byte and double-byte characters are aligned even over multiple lines.

return to a standard

Restores the state where only the **Body** checkbox is selected.

>>>> Important

• This may not be displayed depending on your language.

Back

Returns to the previous screen.

Next

Proceeds to the next screen.

Cancel

Cancels Auto Design and closes the Auto Design screen.

Design Image

Displays design themes automatically based on the settings specified in the previous screens.

The thumbnails of design patterns are displayed.

Color Patterns

Select the color pattern you like.

Text Color

Select the text color from the list.



(Small Size / Medium Size / Large Size)

Changes the display size of thumbnails.

Open the image replacement window / Close the image replacement window

Shows or hides the **Photos/Clipart** list.

Photos/Clipart

Displays a list of photos and clipart used in the poster.

Changing the order of thumbnails by dragging and dropping them recreates the design.

To select multiple files and change the order, hold down the Ctrl or Shift key as you click the thumbnails.

Reset

Resets all settings.

Add to Temporary Tray

Adds the selected design(s) to the temporary tray. By placing designs in the temporary tray, you can use them as replacements even after ending Auto Design. Multiple designs can be added to the temporary tray.

Back

Returns to the previous screen.

OK

Displays the selected design in the poster design area of the main screen. (Auto Design ends.)


Cancel

Cancels Auto Design and closes the **Auto Design** screen.

View All Templates Dialog Box

View a list of templates sorted by category.

To display the dialog box, click View All Templates... in the Select Template screen.



Templates

Displays the thumbnails of templates.



Changes the display size of thumbnails.

Category

A list of categories. Click a category to display its thumbnails at the top.

Download

Downloads templates that have not been downloaded, at once.

Add to Temporary Tray

Adds the selected template(s) to the temporary tray. By placing templates in the temporary tray, you can use them as replacements easily. Multiple templates can be added to the temporary tray.

OK

Displays the selected template in the poster design area of the main screen.

Cancel

Closes the View All Templates dialog box.


Note

 To view all provided templates, photos, clipart, photo frames, text graphics, and backgrounds, refer to Template Guide.

Find Template Dialog Box

Search templates by specifying the search criteria.

To display the dialog box, click **Find Template** in the **Select Template** screen.



Orientation

From the list, select the poster orientation to search for.

No. of Photos

From the list, select the number of photos that can be inserted in posters.



Changes the display size of thumbnails.

Thumbnail list

Displays the thumbnails of templates that match the search criteria.

Download

Downloads templates that have not been downloaded, at once.

Add to Temporary Tray

Adds the selected template(s) to the temporary tray. By placing templates in the temporary tray, you can use them as replacements easily. Multiple templates can be added to the temporary tray.

OK

Displays the selected template in the poster design area of the main screen.


Cancel

Closes the Find Template dialog box.

Saving Artwork Dialog Box (Templates)

Add created posters as templates.

To display the dialog box, click Add to Templates... in the Select Template screen.



Artwork type

Displays Templates.

Category

From the list, select the category for the template to be added.



• My Templates is provided as the category exclusively for users.

Add new category...

Add new categories.

Enter the category name in the displayed dialog box. The category will be added to the bottom of the list.

Set Use Period

Set the usage period for the template to be added.

Effective until

Click (Calendar) to display the Calendar dialog box for specifying the usage period.

>>> Important

• Once set, the usage period for added templates cannot be changed or canceled. To change or cancel the usage period, add the template again.

>>> Note

• The (Calendar) icon is displayed for the thumbnails of templates whose usage period is set.

Prohibit Editing

Protect the template from being edited.

>>> Important

• Once set, edit protection cannot be canceled. To edit, add the template again.

>>> Note

- The 🎉 (Not editable) icon is displayed for the thumbnails of templates protected from editing.
- Once the template is added, its thumbnail appears in the list; right-click the thumbnail to check the settings.

Restrictions Information...:


Selectable when the image is protected from being edited or when the usage period or a QR code is set.

Artwork Properties...:

Displays the **Artwork Properties** dialog box for checking the template information. Templates added by the user are displayed as **User Artwork**.

Design Assist Dialog Box

To display the **Design Assist** dialog box, click (Design Assist Area Set Mode) on the toolbar, and then select the area for which you want to adjust the layout in the poster design area.



Generated design

Displays the thumbnails of designs.



Changes the display size of thumbnails.

Open the image replacement window / Close the image replacement window

Shows or hides the Photos/Clipart list.

Photos/Clipart

Displays a list of photos and clipart used in the poster.

Changing the order of thumbnails by dragging and dropping them recreates the design.

To select multiple files and change the order, hold down the Ctrl or Shift key as you click the thumbnails.

Reset

Resets all settings.

Add to Temporary Tray

Adds the selected design(s) to the temporary tray. By placing designs in the temporary tray, you can use them as replacements even after ending Design Assist. Multiple designs can be added to the temporary tray.

OK

Displays the selected design in the poster design area of the main screen. (Design Assist ends.)

Cancel

Cancels Design Assist and closes the **Design Assist** dialog box.


Paper Options Screen

This is the screen for specifying the paper to print the poster on.

To display the screen, click Paper Options in the task area.

>>> Important

· Available functions and settings vary depending on your model.



Note

• For details on other areas of the screen, see Main Screen.

Page Size

Select the page size of the poster.

Set Custom Size...

Displays the Set Custom Size dialog box for specifying non-standard page sizes.

Poster Orientation

Select Portrait or Landscape.

Printer

Select the printer to use.

Note

· Only printers installed on your computer which are compatible with PosterArtist are displayed.

Media Source

Select the paper source from the list.

Media Type

Select the paper type from the list. Supported paper types vary depending on the printer.

Roll Paper Width

Select the width of roll paper loaded in the printer from the list. Selectable roll paper widths vary depending on the printer.

Reacquire Media Information

Sets **Media Type** and **Roll Paper Width** or **Media Size** based on the media information acquired from the printer driver.

>>> Note

• When Roll Paper is selected in Media Source, Roll Paper Width will be set, and when Cut Sheet is selected, Media Size will be set automatically.

Edit layout with Free Layout plus

Select this checkbox when printing at a larger size than roll paper.

Free Layout plus starts when printing. You can adjust the layout.

>>> Note

- This function is available only when the Free Layout plus application is installed. For details, refer to the Free Layout plus manual.
- When the checkbox is selected, the media size cannot be specified in PosterArtist.

Borderless Printing / Minimal Margin Printing

Select this checkbox when printing without borders.

>>> Note

- For some models, **Minimal Margin Printing** is displayed instead of **Borderless Printing**. When **Minimal Margin Printing** is displayed, printouts will have slight margins on the left and right sides.
- For borderless printing, select a roll paper width and paper type that support borderless printing. For the types of paper supporting borderless printing, refer to the manual of your printer.

Enlarged/Reduced Printing

Select this checkbox to scale the page size for printing.

Use the following settings for scaling.

Fit Long Side to Roll Width

The poster will be printed to scale so that the length of its long side will be the same as the width of the roll paper loaded in the printer.

If the poster is in portrait orientation, the poster height will match the roll paper width.

Fit Short Side to Roll Width

The poster will be printed to scale so that the length of its short side will be the same as the width of the roll paper loaded in the printer.

If the poster is in portrait orientation, the poster width will match the roll paper width.

Scaling

Specify the scale by entering a value or clicking ∧ (Up Arrow) or ∨ (Down Arrow).

Fit in Printable Area

Prints the poster by reducing the size of the poster to fit within the printable area of the paper.

Crop Marks

Prints crop marks in the poster's margins to indicate cutting positions.

>>> Note

• Crop marks cannot be printed when there are no margins on the paper to print on.

Media Size

Select the media size in the following cases.

When **Cut Sheet** is selected in **Media Source**When **Fit in Printable Area** is selected for **Enlarged/Reduced Printing**

>>> Note


• Apart from the above, the default **Media Size** is set to **Auto**. The media size is set automatically according to the current settings.

Set Custom Size...

Displays the <u>Set Custom Size dialog box</u> for specifying non-standard media sizes.

Set Custom Size Dialog Box

When printing the poster at non-standard paper sizes, specify the page size or media size. To display the dialog box, click **Set Custom Size...** in the **Paper Options** screen.




Short Side

Specify the length of the poster's short side.

Set to Roll Width

The length of the poster's short side will be the same as the width of the roll paper loaded in the printer. If the poster is in portrait orientation, the poster width will match the roll paper width.




Long Side

Specify the length of the poster's long side.

Set to Roll Width

The length of the poster's long side will be the same as the width of the roll paper loaded in the printer. If the poster is in portrait orientation, the poster height will match the roll paper width.



Maintain Aspect Ratio

Select this checkbox to maintain the poster's aspect ratio. When **Short Side** or **Long Side** is set, the value for the other is set automatically.

To set each aspect ratio manually, deselect the checkbox.


>>> Note

• To specify the largest size for the selected roll paper, enter the maximum value shown in the range in both **Short Side** and **Long Side**.

Edit Screen (Photos)

Edit, add, or replace photos.

To display the screen, click Edit in the task area, and then click Photos.



Add / Replace...

Displays the **Insert Image** dialog box for adding or replacing photos.

Add to Photos / Clipart...

Displays the Saving Artwork dialog box (Images) for adding photos or clipart to the library.

Edit Image



(Cut Out)

Displays the Cut Out dialog box for cutting out images.



(Trim)

Displays the Edit Image dialog box (Trim) for trimming images.



(Gradation)

Displays the Edit Image dialog box (Gradation) for applying gradation to images.



(Retouch Image)

Displays the Retouch Image dialog box for correcting image color levels.

Photos tab

Category

Select a photo category from the list. The thumbnails of templates in the selected category appear.



Displays the View All Photos dialog box for viewing all photos.

Image Search tab

Search Site

From the pull-down menu, select the stock photo service you want to use.

When you select a stock photo service name, the service logo appears.

Click a service logo to start a Web browser and display the home screen of the stock photo service site.

Important

When using a stock photo service for the first time, you must read the license and privacy policy.
 To use the stock photo service, agree to them by clicking I understand.

Q (Search)

Enter a keyword for the image you want to search for, and then click Q (Search) to display the thumbnails of the images related to the keyword.

>>> Important

· Image search supports JPEG and PNG images.

Note

- When you click Q (Search) with the search window empty, images recommended by the service site appear.
- When you place the cursor over a thumbnail in the search results and click (Image Information), a Web browser starts and the image information appears.
- When you switch the stock photo service with the search results displayed, a new image search
 will be performed based on the keyword that was entered into the search window before switching
 the service, and then new search results will appear.

Frames tab

Category

Select a frame category from the list. The thumbnails of templates in the selected category appear.



(View All Frames)

Displays the View All Frames dialog box for viewing all frames.

Frame Color

Displays the current frame color and basic colors. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.

Regular color

Displays the current color or basic colors in the four-color palette.

Spot color

Displays available fluorescent colors in the four-color palette.

>>> Important


• Fluorescent spot colors cannot be used depending on your model or paper type.

 Fluorescent spot colors cannot be used when the Edit layout with Free Layout plus checkbox is selected in the Paper Options screen.

Edit Palette...

Click to display the **Edit Spot Color Palette** dialog box for editing the colors that appear in the palette.

Edit Spot Color Palette dialog box



Select the four colors you want to display in the **Spot color** palette.

Select the color you want to edit in the palette under **Current settings**, and then select the color you want to display in the palette from **Fluorescent spot color**.


>>>> Note

• The four colors that appear in the **Spot color** palette are retained on the printer.

Edit Screen (Clipart)

Add clipart to the poster or replace the added clipart.

To display the screen, click Edit in the task area, and then click Clipart.



Add / Replace...

Displays the Insert Image dialog box for adding or replacing clipart.

Add to Clipart...

Displays the Saving Artwork dialog box (Images) for adding clipart to the library.

Convert to bitmap and edit...

Displays the Fill dialog box for filling specified areas with colors.

>>> Important

• If you edit clipart by clicking **Convert to bitmap and edit...**, you cannot change the color of the clipart with **Clipart Color**. To edit the color again, open the <u>Fill dialog box</u> and change the color.

Category

Select a clipart category from the list. The thumbnails of templates in the selected category appear.



(View All Clipart)

Displays the View All Clipart dialog box for viewing all clipart.

Clipart Color

Displays the current clipart color and basic colors. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.

Regular color

Displays the current color or basic colors in the four-color palette.

Spot color

Displays available fluorescent colors in the four-color palette.


>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the **Edit layout with Free Layout plus** checkbox is selected in the **Paper Options** screen.

Edit Palette...

Click to display the **Edit Spot Color Palette** dialog box for editing the colors that appear in the palette.

Edit Spot Color Palette dialog box



Select the four colors you want to display in the **Spot color** palette.

Select the color you want to edit in the palette under **Current settings**, and then select the color you want to display in the palette from **Fluorescent spot color**.

>>> Note

• The four colors that appear in the **Spot color** palette are retained on the printer.


Edit Screen (Text)

Add text to posters. Decorate the added text as needed.

To display the screen, click **Edit** in the <u>task area</u>, and then click **Text**.

>>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the **Edit layout with Free Layout plus** checkbox is selected in the **Paper Options** screen.





Add horizontal text.



Add vertical text.

Edit tab

Font

Select the font type.

Font Size

Select the font size. You can also set by entering a value directly.

Text Alignment



Specify how you want to align text.



Position the text evenly across the text box.

Line Spacing

Select the line spacing.

Increase the value to widen the space between lines and decrease the value to narrow it.

Character Spacing

Specify the character spacing.

Increase the value to widen the space between characters and decrease the value to narrow it.

Word Wrap

Wrap text at the end of a line automatically.

Text Color

Displays the current text color and basic colors. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.

Regular color

Displays the current color or basic colors in the four-color palette.


Spot color

Displays available fluorescent colors in the four-color palette.

Edit Palette...

Click to display the **Edit Spot Color Palette** dialog box for editing the colors that appear in the palette.

Edit Spot Color Palette dialog box



Select the four colors you want to display in the **Spot color** palette.

Select the color you want to edit in the palette under **Current settings**, and then select the color you want to display in the palette from **Fluorescent spot color**.

Note

• The four colors that appear in the **Spot color** palette are retained on the printer.

Text Style



Make the text italic or bold. Underline the text as needed.

Text Effects



(Fill and Stroke)

Displays the <u>Fill and Stroke dialog box</u> for applying a single or double outline to the text and specifying the width, shape, and color of the outline.



(Shaded Text)

Displays the <u>Set Shaded Text dialog box</u> for specifying the drop shadow settings such as color, distance, angle, opacity, and softening.

Text Graphics tab

Category

Select a text graphic category from the list. The thumbnails of templates in the selected category appear.



(View All Text Graphics)

Displays the View All Text Graphics dialog box for viewing all text graphics.

Text Graphic Color

Displays the current text graphic color and basic colors. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.



• Regular color, Spot color, and Edit Palette... can be specified in the same way as Text Color.


Edit Screen (Shapes)

Add straight lines, circles, rectangles, arrows, and other shapes to posters.

To display the screen, click Edit in the task area, and then click Shapes.

>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the Edit layout with Free Layout plus checkbox is selected
 in the Paper Options screen.






Drag the crosshair pointer to add a line or arrow.

Note

• To draw a horizontal line, vertical line, or a line angled at a multiple of 15 degrees, hold down the Shift key as you drag the pointer.



- To set the clicked point as the center point, hold down the Ctrl key as you drag the pointer.
- To draw a horizontal line, vertical line, or a line angled at a multiple of 15 degrees with the clicked point set as its center point, hold down the Shift and Ctrl keys as you drag the pointer.





(Rectangle)


Drag the crosshair pointer to add a rectangle.

>>> Note

• To draw a square, hold down the Shift key as you drag the pointer.



- To set the clicked point as the center point, hold down the Ctrl key as you drag the pointer.
- To draw a square with the clicked point set as its center point, hold down the Shift and Ctrl keys as you drag the pointer.





(Ellipse)


Drag the crosshair pointer to add a circle or ellipse.

>>> Note

• To draw a circle, hold down the Shift key as you drag the pointer.



- To set the clicked point as the center point, hold down the Ctrl key as you drag the pointer.
- To draw a circle with the clicked point set as its center point, hold down the Shift and Ctrl keys as you drag the pointer.



Line Thickness

Specify the line thickness. Enter the value directly.

Drop Shadow

Displays the <u>Set Shadow dialog box</u> for adding a drop shadow to the shape.



• In the <u>Set Shadow dialog box</u>, you can specify a fluorescent spot color for the drop shadow color.

Line Type

Select the line type from the list.

Line Color / Fill-in Color

Displays the current line or fill color and basic colors. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.



• Fill-in Color appears when a rectangle or ellipse is selected.

Regular color

Displays the current color or basic colors in the four-color palette.


Spot color

Displays available fluorescent colors in the four-color palette.

Edit Palette...

Click to display the **Edit Spot Color Palette** dialog box for editing the colors that appear in the palette.

Edit Spot Color Palette dialog box



Select the four colors you want to display in the **Spot color** palette.

Select the color you want to edit in the palette under **Current settings**, and then select the color you want to display in the palette from **Fluorescent spot color**.



• The four colors that appear in the **Spot color** palette are retained on the printer.

Opacity

Specify the opacity of Fill-in Color.

Increase the value to increase opacity and decrease the value to increase transparency.

Start Point Shape / End Point Shape

Select the shape of the starting point or ending point.

Size

Select the size of the starting point or ending point from Small, Medium, and Large.

>>> Note

· Appears when a line is selected.

Corner Shape

Select the corner shape.

Radius

When the round shape is selected for **Corner Shape**, specify the roundness as needed.

>>> Note

· Appears when a rectangle is selected.




(All Map Symbols)

Displays a dialog box for viewing all map symbols.

Edit Screen (Backgrounds)

Set the poster background.

To display the screen, click Edit in the task area, and then click Backgrounds.



Category

Select a background category from the list. The thumbnails of backgrounds in the selected category appear.



(View All Backgrounds)

Displays the View All Backgrounds dialog box for viewing all backgrounds.

Background Color

Displays the current background color and basic colors. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.

Regular color

Displays the current color or basic colors in the four-color palette.

Spot color

Displays available fluorescent colors in the four-color palette.

>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the **Edit layout with Free Layout plus** checkbox is selected in the **Paper Options** screen.


Note

• To create a gradation with fluorescent spot colors, use Vivid mode.

Edit Palette...

Click to display the **Edit Spot Color Palette** dialog box for editing the colors that appear in the palette.

Edit Spot Color Palette dialog box



Select the four colors you want to display in the **Spot color** palette.


Select the color you want to edit in the palette under **Current settings**, and then select the color you want to display in the palette from **Fluorescent spot color**.

>>> Note

• The four colors that appear in the **Spot color** palette are retained on the printer.

Set Margins...


Displays the **Background Margins** dialog box for specifying the top, bottom, left, and right margins.



Edit Screen (Variable Data)

Automatically substitute text and images on the poster by using tabular data.

To display the screen, click Edit in the task area, and then click Variable Data.



Connect to...

Displays the **Open Data Source** dialog box for specifying the location to save the tabular data.

Disconnect Data

Cancels the link to the tabular data and disables the variable printing settings.

Connected to

Displays the name of the linked tabular data file.

Connected Data

Displays the field names that indicate the data type of the read tabular data.

Select a field name to link the selected text string or image to the corresponding record.

>>> Note

- To cancel the link, select Unselected.
- To substitute images, select the field name of the file paths to the target images.

Text alignment

Align the text of each record.

For horizontal text, select left, center, or right. For vertical text, select top, center, or bottom.

>>> Important

· Settings for vertical text are not available depending on your language.

Text format

Format the text of each record.

Ambient Light Settings


Change the ambient light setting.

Ambient Light Field

Select the field name for which you want to change the ambient light setting.

Filter Records...

Displays the Filter Records dialog box for setting the number of copies to print.



>>> Note

- To exclude from the data to be printed, deselect the **Print** checkbox.
- To change the number of prints, double-click **Copies**, and then enter the value directly or click ∧ (Up Arrow) or ∨ (Down Arrow) on the right to increase or decrease the number.

Selected Records

Displays the number of records to be printed.

Record Number

Displays the number of the record displayed in the poster design area.

Click (Previous) or (Next) to check that the text string or image is replaced with each record.

Saving Artwork Dialog Box (Images)


Add photos, clipart, shapes, and other objects.

Display the Saving Artwork dialog box by one of the following operations.

Click Edit in the task area, select Photos, and then click Add to Photos / Clipart....

In the task area, select Clipart in Edit, and then click Add to Clipart....

Right-click an image in the poster design area, and then click Add to Photos / Clipart....



Artwork type

Select the artwork type.

Select **Photos** or **Clipart** according to the content of artwork to be added.

Photos: Photos

Clipart: Clipart, shapes, text, and QR codes

Category

From the list, select the category for the artwork to be added.



• My Images and My Clipart are provided as the categories exclusively for users.

Add new category...

Add new categories.

Enter the category name in the displayed dialog box. The category will be added to the bottom of the list.

Set Use Period

Set the usage period for the artwork to be added.

Effective until

Click (Calendar) to display the **Calendar** dialog box for specifying the usage period.

>>> Important

• Once set, the usage period for added artwork cannot be changed or canceled. To change or cancel the usage period, add the template again.

Prohibit Editing

Protect the artwork from being edited.

>>> Important

• Once set, edit protection cannot be canceled. To edit, add the template again.

Note

• Once the artwork is added, its thumbnail appears in the list; right-click the thumbnail to check the settings.

Restrictions Information...:

Selectable when the image is protected from being edited or when the usage period or a QR code is set.

Artwork Properties...:

Displays the **Artwork Properties** dialog box for checking the artwork information. Artwork added by the user is displayed as **User Artwork**.

Cut Out Dialog Box

Isolate the area you want to keep in a photo and discard the rest such as the background.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to edit on the poster.

To display the Cut Out dialog box, click



(Cut Out) in Edit Image.





Click (Zoom In) or (Zoom Out) to enlarge or reduce the display size. You can also enlarge or reduce the display size by specifying the scale.

color of area remain

Specify the color to fill the area to cut out when the original image that has not been cut out is displayed in the preview. The color can be changed in the **Color** dialog box displayed by clicking **Custom...**.

Preview

Switch the preview between the original image that has not been cut out and the cut out image. When the button is off, the original image is displayed; when on, the cut out image is displayed.

Auto tab

Tolerance

Adjust the extent of the area to retain.

To retain a larger area, move the slider to the right (because more colors are judged similar).

To erase a larger area, move the slider to the left (because fewer colors are judged similar).

You can also set by entering a value directly.

Blur edge

Blurs the edges of cut out portions.


Manual tab



(Specify by color and cut)

Retains the area whose color is similar to the color specified on the image.

In **Tolerance**, set a larger value to retain a larger area and set a smaller value to erase a larger area.






(Specify by area and cut)

Retains the area you outline freehand or by drawing a polygon.

Select Freehand or Shape in Mode, and then outline the area you want to retain.

Drag on the image to outline the area, or click to specify the vertices of the polygon and doubleclick when you have finished drawing.






(Specify by line and cut)

Retains the area you trace freehand or by drawing a polyline.

Select **Brush** or **Line** in **Mode**, and then trace the area you want to retain.

The thickness of the brush and polyline can be specified in Size.

Drag on the image to trace the area, or click to specify the vertices of the polyline and double-click when you have finished drawing.






(Specify by color and clear)

Erases the area whose color is similar to the color specified on the image.

In **Tolerance**, set a larger value to erase a larger area and set a smaller value to retain a larger area.






(Specify by area and clear)

Erases the area you outline freehand or by drawing a polygon.

Select Freehand or Shape in Mode, and then outline the area you want to erase.

Drag on the image to outline the area, or click to specify the vertices of the polygon and doubleclick when you have finished drawing.






(Specify by line and clear)

Erases the area you trace freehand or by drawing a polyline.

Select **Brush** or **Line** in **Mode**, and then trace the area you want to erase.

The thickness of the brush and polyline can be specified in Size.

Drag on the image to trace the area, or click to specify the vertices of the polyline and double-click when you have finished drawing.




Blur edge

Blurs the edges of cut out portions.

Invert Selection

Switches the area to erase and area to retain.



Undo

Undoes the last operation.

Redo

Redoes the last undone correction.

Reset

Cancels the cut out effect.

Help

Fill Dialog Box

Change the color of a specified area of an object or image.

Display the **Fill** dialog box by one of the following operations.


Click Edit in the task area, click Photos, select the image you want to edit (such as a photo) on the poster,

click (Retouch Image) in **Edit Image**, and then click (Fill) in the displayed **Retouch Image** dialog box.

Right-click the image you want to edit (such as a photo) on the poster, and then click **Retouch Image...** > **Fill**.

Click **Edit** in the task area, click **Clipart**, select the clipart you want to edit on the poster, and then click **Convert to bitmap and edit...**.

Right-click the clipart you want to edit on the poster, and then click Retouch Image....





Click (Zoom In) or (Zoom Out) to enlarge or reduce the display size. You can also enlarge or reduce the display size by specifying the scale.

Select color

Displays the current object or image color and basic colors. To use other colors, click **Custom...**, and then select a color in the displayed dialog box.

Regular color

Displays the current color or basic colors in the four-color palette.

Spot color

Displays available fluorescent colors in the four-color palette.


>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the **Edit layout with Free Layout plus** checkbox is selected in the **Paper Options** screen.

Edit Palette...

Click to display the **Edit Spot Color Palette** dialog box for editing the colors that appear in the palette.

Edit Spot Color Palette dialog box



Select the four colors you want to display in the **Spot color** palette.

Select the color you want to edit in the palette under **Current settings**, and then select the color you want to display in the palette from **Fluorescent spot color**.

Note

• The four colors that appear in the **Spot color** palette are retained on the printer.


Area selection mode



(Auto Select Based on Clicked Color)

Change the color by automatically selecting an area whose color is similar to the color specified on the image.

In **Tolerance**, increase the value to change a larger area and decrease the value to narrow the area.






(Select Area Manually)

Change the color of the area you outline freehand or by drawing a polygon.

Select Freehand or Shape in Mode, and then outline the area whose color you want to change.

Drag on the image to outline the area, or click to specify the vertices of the polygon and double-click when you have finished drawing.



Undo

Undoes the last operation.

Redo

Redoes the last undone correction.

Reset

Restores the original state (the state before changing the colors).

Help

Edit Image Dialog Box (Trim)

Select and display the area you want to keep in an image.

>>> Important


- · Trimming photos does not edit the original photos.
- Trimming is canceled if the photo is replaced with another photo.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to edit on the poster.

To display the **Edit Image** dialog box and preview panel, click



(Trim) in **Edit Image**



Orange frame (trimming area)

Represents the trimming area.

To resize the frame for the trimming area, drag \checkmark (Arrow) in the corners.

To move the frame for the trimming area, drag \clubsuit (Crosshair) that appears when you point inside the frame.

>>> Note

• To change the frame orientation from portrait to landscape and vice versa, rotate the orange frame by clicking \bigcirc (Rotation).

Reset Trim

Resets the trimming area.

Undo

Undoes the last operation.

Redo

Redoes the last undone correction.

Help

Edit Image Dialog Box (Gradation)


Apply a gradation to photos.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to edit on the poster.

To display the Edit Image dialog box and preview panel, click



(Gradation) in Edit Image.



Opacity



(Set Opacity to Background)

Apply transparency to the entire photo by specifying the opacity.

Increase the value to increase opacity and decrease the value to increase transparency.

Gradation Orientation

Specify the direction of the gradation.



Colors fade from left to right.





Colors fade from the upper left to the lower right.



(Upper Right to Lower Left)

Colors fade from the upper right to the lower left.



(Top to Bottom)

Colors fade from the top to the bottom.



>>>> Note

• To remove the gradation, click the selected Gradation Orientation again.

Number of Points in Gradation

Select whether to apply a gradation with midpoints.

To use midpoints, select **Three Points**. Midpoints (C1 and C2) appear in the preview; use them to make the gradation more variable.

Point A Opacity

Specify the opacity of starting point.

Increase the value to increase opacity and decrease the value to increase transparency.

Point B Opacity

Specify the opacity of ending point.

Increase the value to increase opacity and decrease the value to increase transparency.

Point C Opacity

Specify the opacity of midpoints.

Increase the value to increase opacity and decrease the value to increase transparency.



• Selectable when Three Points is selected for Number of Points in Gradation.

Undo

Undoes the last operation.

Redo

Redoes the last undone correction.

Help

Edit Image Dialog Box (Slant Correction)

Correct slant of images.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to retouch on the poster.

To display the **Edit Image** dialog box and preview panel, click




(Trim) in Edit Image.

In the **Edit Image** dialog box, click



(Slant Correction).



Slant Correction Method

Correct slant of images.

Select from Auto, Manual, and Specify Angle.

Offset Angle

To specify an angle, select **Specify Angle**.

Reset Slant Correction

Cancels slant correction.

Undo

Undoes the last operation.

Redo

Redoes the last undone correction.

Help

Retouch Image Dialog Box

Correct photos, apply effects to photos to create a particular mood in photos, adjust the colors, and use other retouching features to enhance your posters.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to retouch on the poster.

To display the **Retouch Image** dialog box, click



(Retouch Image) in Edit Image.

Note

• Alternatively, right-click the image you want to edit (such as a photo) on the poster, and then click **Retouch Image...** to display the **Retouch Image** dialog box.



Auto Color Correction

Automatically retouch image color levels.

Color Adjustment

Displays the Color Adjustment dialog box for retouching image color levels manually.

Color Point Correction

Displays the <u>Color Point Correction dialog box</u> for adjusting the brightness based on the brightest point in the image (white point), the point of intermediate brightness (gray point), or the darkest point (black point).

Backlight Correction

Displays the <u>Backlight Correction dialog box</u> for correcting backlit images or blown-out highlights in images.

Sharpness

Displays the Sharpness dialog box for sharpening image edges.

Soft Focus

Displays the Soft Focus dialog box for blurring images to create a softer effect.

Monochrome

Converts images to monochrome.

Sepia

Converts images to sepia.

Logo Color Adjustment

Displays the Logo Color Adjustment dialog box for adjusting a portion of the logo image colors.

Cut Out

Displays the <u>Cut Out dialog box</u> for discarding the unwanted areas such as the background.

Fill

Displays the Fill dialog box for changing the colors of the specified areas of the object or image.

Undo

Undoes the last operation.

Redo

Redoes the last undone correction.


Help

Color Adjustment Dialog Box

Correct image color levels.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to retouch on the poster.

To display the **Retouch Image** dialog box, click (Retouch Image) in **Edit Image**. To display the **Color Adjustment** dialog box, click **Color Adjustment**.



Original Image

Displays the original image.

Touched Up Image

Displays the retouched image.



Click (Zoom In) or (Zoom Out) to enlarge or reduce the display size. You can also enlarge or reduce the display size by specifying the scale.

Quality

Brightness

Adjust the overall image brightness.

Adjust within the range of -100 to 100; move the slider to the right to brighten and left to darken. You can also set by entering a value directly.

Contrast

Adjust the overall image contrast.

Adjust within the range of -100 to 100; move the slider to the right to increase and left to decrease the contrast. You can also set by entering a value directly.

Saturation

Adjust the overall image vividness.

Adjust within the range of -100 to 100; move the slider to the right to increase and left to decrease the vividness. You can also set by entering a value directly.

Color Settings

Increase Red / Increase Cyan

Adjust the balance of red and cyan. Adjust within the range of -100 to 100; move the slider to the right to increase cyan and left to increase red. You can also set by entering a value directly.

Increase Green / Increase Magenta

Adjust the balance of green and magenta. Adjust within the range of -100 to 100; move the slider to the right to increase magenta and left to increase green. You can also set by entering a value directly.

Increase Blue / Increase Yellow

Adjust the balance of blue and yellow. Adjust within the range of -100 to 100; move the slider to the right to increase yellow and left to increase blue. You can also set by entering a value directly.

Reset

Restores the original image.


Help

Color Point Correction Dialog Box

Adjust the overall brightness based on the brightest point in the image (white point), the point of intermediate brightness (gray point), or the darkest point (black point).

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to retouch on the poster.

To display the **Retouch Image** dialog box, click (Retouch Image) in **Edit Image**. To display the **Color Point Correction** dialog box, click **Color Point Correction**.



Original Image

Displays the original image.

Touched Up Image

Displays the retouched image.



Click (Zoom In) or (Zoom Out) to enlarge or reduce the display size. You can also enlarge or reduce the display size by specifying the scale.

Auto

Automatically adjust the image brightness.



• Click Auto to produce the same results as Auto Color Correction in the Retouch Image dialog box.

White Point

Adjusts the brightness based on the brightest point in the image under Original Image.

Gray Point

Adjusts the brightness based on the point of intermediate brightness in the image under **Original Image**.

Black Point

Adjusts the brightness based on the darkest point in the image under **Original Image**.

Reset

Restores the original image.

Help

Backlight Correction Dialog Box

Correct backlit images.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to retouch on the poster.

To display the **Retouch Image** dialog box, click (Retouch Image) in **Edit Image**. To display the **Backlight Correction** dialog box, click **Backlight Correction**.



Original Image

Displays the original image.

Touched Up Image

Displays the retouched image.



Click (Zoom In) or (Zoom Out) to enlarge or reduce the display size. You can also enlarge or reduce the display size by specifying the scale.

Auto Adjust For Faces

Automatically adjust the brightness based on people's faces.

Level

Over / Backlight

Move the slider toward **Backlight** to brighten areas that are dark.

Move the slider toward **Over** to darken areas that are too bright.

You can also set by entering a value directly.

Reset

Restores the original image.


Help

Sharpness Dialog Box

Sharpen image edges.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to retouch on the poster.

To display the **Retouch Image** dialog box, click (Retouch Image) in **Edit Image**. To display the **Sharpness** dialog box, click **Sharpness**.



Original Image

Displays the original image.

Touched Up Image

Displays the retouched image.



Click (Zoom In) or (Zoom Out) to enlarge or reduce the display size. You can also enlarge or reduce the display size by specifying the scale.

Level

Adjust the level of image edge sharpness.

Adjust within the range of 0 to 100; move the slider to the right to increase sharpness. You can also set by entering a value directly.

Reset

Restores the original image.


Help

Soft Focus Dialog Box

Blur images to create a softer effect.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to retouch on the poster.

To display the **Retouch Image** dialog box, click (Retouch Image) in **Edit Image**. To display the **Soft Focus** dialog box, click **Soft Focus**.



Original Image

Displays the original image.

Touched Up Image

Displays the retouched image.



Click (Zoom In) or (Zoom Out) to enlarge or reduce the display size. You can also enlarge or reduce the display size by specifying the scale.

Level

Adjust the level of blur.

Adjust within the range of 0 to 100; move the slider to the right to increase blur and left to reduce it. You can also set by entering a value directly.

Reset

Restores the original image.


Help

Logo Color Adjustment Dialog Box

Adjust a portion of the logo image colors.

Click **Edit** in the <u>task area</u>, click **Photos**, and then select the image you want to retouch on the poster.

To display the **Retouch Image** dialog box, click (Retouch Image) in **Edit Image**. To display the **Logo Color Adjustment** dialog box, click **Logo Color Adjustment**.



Original Image

Displays the original image.

The color of a portion you click on the image will be adjusted.

Touched Up Image

Displays the retouched image.



Click (Zoom In) or (Zoom Out) to enlarge or reduce the display size. You can also enlarge or reduce the display size by specifying the scale.

Color Table

Displays a list of colors used in the logo.

Color Settings

Adjust the color intensity of the image.

Adjust within the range of -100 to 100; move the slider to adjust the color intensity. You can also adjust by entering a value directly.

Hue

Adjust the image's overall color tone.

Adjust within the range of -100 to 100; move the slider to the right to emphasize and left to weaken the color tone. You can also set by entering a value directly.

Saturation

Adjust the overall image vividness.

Set within the range of -100 to 100; move the slider to the right to increase and left to decrease the vividness. You can also set by entering a value directly.

Luminance

Adjust the overall image brightness.

Set within the range of -100 to 100; move the slider to the right to brighten and left to darken. You can also set by entering a value directly.

Reset

Restores the original image.

Help

Fill and Stroke Dialog Box


Outline text.

Click **Edit** in the <u>task area</u>, click **Text**, and then select the text (or text box of the text) you want to outline on the poster.

To display the **Fill and Stroke** dialog box, on the **Edit** tab, click (Fill and Stroke) in **Text Effects**.

>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the **Edit layout with Free Layout plus** checkbox is selected in the **Paper Options** screen.



Text Color

The color specified in the settings panel in the **Edit** screen (Text) is reflected.

To change the text color, click **Custom...**, **Change to Spot Color...**, or **Change to Regular Color...**, and then select a color in the displayed dialog box.

Inner Stroke / Outer Stroke

Apply a single or double outline to the text.

Width


Specify the outline width.

Enter a value (0.10 to 100.00) directly. Alternatively, click \land (Up Arrow) or \lor (Down Arrow) on the right to increase or decrease the value.

Corner Shape

Specify the outline shape.

Select from Round, Square, and Bevel.



Color

Specify the outline color.


Click **Custom...**, **Change to Spot Color...**, or **Change to Regular Color...**, and then select a color in the displayed dialog box.

Set Shaded Text Dialog Box

Add a drop shadow to text.

Click **Edit** in the <u>task area</u>, click **Text**, and then select the text (or text box of the text) you want to add a shadow to on the poster.

To display the **Set Shaded Text** dialog box, on the **Edit** tab, click (Shaded Text) in **Text Effects**.



Drop Shadow

Add a drop shadow to text.

Color

Specify the shadow color.

Click **Custom...**, **Change to Spot Color...**, or **Change to Regular Color...**, and then select a color in the displayed dialog box.

>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type.
- Fluorescent spot colors cannot be used when the **Edit layout with Free Layout plus** checkbox is selected in the **Paper Options** screen.

Distance

Specify the distance between the text and shadow.

Angle

Specify the shadow angle.

Opacity

Specify the shadow opacity.

Increase the value to make shadows darker and decrease the value to make shadows lighter.

>>> Important

• Opacity cannot be set when a fluorescent spot color is specified for the drop shadow color.

Fade Shadows

Softens the shadow.

>>> Important

• Shadows cannot be softened when a fluorescent spot color is specified for the drop shadow color.

Radius

Specify the degree of shadow softening.


Increase the value to soften shadows more and decrease the value to emphasize shadows.

Set Shadow Dialog Box

Add a drop shadow to shapes.

Click **Edit** in the <u>task area</u>, click **Shapes**, and then select the shape you want to add a shadow to on the poster.

To display the **Set Shadow** dialog box, click (Drop Shadow) in **Dropshadow**.



Drop Shadow

Add a drop shadow to the shape.

Color

Specify the shadow color.

Click **Custom...**, **Change to Spot Color...**, or **Change to Regular Color...**, and then select a color in the displayed dialog box.

>>> Important

- Fluorescent spot colors cannot be used depending on your model or paper type. In addition, fluorescent spot colors cannot be used in the following cases.
- Opacity is set for Fill-in Color of the object.
- The Edit layout with Free Layout plus checkbox is selected in the Paper Options screen.

Distance

Specify the distance between the shape and shadow.

Angle

Specify the shadow angle.

Opacity

Specify the shadow opacity.

Increase the value to make shadows darker and decrease the value to make shadows lighter.

>>> Important

• Opacity cannot be set when a fluorescent spot color is specified for the drop shadow color.

Fade Shadows

Softens the shadow.

Radius

Specify the degree of shadow softening.

Increase the value to soften shadows more and decrease the value to emphasize shadows.

>>> Important

• Shadows cannot be softened when a fluorescent spot color is specified for the drop shadow color.


Print Screen

Specify or check print settings before printing.

To display the screen, click **Print** in the task area.

>>> Important

Available functions and settings vary depending on your model or paper type.



Test Print

Before printing at the actual size, test print your poster on A4 or Letter size paper.

>>> Important

- Some printer features, such as borderless printing (or minimal margin printing) and print quality are not available when test printing.
- · Ambient light settings are not applied.

Note

• For instructions on selecting the printer to use for test printing, see Preferences Dialog Box.

Printer / Media Source / Media Type / Roll Paper Width / Borderless Printing / Minimal Margin Printing / Enlarged/Reduced Printing / Crop Marks / Media Size

Settings made in the Paper Options screen are displayed.

>>> Note

- To change the settings, see Paper Options Screen.
- For some models, **Minimal Margin Printing** is displayed instead of **Borderless Printing**. When **Minimal Margin Printing** is displayed, printouts will have slight margins on the left and right sides.

Print Quality

Select the print quality.

Matching Method

Select a rendering intent.

Perceptual (Photo)

Select this when you want to print with an impression close to that on the monitor since the characteristics of the data displayed on the monitor will be reflected correctly.

Saturation (Poster)

Select this when you want to print posters, business documents, and other items that require attractiveness or reader-friendly graphs.

Use fluorescent ink

Vivid mode

Prints the entire image in vivid color tones using fluorescent ink.

Spot mode

Print after specifying areas (text, shapes, or other objects) in which to use fluorescent ink.

Use Free Layout

Use the Free Layout function. Import print data from various applications and move, align, enlarge/reduce, or rotate each data to adjust the layout before printing.

>>> Note

- This does not appear when the Edit layout with Free Layout plus checkbox is selected in the Paper Options screen, or depending on your printer driver.
- For details on the Free Layout function, refer to the Online Manual for your model.

Check Print Preview Before Printing

imagePROGRAF Preview starts and you can check the print result in the preview before printing.



· For details on imagePROGRAF Preview, refer to the Online Manual for your model.

Use Ambient Light Setting

Adjust colors according to the environment to visually enhance the poster's color tones.

>>> Important

• This function is unavailable depending on the type of your paper.

Copies

Set the number of copies to print.

Print

Starts printing after the **Print Progress** dialog box appears.

>>> Note

• When the **Edit layout with Free Layout plus** checkbox is selected in the **Paper Options** screen, **Print** (**Start Free Layout plus**) is displayed instead of the Print button; click to start Free Layout plus. For details on Free Layout plus, refer to the Online Manual for your model.

Ambient Light Setting Dialog Box

Automatically adjust colors according to the environment to visually enhance the poster's color tones.

Display the Print screen from the task area, and then select the Use Ambient Light Setting checkbox.

The displayed screen varies depending on the item selected in the ambient light setting list.


>>> Important

- This function cannot be used depending on your printer or paper type.
- This function requires the "i1" light meter and the Light Source Measure Tool. Download the "i1" light meter
 or the Light Source Measure Tool from our website, and then install it on the computer used for measuring
 ambient light.

Note

• For instructions on measuring the light source type and color temperature, refer to "LightSourceMeasureTool_English.pdf" supplied with the Light Source Measure Tool.

When Custom Settings Is Selected



Lighting Source Type

Select the light source type measured with the Light Source Measure Tool.

Color Temperature

Specify the color temperature measured with the Light Source Measure Tool.

When By selecting a chart number Is Selected




Chart Number

Check printed charts and select the desired chart number.

Note

• Check printed charts in the environment where the poster is displayed.


Color Temperature

Specify the color temperature measured at monitor calibration.

Illuminance

Specify the illuminance measured at monitor calibration.

When By entering values directly Is Selected



Lighting Source Type

Select the light source type measured with the Light Source Measure Tool.

Color Temperature

Specify the color temperature measured with the Light Source Measure Tool.


Illuminance

Specify the illuminance measured with the Light Source Measure Tool.

Managing Ambient Light Settings Dialog Box

Add ambient light settings under a name of your choice. By adding ambient light settings, you can quickly print posters according to the environment where they are displayed.

To display the **Managing Ambient Light Settings** dialog box, click **Managing Ambient Light Settings...** in the **Tool** menu.



Ambient Light Settings

Displays a list of ambient light settings.

Custom Ambient Light Setting

Set the name of the ambient light setting.

Chart Number

Select a chart number.

Delete

Deletes the selected ambient light setting.



- Chart Number 1 to Chart Number 4 and Custom Settings cannot be deleted.
- When multiple instances of PosterArtist are running, ambient light settings cannot be deleted.

Add

Add the ambient light setting with the specified settings. Once added, the setting appears under **Ambient Light Setting**.

>>> Note

• Added ambient light settings appear in the ambient light setting list in the **Print** screen.

List

Displays the Ambient Light Setting List dialog box for viewing ambient light settings.


Help

Opens this guide.

Export Dialog Box

Export artwork added to the library as a single file (with a .cptx extension).

To display the **Export** dialog box, click **Export...** in the **File** menu.



Library tabs

Switch between the Templates, Photos, Clipart, and Backgrounds tabs.

Category

Displays a list of categories in the library.

Show

Change the type of displayed artwork.

All Artwork

Displays all artwork.

User Artwork

Displays artwork added by the user.

Library Artwork

Displays the pre-installed artwork.

Artwork with Expiration Date

Displays artwork whose usage period is set.

Artwork with Edit Restriction

Displays artwork whose edit restrictions are set.



Changes the display size of thumbnails.

Artwork

Displays the thumbnails of artwork in the library.

Add

Select the artwork you want to export, and then click **Add** to add it to **Item to be exported**.

>>> Note

- Up to 200 artwork items can be selected from multiple libraries.
- Multiple artwork items are exported as a single file.

Item to be exported

Artwork displayed in Item to be exported will be exported.

Back

Closes the **Export** dialog box.


Next

Displays the **Export to** dialog box; enter the destination category name, and then specify the destination folder to save the export file.

Set Grid and Guide Dialog Box

Specify the color and line type of the grid and guide.

To display the **Set Grid and Guide** dialog box, right-click the poster's background or outside it, and then click **Grid and Guide** > **Set Grid and Guide...**.



Grid

Color

Displays the current color. To change the color, click **Custom...** to display the **Color** dialog box, and then select a color.

Style

Select the grid line type from the list.

Guide

Color

Displays the current color. To change the color, click **Custom...** to display the **Color** dialog box, and then select a color.

Style

Select the guide line type from the list.


Note

• For instructions on using the guide, see Using the Guide.

Preferences Dialog Box

Specify the location to save artwork, printer to use for test printing, and more.

To display the **Preferences** dialog box, click **Preferences...** in the **Edit** menu.



User Artwork

Specify the location to save templates, images, and other artwork created using PosterArtist. Click **Browse...**, and then specify the destination folder.

Test Printer

Select the printer to use for test printing.

Media Size

Select the paper size for test printing from A4 and Letter.

Measurement Units

Select the unit of length for PosterArtist from mm and inch.

Nudge Distance

Specify the distance objects move each time a keyboard arrow key is pressed, within the following ranges.

When **Measurement Units** is **mm**: 0.01 to 10,000 mm When **Measurement Units** is **inch**: 0.01 to 393.70 in.



• Press the arrow key while holding down the Ctrl key to move objects by one tenth of the value set in **Nudge Distance**.

Default poster size

Set the default size of templates and new posters. It can also be changed at a later time.

Proxy Server Settings

Set the proxy server. If you are not using a proxy server, leave those fields blank.

User Name

Enter the user name.

Password

Enter the password.

Select Your Place of Residence...

Displays the Select Your Place of Residence dialog box; select Region or Country and Region.



Display all messages

If you deselect this checkbox, messages displayed while using PosterArtist will no longer appear.

Check for new version at startup

When the latest version of PosterArtist is released, an update notification message will appear, allowing you to download the latest version.


Properties Dialog Box

Specify the size, position, or rotation angle of objects by entering a value.

To display the **Properties** dialog box, select the target object on the poster, and then click **Properties...** in the **Object** menu.

- ➡ For Objects Other than Lines and Arrows
- ➡ For Lines and Arrows

For Objects Other than Lines and Arrows



Size

Height

Specify the height of the object.

Width

Specify the width of the object.

Scale

Height

Specify the height of the object by changing the scale.

Width

Specify the width of the object by changing the scale.

Maintain Aspect Ratio

Maintains the aspect ratio of the object. When this checkbox is selected and you change **Height** or **Width**, the other is changed automatically to maintain the aspect ratio.

Position

Horizontal

Specify the horizontal position relative to the left or right edge of the page.

From

Select the reference position from Left Edge and Right Edge.

Vertical

Specify the vertical position relative to the top or bottom edge of the page.

From

Select the reference position from Top Edge and Bottom Edge.

Rotation

Specify the clockwise rotation angle.

>>> Note

• To rotate objects counter-clockwise, enter a negative value.

Object Locking

Select this checkbox to lock the position of the object.

>>> Important

· Objects that have been set up for variable printing cannot be locked.

>>> Note

· Locked objects are outlined in red when you point to them.

Security

Effective until

Displays the usage period of the object when the **Set Use Period** checkbox is selected in the **Saving Artwork** dialog box.


Editable

Displays whether **Prohibit Editing** in the **Saving Artwork** dialog box is enabled or disabled.

>>> Note

- · Appears only when a photo or clipart is selected.
- For details on the Saving Artwork dialog box, see Saving Artwork Dialog Box (Images).

For Lines and Arrows



Size

Length

Specify the line or arrow length.

Thickness

Specify the line or arrow thickness.

Scale

Length

Specify the line or arrow length by changing the scale.

Thickness

Specify the line or arrow thickness by changing the scale.

Start Point Position / End Point Position

Horizontal

Specify the horizontal position relative to the left or right edge of the page.

From

Select the reference position from Left Edge and Right Edge.

Vertical

Specify the vertical position relative to the top or bottom edge of the page.

From

Select the reference position from **Top Edge** and **Bottom Edge**.

Rotation

Specify the clockwise rotation angle.


>>> Note

• To rotate objects counter-clockwise, enter a negative value.

Customize Toolbar Dialog Box

Customize toolbars by rearranging the buttons, showing only frequently used buttons, and more.

To display the **Customize Toolbar** dialog box, from the **Tool** menu, select **Custom**, and then click **Main Toolbar...** or **Sub Toolbar...**.



Available toolbar buttons

Displays buttons not shown on the toolbar.

Add

Adds the button or Separator selected under Available toolbar buttons.



• Add Separator to insert a separator line between buttons on the toolbar.

Remove

Deletes the button selected under Current toolbar buttons.

Current toolbar buttons

Displays the buttons shown on the toolbar.

Reset

Restores the original state.

Help

Opens this guide.

Move Up

Moves the button selected under Current toolbar buttons up one position at a time.


Move Down

Moves the button selected under Current toolbar buttons down one position at a time.

Artwork Manager Dialog Box

Add new categories, rename categories, or delete unnecessary categories. In addition, rearrange categories and artwork, for example in descending order of frequency.

To display the **Artwork Manager** dialog box, click (Artwork Manager Dialog) on the toolbar.



Category

Displays a list of categories in the library.

Categories can be rearranged by dragging them.

>>> Note

· No Frame, No Text Graphic, and No Background are not displayed.

New Category

Add new categories. Newly created categories are added to the bottom of the category list.

Rename

Rename categories.

Delete

Delete categories.

>>> Important

Categories with a (Lock) icon cannot be deleted.

Show

Change the type of displayed artwork.

All Artwork

Displays all artwork.

User Artwork

Displays only the artwork added by the user.

Library Artwork

Displays only the pre-installed artwork.



Changes the display size of thumbnails.

Artwork

Displays the thumbnails of artwork in the library.

>>> Note

- 🗵 (P) icon indicates the pre-installed artwork.
- 🛍 (Lock) icon indicates that the artwork is used in templates.

Select All

Selects all displayed artwork.

Clear All

Cancels the selection of artwork.

Cut

Cuts artwork.

Paste

Pastes the copied or cut artwork.

>>> Important

• Copied artwork can be pasted within the same library. It cannot be pasted into other libraries.

Copy

Copies artwork.

Restore

Adds artwork deleted from the library to the library again.

Click **Deleted content** in **Category**, and then from the deleted artwork, select the artwork you want to add again.

Move

Displays the Move Artwork dialog box for moving the selected artwork to a different category.

Delete

Deletes the selected artwork.

>>> Important

Artwork with a (Lock) icon cannot be deleted.

Undo

Undoes the last operation.

Redo

Redoes the last undone correction.

Download

Downloads artwork that has not been downloaded, at once.


Help

Opens this guide.

Align and Distribute Objects Dialog Box

Align multiple objects (photos, clipart, etc.) on the poster.

To display the **Align and Distribute Objects** dialog box, click (Align and Distribute Objects Dialog) on the toolbar.



Align

Aligns objects.



Objects are aligned to the left edge of the leftmost object.



(Center Horizontally)

Objects are centered horizontally between the leftmost and rightmost objects.



(Right Align)

Objects are aligned to the right edge of the rightmost object.




(Top Align)

Objects are aligned to the top edge of the top object.



(Center Vertically)

Objects are centered vertically between the top and bottom objects.



(Bottom Align)

Objects are aligned to the bottom edge of the bottom object.




Distribute

Arranges objects at equal distances from each other.


(Even Horizontal Spacing)

Objects are arranged horizontally at equal distances from each other.



(Even Vertical Spacing)

Objects are arranged vertically at equal distances from each other.




Center

Centers objects in the middle of the page.




(Center Vertically on Page)

Objects are centered vertically in the middle of the page.



(Center Horizontally on Page)

Objects are centered horizontally in the middle of the page.




Match Size

Makes objects the same size.



Each object is resized to match the width of the first selected object.




>>> Note

• The objects' aspect ratios are not maintained.

(Fit Height)

Each object is resized to match the height of the first selected object.




Note

• The objects' aspect ratios are not maintained.

Guide Position Dialog Box

Specify the guide position numerically.

To display the **Guide Position** dialog box, on the toolbar, click (Down Arrow) to the right of (Guide), and then select **Enter Guide Position...**



Horizontal

Guide 1 / Guide 2

Position

Specify the horizontal guide positions relative to the top or bottom edge of the page.

From

Select the reference position from **Top Edge** and **Bottom Edge**.

Vertical

Guide 1 / Guide 2

Position

Specify the vertical guide positions relative to the left or right edge of the page.

From

Select the reference position from Left Edge and Right Edge.


Note

• For instructions on using the guide, see Using the Guide.

QR code Dialog Box

Add QR codes to posters.

To display the **QR code** dialog box, click (QR Code) on the toolbar.



QR code

Enter text such as email address and URL.

>>> Important

- The number of characters that can be entered in a single QR code is as follows.
- Numbers only: 7089 characters or less
- Letters and numbers: 4296 characters or less
- If a large number of characters is entered, scanning may fail depending on your device. We recommend that you limit the number of characters as follows.
- Numbers only: 513 characters or less
- Letters and numbers: 311 characters or less

Commands

- Menus and Commands
- → Main Screen Toolbar
- → Context Menus

Menus and Commands

The PosterArtist menu bar includes the following menus.

- **→** File Menu
- **Edit** Menu
- **View** Menu
- → Insert Menu
- **→ Object** Menu
- → Cloud sharing Menu
- **→ Tool** Menu
- → Help Menu

File Menu

Command	Key- board Short- cut	Description
New Poster	Ctrl+N	Closes the current poster to create a new, blank poster.
Open Post- er	Ctrl+O	Displays previously printed or saved posters. Select a poster to edit it.
Import		Displays the Import dialog box for importing posters or images.
Export		Displays the Export dialog box for exporting poster templates.
Export (for Easy-Pho- toPrint Edi- tor)		Displays the Export (for Easy-PhotoPrint Editor) dialog box for exporting poster data for use in Easy-PhotoPrint Editor.
Save	Ctrl+S	Saves the current poster.
Save As		Displays the Save As dialog box for saving the poster with a new name.
Save As JPEG		Displays the Save As JPEG dialog box for saving a copy of the poster as a JPEG image file.
Add to Tem- plates		Adds the current poster to the library as a poster template.
Print Pre- view		Displays the Print Preview dialog box for checking the print result.
Print	Ctrl+P	Displays the Print screen.
Recent File		Displays a list of recently used posters.

Exit	Exits PosterArtist.	
------	---------------------	--

Edit Menu

Com- mand	Sub Com- mand	Key- board Short- cut	Description	
Undo		Ctrl+Z	Undoes the last operation.	
Redo		Ctrl+Y	Redoes the last undone correction.	
Cut		Ctrl+X	Copies the selected object to the clipboard, removing it from the poster.*	
Сору		Ctrl+C	Copies the selected object to the clipboard.*	
Paste		Ctrl+V	Pastes the object from the clipboard.	
Paste as T	ext		Extracts text from WMF/EMF data on the clipboard to paste it.	
Delete		Del	Deletes the selected object from the poster.*	
Select All		Ctrl+A	Selects all objects on the poster.	
Snap to Grid			Selects whether to snap an object to the grid when they come close to each other.	
Snap to Guide			Selects whether to snap an object to the guide when they come close to each other.	
Set Grid and Guide			Displays the Set Grid and Guide dialog box for specifying the color and line type of the grid and guide.	
Enter Guide Posi-			Displays the Guide Position dialog box for specifying the guide position.	
Change Back- ground	From Back- ground Library		Displays the Edit screen (Backgrounds) for selecting a poster background.	
Backgrour gins	d Mar-		Displays the Background Margins dialog box for specifying page margins.	
Preferences			Displays the Preferences dialog box.	

^{*} Multiple objects can be selected.

View Menu

Com- mand	Sub Com- mand	Key- board Short- cut	Description
Toolbar			Shows or hides the toolbars.
	Main Tool- bar		Shows or hides the main toolbar.

	Sub Tool- bar		Shows or hides the sub toolbar.	
Status Bar			Shows or hides the status bar.	
Tempora	ry Tray	Ctrl+T	Shows or hides the temporary tray.	
Select Te	emplate	Ctrl+1	Displays the Select Template screen.	
Paper O	otions	Ctrl+2	Displays the Paper Options screen.	
Edit		Ctrl+3		
	Photos		Displays the Edit screen (Photos).	
	Clipart		Displays the Edit screen (Clipart).	
	Text		Displays the Edit screen (Text).	
	Shapes		Displays the Edit screen (Shapes).	
Back- grounds			Displays the Edit screen (Backgrounds).	
Variable Data			Displays the Edit screen (Variable Data).	
Print		Ctrl+4	Displays the Print screen.	
Zoom	100% (Fit View)		Displays the entire poster in the poster preview.	
	Fit Width		Displays the poster to fit to the width of the poster preview.	
	Fit Height		Displays the poster to fit to the height of the poster preview.	
	Set Zoom		Displays the Enlarged/Reduced dialog box for selecting a scale or enlargement method for posters.	
Ruler			Shows or hides the ruler.	
Grid			Shows or hides the grid.	
Guide			Shows or hides the guide.	

Insert Menu

Com- mand	Sub Command		Description
Add / Re- place Im-	From File		Displays the Insert Image dialog box for adding or replacing images to the poster.
age	From Image Library	Pho- tos	Displays the Edit screen (Photos).
		Clipart	Displays the Edit screen (Clipart).
	QR Code		Displays the QR code dialog box for adding QR codes to the poster.
	Read from (De- vice Name)		Acquire images from available TWAIN devices.
Add Text	Text		Changes the pointer to that for adding a horizontal text box.
	Vertical		Changes the pointer to that for adding a vertical text box.*

Add	Line	Changes the pointer to that for adding lines or arrows.	
Shape	Rectangle	Changes the pointer to that for adding rectangles.*	
	Ellipse	Changes the pointer to that for adding ellipses or circles.*	

^{*} May not be displayed depending on your language.

Object Menu

Command	Sub Com- mand	Description		
Edit		Makes the selected object editable. The action varies depending on the selected object. For text, an editing box appears. For QR codes, the QR code dialog box appears.		
Show Settin	ngs Panel	Displays the settings panel corresponding to the selected object.		
Size and Po	osition	Displays the Properties dialog box for resizing, moving, and rotating objects.* 1		
Rotate or		Rotates or inverts the selected object by a predetermined or user-specified amount.* 1		
Flip	Flip Verti- cal	Inverts the selected object vertically.* 1		
	Flip Hori- zontal	Inverts the selected object horizontally.* 1		
	Rotate Left 90 degrees	Rotates the selected object 90 degrees to the left.* 1		
Rotate Right 90 degrees		Rotates the selected object 90 degrees to the right.* 1		
	Rotate 180 de- grees	Rotates the selected object 180 degrees.* 1		
	Specify Rotation	Displays the Properties dialog box for specifying the rotation angle of the selected object.* 1		
Align and	Left Align	Aligns the selected objects to the left edge of the leftmost object.* 3		
Distribute Objects	Center Horizon- tally	Centers the selected objects horizontally between the leftmost and rightmost objects.* 3		
	Right Align	Aligns the selected objects to the right edge of the rightmost object.* 3		
	Top Align	Aligns the selected objects to the top edge of the top object.* 3		
	Center Vertically	Centers the selected objects vertically between the top and bottom objects.* 3		
	Bottom Align	Aligns the selected objects to the bottom edge of the bottom object.* 3		

		,
	Even Hor- izontal Spacing	Arranges the selected objects horizontally at equal distances from each other.* 3
	Even Ver- tical Spacing	Arranges the selected objects vertically at equal distances from each other.* 3
Center Horizon- tally on Page		Centers the selected objects horizontally in the middle of the page.* 3
	Center Vertically on Page	Centers the selected objects vertically in the middle of the page.* 3
	Fit Height	Resizes all objects to match the height of the first selected object. The objects' aspect ratios are not maintained.* 3
	Fit Width	Resizes all objects to match the width of the first selected object. The objects' aspect ratios are not maintained.* 3
	Align and Distribute Objects Dialog	Displays the Align and Distribute Objects dialog box for aligning or arranging multiple objects.* 3
Fit to backg	=	Scales the image to the full poster size and locks it at the very back.
Group		Groups or ungroups multiple objects.
	Group	Groups multiple objects to work with the group as if it were a single object.* 3
	Ungroup	Ungroups objects.* 3
Order		Moves the selected object forward or backward.* 1
	Bring to Front	Moves the selected object to the front.* 1
	Send to Back	Moves the selected object to the back.* 1
	Bring For- ward	Moves the selected object one position forward.* 1
	Send Backward	Moves the selected object one position back.* 1
Lock	•	Locks or unlocks the selected object.* 1
Trim / Gradation set- tings		Displays the Edit Image dialog box and preview panel for editing images.* 2
Retouch Im	age	Displays the Retouch Image dialog box for retouching images.* 2
Add to Pho	tos / Clip-	Displays the Saving Artwork dialog box for adding objects to the library.
Properties.		Displays the Properties dialog box for resizing, moving, and rotating objects.* 1
•		

- *1 Multiple objects can be selected.
- *2 Available when photos are selected.
- *3 Available when multiple objects are selected.

Cloud sharing Menu

Command	Description
Download poster/material	Download poster files and image files from cloud storage.
Upload currently open poster	Upload the current poster to cloud storage.
Upload export file	Export and upload artwork to cloud storage.

Tool Menu

Command	Sub Com- mand	Description	
Artwork Manager Dia- log		Displays the Artwork Manager dialog box for organizing artwork in the library.	
Artwork Sna	apshot	Displays the Artwork Snapshot dialog box for creating the artwork environment installer file.	
Design Che	ck	Performs Design Check. Select again to end Design Check.	
Custom	Main Tool- bar	Displays the Customize Toolbar dialog box for customizing the main toolbar.	
	Sub Tool- bar	Displays the Customize Toolbar dialog box for customizing the sub toolbar.	
Print Ambie Correction	•	Displays the Print Chart dialog box.	
Managing A		Displays the Managing Ambient Light Settings dialog box.	
Design Assist - Area Set		Activates Area Set mode to start Design Assist.	
Design Assist - Gener- ate Design		Starts Design Assist for the specified area to create designs.	
Quick Exchange		Activates Quick Exchange mode.	

Help Menu

Command	Keyboard Shortcut	Description
Manual	F1	Opens this guide.
View the Readme File		Displays the PosterArtist readme file.
About PosterArtist		Displays information about PosterArtist.

Main Screen Toolbar

The main screen toolbar displays toolbar buttons for frequently used functions. Two toolbars are available. Some toolbar buttons may not be displayed if the PosterArtist window is too small. Click to display the hidden buttons.

- → Main Toolbar
- → Sub Toolbar

Main Toolbar

Command	Name		Description
:	Artwork Manag- er Dialog		Displays the Artwork Manager dialog box for organizing artwork in the library.
	Print Pre	eview	Displays the Print Preview dialog box for checking the print result.
₽	Use Ima	ige File	Displays the Insert Image dialog box for adding or replacing images to the poster.
\(\Omega\)	Undo		Undoes the last operation.
<u>@</u>	Redo		Redoes the last undone correction.
	Align and Dis- tribute Objects Dialog		Displays the Align and Distribute Objects dialog box for aligning or arranging multiple objects.* 1
	Flip Vertical		Inverts the selected object vertically.* 1
4	Flip Horizontal		Inverts the selected object horizontally.* 1
=	Rotate Left 90 degrees		Rotates the selected object 90 degrees to the left.* 1
	Rotate Right 90 degrees		Rotates the selected object 90 degrees to the right.* 1
	Set Locked Status		Locks or unlocks the selected object.
+	Guide		Shows or hides the guide.
		Snap to Guide	Selects whether to snap an object to the guide when they come close to each other.
		Enter Guide Posi- tion	Displays the Guide Position dialog box.
-	Grid		Shows or hides the grid.
		Snap to Grid	Selects whether to snap an object to the grid when they come close to each other.

•	Enlarge	Enlarges the poster view.
Q	Reduce	Reduces the poster view.
100% (Fit View) 🔻	Select Scale	Select a scale or enlargement method for posters.* 2

^{*1} Multiple objects can be selected.

Sub Toolbar

Com- mand	Name	Description
B	Resize Se- lection Tool	Switches the selected object to Resize mode.* 1
Ð	Rotation Se- lection Tool	Switches the selected object to Rotation mode.* 1
<u>T</u> ,	Horizontal Text	Changes the pointer to that for adding a horizontal text box.
Tl	Vertical Text	Changes the pointer to that for adding a vertical text box.* 2
/	Line	Changes the pointer to that for adding lines or arrows.
	Rectangle	Changes the pointer to that for adding rectangles.
0	Ellipse	Changes the pointer to that for adding ellipses or circles.
960	QR Code	Displays the QR code dialog box for adding QR codes to the poster or replacing the added QR codes.
4	Hand Tool	When the poster is displayed in enlarged view, drag anywhere on the poster to scroll.
⇔	Print Ambi- ent Light Correction Chart	Prints the ambient light correction chart.
•	Add Transla- tion Tem- plate	Displays the Add Translation Template dialog box for entering multilingual translations in the poster.
	Design Assist Area Set Mode	Activates Area Set mode to start Design Assist.
®h ♥≡	Quick Ex- change	Activates Quick Exchange mode.
	Design Check	Switches Design Check mode on or off.

^{*1} Multiple objects can be selected.

^{*2} This function enlarges or reduces the poster preview. It does not enlarge or reduce the poster itself.

*2 May not be displayed depending on your language.

Context Menus

PosterArtist offers many context menus for instant access to required commands. Right-click an object on the poster to display these menus.

- → Context Menus Common to All Objects
- ➡ Photo Context Menu
- Clipart Context Menu
- Shape Context Menu
- → WMF/EMF Context Menu
- **→** Text Context Menu
- → QR Code Context Menu

The following menus appear by right-clicking the corresponding area (other than objects) in the poster design area.

- → Background Context Menu
- ➡ Context Menu Outside the Background
- ➡ Guide Context Menu

Context Menus Common to All Objects

This section describes context menus common to all objects. For the context menu unique to each object, refer to the context menu of the corresponding object.

Com- mand	Sub Com- mand	Key- board Short- cut	Description
Cut		Ctrl+X	Copies the selected object to the clipboard, removing it from the poster.* 1
Сору		Ctrl+C	Copies the selected object to the clipboard.* 1
Paste		Ctrl+V	Pastes the object from the clipboard.
Delete		Del	Deletes the selected object from the poster.* 1
Size and I	Position		Displays the Properties dialog box for resizing, moving, and rotating objects.* 1
Rotate or Flip			Rotates or inverts the selected object by a predetermined or user-specified amount.* 1
	Flip Ver- tical		Inverts the selected object vertically.* 1
	Flip Hor- izontal		Inverts the selected object horizontally.* 1
	Rotate Left 90 degrees		Rotates the selected object 90 degrees to the left.* 1

	Rotate Right 90 degrees	Rotates the selected object 90 degrees to the right.* 1
	Rotate 180 de- grees	Rotates the selected object 180 degrees.* 1
	Specify Rota- tion	Displays the Properties dialog box for the selected object.* 1
Align and Dis-	Left Align	Aligns the selected objects to the left edge of the leftmost object.
tribute Objects	Center Horizon- tally	Centers the selected objects horizontally between the leftmost and rightmost objects.* 2
	Right Align	Aligns the selected objects to the right edge of the rightmost object.* 2
	Top Align	Aligns the selected objects to the top edge of the top object.* 2
	Center Vertical- ly	Centers the selected objects vertically between the top and bottom objects.* 2
	Bottom Align	Aligns the selected objects to the bottom edge of the bottom object.* 2
	Even Horizon- tal Spac- ing	Arranges the selected objects horizontally at equal distances from each other.* 2
	Even Vertical Spacing	Arranges the selected objects vertically at equal distances from each other.* 2
	Center Horizon- tally on Page	Centers the selected objects horizontally in the middle of the page.* 1
	Center Vertical- ly on Page	Centers the selected objects vertically in the middle of the page.* 1
	Fit Height	Resizes all the selected objects to match the height of the first selected object. The objects' aspect ratios are not maintained.* 2
	Fit Width	Resizes all the selected objects to match the width of the first selected object. The objects' aspect ratios are not maintained.* 2
	Align and Dis- tribute	Displays the Align and Distribute Objects dialog box for aligning or arranging multiple objects.* 1

	Objects Dialog	
Group		Groups or ungroups multiple objects.
	Group	Groups multiple objects to work with the group as if it were a single object.* 2
	Ungroup	Ungroups objects.
Order		Moves the selected object forward or backward.* 1
	Bring to Front	Moves the selected object to the front.* 1
	Send to Back	Moves the selected object to the back.* 1
	Bring Forward	Moves the selected object one position forward.* 1
	Send Back- ward	Moves the selected object one position back.* 1
Add to P		Displays the Saving Artwork dialog box for adding objects to the library.* 1
Properti	es	Displays the Properties dialog box for resizing, moving, and rotating objects.* 1

^{*1} Multiple objects can be selected.

Photo Context Menu

This section describes the context menu commands unique to photo objects. For other commands, see Context Menus Common to All Objects.

Command	Sub Com- mand	Description
Replace Image	From File	Displays the Insert Image dialog box for replacing the selected image with another image.*
	From Photo Library	Displays the Edit screen (Photos).*
	Read from (Device Name)	Acquire images from available TWAIN devices.*
Show Settings Panel		Displays the Edit screen (Photos).
Fit to background (Back- ground setting)		Scales the image to the full poster size and locks it at the very back.*
Trim / Gradation set- tings		Displays the Edit Image dialog box and preview panel for editing images.*
Retouch Image		Displays the Retouch Image dialog box for retouching images.*

^{*} Available when a photo is selected.

^{*2} Available when multiple objects are selected.

Clipart Context Menu

This section describes the context menu commands unique to clipart objects. For other commands, see Context Menus Common to All Objects.

Command	Sub Com- mand	Description
Replace Image	From File	Displays the Insert Image dialog box for replacing the selected image with another image.*
	From Clip- art Library	Displays the Edit screen (Clipart).*
Show Settings Panel		Displays the Edit screen (Clipart).

^{*} Available when a clipart item is selected.

Shape Context Menu

This section describes the context menu command unique to shape objects. For other commands, see Context Menus Common to All Objects.

Command	Description
Show Settings Panel	Displays the Edit screen (Shapes).

WMF/EMF Context Menu

This section describes the context menu commands unique to WMF/EMF objects. For other commands, see <u>Context Menus Common to All Objects</u>.

Command	Sub Com- mand	Description
Replace From File		Displays the Insert Image dialog box for replacing the selected image with another image.*
	From Photo Library	Displays the Edit screen (Photos).*
	Read from (Device Name)	Acquire images from available TWAIN devices.*
Show Settings Panel		Displays the Edit screen (Photos).
Fit to background (Background setting)		Scales the image to the full poster size and locks it at the very back.*

^{*} Available when a WMF/EMF image is selected.

Text Context Menu

This section describes the context menu commands unique to text objects. For other commands, see Context Menus Common to All Objects.

Command	Key- board Short- cut	Description
Cut	Ctrl+X	Copies the selected text to the clipboard, deleting it from the poster.*
Сору	Ctrl+C	Copies the selected text to the clipboard.*
Paste	Ctrl+V	Pastes the text from the clipboard.*
Edit		Displays the text in an editing box.
Show Set- tings Pan- el		Displays the Edit screen (Text).
Add Transla- tion Tem- plate	Ctrl+V	Displays the Add Translation Template dialog box for entering multilingual translations of fixed phrases in the poster.*

^{*} Available when an editing box is displayed.

QR Code Context Menu

This section describes the context menu command unique to QR code objects. For other commands, see <u>Context Menus Common to All Objects</u>.

Command	Description
Edit	Displays the QR code dialog box for editing the QR code.

Background Context Menu

Com- mand	Sub Command		Key- board Short- cut	Description
Paste			Ctrl+V	Pastes the object from the clipboard.
Paste as Text				Extracts text from WMF/EMF data on the clipboard to paste it.
Select All		Ctrl+A	Selects all objects on the poster.	
Add Im-	From File			Displays the Insert Image dialog box for adding images to the poster.
age	From Image Li- brary	Pho- tos		Displays the Edit screen (Photos).
		Clip- art		Displays the Edit screen (Clipart).
	QR Code			Displays the QR code dialog box for adding QR codes to the poster.
	Read from (De- vice Name)			Acquire images from available TWAIN devices.
Add Text	Text			Changes the pointer to that for adding a horizontal text box.

_		
	Vertical	Changes the pointer to that for adding a vertical text box.*
Add Shape	Line	Changes the pointer to that for adding lines or arrows.
	Rectangle	Changes the pointer to that for adding rectangles.
	Ellipse	Changes the pointer to that for adding ellipses or circles.
Zoom	100% (Fit View)	Displays the entire poster in the poster preview.
	Fit Width	Displays the poster to fit to the width of the poster preview.
	Fit Height	Displays the poster to fit to the height of the poster preview.
	Set Zoom	Displays the Enlarged/Reduced dialog box for selecting a scale or enlargement method for posters.
Grid and	Ruler	Shows or hides the ruler.
Guide	Grid	Shows or hides the grid.
	Snap to Grid	Selects whether to snap an object to the grid when they come close to each other.
	Guide	Shows or hides the guide.
	Snap to Guide	Selects whether to snap an object to the guide when they come close to each other.
	Set Grid and Guide	Displays the Set Grid and Guide dialog box for specifying the color and line type of the grid and guide.
	Enter Guide Position	Displays the Guide Position dialog box for specifying the guide position.
Change Back- ground	From Back- ground Li- brary	Displays the Edit screen (Backgrounds) for selecting a poster background.
Backgrou	ind Margins	Displays the Background Margins dialog box for specifying page margins.
Add to Te	mplates	Adds the current poster to the library as a poster template.
Design C	heck	Performs Design Check.
Quick Exchange		Activates Quick Exchange mode.
Design A	ssist - Area Set	Activates Area Set mode to start Design Assist.
Design Assist - Generate Design		Starts Design Assist to create designs.
Preference	es	Displays the Preferences dialog box.

^{*} May not be displayed depending on your language.

Context Menu Outside the Background

	Sub Com- mand	Key- board Short- cut	Description
Temporary Tray Ctrl+T		Ctrl+T	Shows or hides the temporary tray.

Zoom	100% (Fit View)		Displays the entire poster in the poster preview.
	Fit Width		Displays the poster to fit to the width of the poster preview.
	Fit Height		Displays the poster to fit to the height of the poster preview.
	Set Zoom		Displays the Enlarged/Reduced dialog box for selecting a scale or enlargement method for posters.
Grid and Guide	Ruler		Shows or hides the ruler.
	Grid		Shows or hides the grid.
	Snap to Grid		Selects whether to snap an object to the grid when they come close to each other.
	Guide		Shows or hides the guide.
	Snap to Guide		Selects whether to snap an object to the guide when they come close to each other.
	Set Grid and Guide		Displays the Set Grid and Guide dialog box for specifying the color and line type of the grid and guide.
	Enter Guide Po- sition		Displays the Guide Position dialog box for specifying the guide position.
Artwork Manager Dialog			Displays the Artwork Manager dialog box for organizing artwork in the library.
Artwork Snap- shot			Displays the Artwork Snapshot dialog box for creating the artwork environment installer file.
Custom	Main Toolbar		Displays the Customize Toolbar dialog box for customizing the main toolbar.
	Sub Tool- bar		Displays the Customize Toolbar dialog box for customizing the sub toolbar.
Preferences			Displays the Preferences dialog box.
Manual	Manual		Opens this guide.
About PosterArt- ist			Displays information about PosterArtist.

Guide Context Menu

Com- mand	Sub Com- mand	Description
Zoom	100% (Fit View)	Displays the entire poster in the poster preview.
	Fit Width	Displays the poster to fit to the width of the poster preview.
	Fit Height	Displays the poster to fit to the height of the poster preview.
	Set Zoom	Displays the Enlarged/Reduced dialog box for selecting a scale or enlargement method for posters.

Grid and Guide	Ruler	Shows or hides the ruler.
	Grid	Shows or hides the grid.
	Snap to Grid	Selects whether to snap an object to the grid when they come close to each other.
	Guide	Shows or hides the guide.
	Snap to Guide	Selects whether to snap an object to the guide when they come close to each other.
	Set Grid and Guide	Displays the Set Grid and Guide dialog box for specifying the color and line type of the grid and guide.
	Enter Guide Po- sition	Displays the Guide Position dialog box for specifying the guide position.

FAQ

What Is PosterArtist QuickCopy?

It is an application to print enlarged copies of scanned photos and documents. Simply click the **Copy** button in PosterArtist QuickCopy to create posters from enlarged copies of originals in your scanner.

Scanned items can also be inserted in posters as PosterArtist materials.

Creating and Printing Enlarged Copies of Photos and Documents

Which Scanners Support PosterArtist QuickCopy?

A CanoScan series scanner or PIXMA Inkjet All-In-One printer is required. Access our website for information on scanners compatible with PosterArtist QuickCopy.

➡ Creating and Printing Enlarged Copies of Photos and Documents

How Can I Perform Large-Format Printing?

For details, see Large-Format Printing.

How Can I Print Without Borders?

The following two methods are available for borderless printing.

- ➡ Printing Borderless Posters Filling the Entire Roll Paper Width
- Printing Without Borders on Three Sides

Depending on your model, you will need to prepare roll paper whose width and paper type support borderless printing. For information on paper that supports borderless printing, click Home to return to the top page of the Online Manual for your model and search for "Paper Sizes." Borderless printing is not available for cut sheets.

Note

 For some models, Minimal Margin Printing is displayed instead of Borderless Printing. When Minimal Margin Printing is displayed, printouts will have slight margins on the left and right sides.

How Can I Use the Variable Printing Function?

To use the variable printing function, prepare tabular data in Excel format (.xls, .xlsx, .xlsm, or .xlsb) or in CSV format (.csv).

For details, see **Using Variable Printing**.

How Can I Print by Rotating Posters 90 Degrees?

To print filling the entire roll paper width, in the <u>Paper Options screen</u>, select **Fit Long Side to Roll Width** (for vertical posters) or **Fit Short Side to Roll Width** (for horizontal posters).

If the width or length is different from the roll paper width, it is not possible to print by rotating posters 90 degrees in the original scale.

Specifying Size and Paper

How Can I Specify Paper Size of My Choice?

The paper size of your choice can be specified in **Set Custom Size...** in the <u>Paper Options screen</u>.

Specifying Non-Standard Page Sizes

How Can I Insert Data from Other Software?

Data created with Microsoft Office applications can be inserted. Other data such as PDF files cannot be inserted.

Inserting Images in Posters

Which Printers Can I Use?

Posters can be printed only on Canon printers and Océ printers that support PosterArtist.

The printer to use for test printing can be specified in the **Preferences** dialog box.

Important

Available functions and settings vary depending on your model.

How Can I Print on a Cut Sheet Without the Image Being Cut Off?

In the <u>Paper Options screen</u>, select the **Enlarged/Reduced Printing** checkbox, select **Fit in Printable Area**, and then print.

➡ When Printing Entire Poster Within Printable Area

What Is the Ambient Light Setting?

Ambient light color and brightness vary by environmental factors such as location (indoors or outdoors) or lighting (fluorescent or incandescent). Therefore the same poster may appear different depending on where it is displayed.

Use the ambient light setting functions to adjust colors automatically according to the environment to visually enhance the poster's color tones.

Ambient Light Setting

What Should I Do when I Replace My Computer or Hard Disk?

When replacing your computer or hard disk, license authentication will be required again.