


VP229QF Series LCD Monitor User Guide





HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

First Edition

April 2025

Copyright © 2025 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification of alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Contents

Conte	ents		iii	
Notic	es		iv	
Safet	y informa	ation	v i	
Care	& Cleani	ng	vii	
Takel	oack Serv	vices	viii	
. .		5 1 44 4 1 4		
	oter 1:	Product introduction		
1.1		me!		
1.2		ge contents		
1.3	Monito	or introduction	1-2	
	1.3.1	Front view	1-2	
	1.3.2	Back view	1-4	
Chap	oter 2:	Setup		
2.1	Assem	nbling the monitor arm/base	2-1	
2.2	Detach	ning the arm/base (for VESA wall mount)	2-2	
2.3	Adjusting the monitor2-			
2.4	Connecting the cables2-			
2.5	Turning on the monitor2-:			
Chap	oter 3:	General instructions		
3.1	OSD (On-Screen Display) menu	3-1	
	3.1.1			
	3.1.2	OSD function introduction		
3.2	Specif	ications summary		
3.3	-	Outline dimensions		
3.4		Troubleshooting (FAQ)		
3.5	Supported operating modes			

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- · This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

ENERGY STAR complied product



ENERGY STAR is a joint program of the U.S. Environmental Protection Agency and the U.S. Department of Energy helping us all save money and protect the environment through energy efficient products and practices.

All ASUS products with the ENERGY STAR logo comply with the ENERGY STAR standard, and the power management feature is enabled by default. The monitor and computer are automatically set to sleep after 10 and 30 minutes of user inactivity. To wake your computer, click the mouse or press any key on the keyboard. Please visit http://www.energystar.gov/powermanagement for detail information on power management and its benefits to the environment. In addition, please visit http://www.energystar.gov for detail information on the ENERGY STAR joint program.



NOTE: Energy Star is NOT supported on FreeDOS and Linux-based operating system.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

This Class B digital apparatus meets all requirements of the Canadian Interference - Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Réglement sur le matériel brouiller du Canada.



Software Low Blue Light compliance

ASUS requests every model to pass SW LBL when "Image/ Blue Light Filter" is set to MAX.

Please refer to the following to alleviate eye strains:

- Users should take some time away from the display if working for long hours.
 It is advised to take short breaks (at least 5 mins) after around 1 hour of
 continuous working at the computer. Taking short and frequent breaks is more
 effective than a single longer break.
- To minimize eye strain and dryness in your eyes, users should rest the eye periodically by focusing on objects that are far away.
- Eye exercises can help to reduces eye strain. Repeat these exercises often. If
 eye strain continues please consult a physician. Eye exercise: (1) Repeating
 look up and down (2) Slowly roll your eyes (3) Move your eyes diagonal.
- High energy blue ligh may lead to eye strain and AMD (Age-Related Macular Degeneration). Blue light Filter to reduce 70% (max.) harmful blue light to avoiding CVS (Computer Vision Syndrome).

Blue Light Filter set to MAX. It is in compliance with TÜV Rheinland low blue light Software Solution certification.

Flicker-Free technology

The Monitor adopts Flicker-Free technology, which clears the eye visible flicker, brings comfort viewing experience and preventing users suffer from eye strain and fatigue.

Safety information

- Before setting up the monitor, carefully read all the documentation that came with the package.
- To prevent fire or shock hazard, never expose the monitor to rain or moisture.
- Never try to open the monitor cabinet. The dangerous high voltages inside the monitor may result in serious physical injury.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.
- Before using the product, make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- Slots and openings on the back or top of the cabinet are provided for ventilation. Do not block these slots. Never place this product near or over a radiator or heat source unless proper ventilation is provided.
- The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- Use the appropriate power plug which complies with your local power standard.
- Do not overload power strips and extention cords. Overloading can result in fire or electric shock.
- Avoid dust, humidity, and temperature extremes. Do not place the monitor in any area where it may become wet. Place the monitor on a stable surface.
- Unplug the unit during a lightning storm or if it will not be used for a long period
 of time. This will protect the monitor from damage due to power surges.
- Never push objects or spill liquid of any kind into the slots on the monitor cabinet.
- To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100-240V AC.
- By means of a power cord connected to a socket-outlet with earthing connection.
- If you encounter technical problems with the monitor, contact a qualified service technician or your retailer.
- Adjustment of the volume control as well as the equalizer to other settings than the center position may increase the ear-/headphones output voltage and therefore the sound pressure level.



This symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment, and mercury-containing button cell battery) should not be placed in municipal waste. Please check local regulations for disposal of electronic products.

AEEE yönetmeliğine uygundur

Care & Cleaning

- Before you lift or reposition your monitor, it is better to disconnect the cables and power cord. Follow the correct lifting techniques when positioning the monitor. When lifting or carrying the monitor, grasp the edges of the monitor. Do not lift the display by the stand or the cord.
- Cleaning. Turn your monitor off and unplug the power cord. Clean the monitor surface with a lint-free, non-abrasive cloth. Stubborn stains may be removed with a cloth dampened with mild cleaner.
- Avoid using a cleaner containing alcohol or acetone. Use a cleaner intended for use with the monitor. Never spray cleaner directly on the screen, as it may drip inside the monitor and cause an electric shock.

The following symptoms are normal with the monitor:

- You may find slightly uneven brightness on the screen depending on the desktop pattern you use.
- When the same image is displayed for hours, an afterimage of the previous screen may remain after switching the image. The screen will recover slowly or you can turn off the Power Switch for hours.
- When the screen becomes black or flashes, or cannot work anymore, contact your dealer or service center to fix it. Do not repair the screen by yourself!

Conventions used in this guide



WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Information that you MUST follow to complete a task.



NOTE: Tips and additional information to aid in completing a task.

Where to find more information

Refer to the following sources for additional information and for product and software updates.

1. ASUS websites

The ASUS websites worldwide provide updated information on ASUS hardware and software products. Refer to http://www.asus.com

2. Optional documentation

Your product package may include optional documentation that may have been added by your dealer. These documents are not part of the standard package.

3. About Flicker

https://www.asus.com/Microsite/display/eye_care_technology/

Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for our customers to be able to responsibly recycle our products, batteries and other components as well as the packaging materials.

Please go to http://csr.asus.com/english/Takeback.htm for detail recycling information in different region.

1.1 Welcome!

Thank you for purchasing the ASUS® LCD monitor!

The latest widescreen LCD monitor from ASUS provides a broader, brighter and crystal-clear display, plus a host of features that enhance your viewing experience.

With these features, you can enjoy the convenience and delightful visual experience that the monitor brings to you!

1.2 Package contents

Check your package for the following items:

- ✓ LCD monitor
- ✓ Monitor arm
- ✓ Monitor base
- ✓ Quick start guide
- ✓ Warranty card
- ✓ Power cord
- ✓ HDMI cable
- ✓ VGA cable (optional)
- ✓ DisplayPort cable (optional)
- ✓ L-shaped screwdriver (optional)
- ✓ 2 screws




If any of the above items is damaged or missing, contact your retailer immediately.



If you need to replace the power cord or the connection cable(s), please contact ASUS customer service.

1.3 Monitor introduction

1.3.1 Front view



- 1. (1) Power (5-way) button/power indicator
 - Turns the monitor on/off.
 - Press the button and move right will shut down the monitor.
 - The color definition of the power indicator is as the below table.

Status	Description
White	On
Amber	Standby mode
Off	Off

2. ⇒ Shortcut 1

- Press the 5-way button to display the OSD menu when the OSD is off.
- Default: Input Select
- To change the hotkey function, go to the Shortcut > Shortcut 1 menu.

3. r(i) Shortcut 2

- Press the 5-way button to display the OSD menu when the OSD is off.
- Default: Energy Saving hotkey
- To change the hotkey function, go to the Shortcut > Shortcut 2 menu.


4. X Exit (5-way) button:

- Press this button to display the OSD menu when the OSD is off.
- Exits the OSD menu.

5. Menu (5-way) button:

- Press this button to display the OSD menu when the OSD is off. Press this button again to enter the OSD main menu.
- Enacts the selected OSD menu items.
- Increases/Decreases values or moves your selection up/down/left/ right.

1.3.2 Back view



- **1. AC-IN port**: This port connects the power cord.
- HDMI port: This port is for connection with an HDMI compatible device.
- DisplayPort in: This port is for connection with a DisplayPort compatible device.
- VGA: This port is for connection with your computer to the monitor with a VGA cable.
- Earphone jack: This port is only available when an HDMI cable is connected.
- 6. Kensington lock slot.


2.1 Assembling the monitor arm/base

To assemble the monitor base:

- 1. Place the monitor flat on the table.
- 2. Remove the stand cover.
- 3. Insert the stand. When inserting the stand, please push it all the way.
- 4. Attach the left and right screw (Lock with the bracket of the stand).
- Reinstall the stand cover.
- Screw the stand base.



We recommend that you cover the table surface with soft cloth to prevent damage to the monitor.






Base screw size: M4 x 10mm.

2.2 Detaching the arm/base (for VESA wall mount)

The detachable arm/base of this monitor is specially designed for VESA wall mount.

To detach the arm/base:

- 1. Place the monitor flat on the table.
- Remove the stand base.
- Remove the stand cover.
- 4. Remove the left and right screws.
- 5. Pull out the stand.
- 6. Reinstall the stand cover.





We recommend that you cover the table surface with soft cloth to prevent damage to the monitor.




- The VESA wall mount kit (100 x 100 mm) is purchased separately.
- Use only with UL/CSA/GS Listed Wall Mount Bracket with minimum weight/load bearing capacity of 22.7 kg (50 lb) (Screw size: M4 x 10 mm).

2-2 Chapter 2: Setup

2.3 Adjusting the monitor

- For optimal viewing, we recommend that you look at the full face of the monitor, then adjust the monitor to the angle that is most comfortable for you.
- Hold the stand to prevent the monitor from falling when you change its angle.
- The recommended adjusting angle is +23° to -5°.






It is normal that the monitor slightly shakes while you adjust the viewing angle.

2.4 Connecting the cables

Connect the cables as the following instructions:



- To connect the power cord: Connect one end of the power cord securely to the monitor's AC input port, the other end to a power outlet.
- To connect the HDMI/DisplayPort cable:
 - a. Plug one end of the HDMI/DisplayPort cable to the monitor's HDMI/ DisplayPort jack.
 - Connect the other end of the HDMI/DisplayPort cable to your device's HDMI/DisplayPort jack.
- To use the VGA: Please select with molding cable to a source device such as a computer or game console.
- To use the earphone: connect the end with plug type to the monitor's earphone jack when an HDMI signal is fed.



When these cables are connected, you can choose the desired signal from the **Input** item in the OSD menu.



If you need to replace the power cord or the connection cable(s), please contact ASUS customer service.

2-4 Chapter 2: Setup

2.5 Turning on the monitor

Press the power button \circlearrowleft . See page 1-2 for the location of the power button. The power indicator \circlearrowleft lights up in white to show that the monitor is ON.

3.1 OSD (On-Screen Display) menu

3.1.1 How to reconfigure



- 1. Press 5-ways button to display the OSD menu.
- 2. Press the Menu button to activate the OSD menu.
- 3. Press 5-ways button as indicated on the screen to navigate through the functions. Highlight the desired function and press it again to activate it. If the function selected has a sub-menu, move the button up and down to navigate through the sub-menu functions. Highlight the desired sub-menu function and press it to activate it.
- Move the 5-ways button up and down to change the settings of the selected function.
- 5. To exit and save the OSD menu, move the 5-ways button left repeatedly until the OSD menu disappears. To adjust other functions, repeat steps 1-4.

3.1.2 OSD function introduction

1. Splendid

This function contains 8 sub-functions you can select for your preference. Each mode has the Reset selection, allowing you to maintain your setting or return to the preset mode.



 Standard Mode: Best choice for document editing with Splendid Video Enhancement.



Standard Mode meets Energy Star® requirements.

- sRGB Mode: Best choice for viewing photos and graphics from PCs.
- Scenery Mode: Best choice for scenery photo display with Splendid Video Enhancement.
- Theater Mode: Best choice for movies with Splendid Video Enhancement.
- Game Mode: Best choice for game playing with Splendid Video Enhancement.
- Night View Mode: Best choice for dark-scene games or movies with Splendid Video Enhancement.
- Reading Mode: This is the best choice for book reading.
- Darkroom Mode: This is the best choice for a weak ambient light environment.



- In the Standard mode, the following function(s) are not user-configurable: Saturation, Sharpness, ASCR.
- In the sRGB mode, the following function(s) are not user-configurable:
 Brightness, Contrast, Saturation, Color Temp., Sharpness, ASCR.
- In the Reading mode, the following function(s) are not user-configurable: Contrast, Saturation, Color Temp., ASCR.

2. Eye Care

In this function, you can adjust settings to better protect your eyes.



- Blue Light Filter: In this function, you can adjust the blue light filter from 0 to Max.
 - Very term of the second of the
 - * Max: The higher the level, the less blue light is scattered. When blue light filter is activated, the default settings of Standard Mode will be automatically imported. Besides maximum level, the brightness is user-configurable. Maximum is the optimized setting. The brightness function is not user configurable.



Please refer to the following to alleviate eye strains:

- Users should take some time away from the display if working for long hours. It is advised to take short breaks (at least 5 mins) after around 1 hour of continuous working at the computer. Taking short and frequent breaks is more effective than a single longer break.
- To minimize eye strain and dryness in your eyes, users should rest the eye
 periodically by focusing on objects that are far away.
- Eye exercises can help to reduces eye strain. Repeat these exercises
 often. If eye strain continues please consult a physician. Eye exercises:

 (1) Repeating look up and down (2) Slowly roll your eyes (3) Move your
 eyes diagonal.
- High energy blue light may lead to eye strain and AMD (Age-Related Macular Degeneration). Blue light filter to reduce 70% (max.) harmful blue light to avoiding CVS (Computer Vision Syndrome) when the user adjusts blue light filter bar to maximum level.
- Rest Reminder: This function provides you a rest reminder according
 to how long you set for your working time. For example, if you set a
 30-minute working time and there will be a pop up reminder appeared on
 the upper left corner of the monitor for 5 seconds when time is up. Press
 any key to make this reminder OSD disappear.



When this function is enabled, the following functions are not available: GamePlus, QuickFit.

 Color Augmentation: The adjusting range of color enhancement is from 0 to 100.



This function is not available when sRGB Mode is selected in the Splendid menu.

3. Color

Set a desired color setting from this menu.



• **Brightness**: The adjusting range is from 0 to 100.



This function is not available when Ambient Effect is enabled.

- **Contrast**: The adjusting range is from 0 to 100.
- **Saturation**: The adjusting range is from 0 to 100.
- Color Temp.: Contains 4 modes including Cool, Normal, Warm and User Mode.

4. Image

Set the image related setting from this menu.



- **Sharpness**: The adjusting range is from 0 to 100.
- **Trace Free**: Adjusts the response time of the monitor.
- Aspect Control: Adjusts the aspect ratio to Full, or 4:3.



4:3 is only available when input source is in 4:3 format.

- ASCR: Turns on/off the ASCR (ASUS Smart Contrast Ratio) function.
- VGA Adjust:
 - * Position: Adjust the horizontal position (H-Position) and the vertical position (V-Position) of the image. The adjusting range is from 0 to 100.
 - * Focus: Reduce the Horizontal-line noise and Vertical-line noise of the image by adjusting (Phase) and (Clock) separately. The adjusting range is from 0 to 100.
- Adaptive-Sync: It can allow a Adaptive-Sync supported graphics source to dynamically adjust display refresh rate based on typical content frame rates for power efficient, virtually stutter free and low-latency display update.

5. Input

In this function, you can select your desired input source.



• **Auto Detection**: Automatically detects other active signals when current input signal is inactive.

6. Settings

Allows you to adjust the system.



Sound:

- * Adjusts Volume from 0 to 100.
- * Mute or un-Mute the audio output.
- GamePlus: The GamePlus function provides a toolkit and creates a better gaming environment for users when playing different types of games.
 - * Corsshair: The crosshair overlay with different crosshair options lets you choose the one that best suits the game you're playing.
 - * Timer: You can position the timer on the upper left corner of the display so you can keep track of the gaming time.
 - * **FPS Counter**: The FPS (frames per second) counter lets you know how smooth the game is running.
 - * Display Alignment: Display Alignment displays alignment lines on 4 sides of the screen, serving as an easy and handy tool for you to line up multiple monitors perfectly.

- QuickFit: You can have a preview of the document or photo layout directly on screen without printing test copies.
 - Paper size: You can view the documents in real size on the screen.





Photo: The various real photo sizes displayed provides photographers and other users to accurately view and edit their photos in real size on the screen.



- Power Saving: Reduces power consumption. The default setting is "Deep Level". When "Deep Level" is selected, the maximum brightness value is fixed and Splendid mode is fixed at "Standard Mode".
- OSD Setup:
 - * Adjusts the OSD timeout from 10 to 120 seconds.
 - * Enables or disables the DDC/CI function.
 - * Adjusts the OSD background from opaque to transparent.
- ASUS Power Svnc: To enable CEC function.
 - * If HDMI™ CEC is set to ON: The monitor will automatically power on/off when the Intel NUC is turned on/off.
 - * Notes: The function can support Intel NUC, ASUS NUC.
- Language: There are 23 languages for your selection, including English, French, German, Italian, Spanish, Dutch, Portuguese, Russian, Czech, Croatian, Polish, Romanian, Hungrian, Turkish, Simplified Chinese, Traditional Chinese, Japanese, Korean, Thai, Indonesian, Persian, Ukrainian, Vietnamese.

- Key Lock: To disable all function keys. Push the 5-way button down for over 5 seconds to cancel the key lock function.
- Information: Shows the monitor information.
- **Power Indicator**: Turns the power LED indicator on/off.
- **Power Key Lock**: Enables or disables the power key.
- All Reset: "Yes" allows you to restore the default settings.

7. Shortcut

Defines the functions for Shortcut 1 and 2 buttons.



 Shortcut 1/Shortcut 2: Selects a function for Shortcut 1 and 2 buttons.



When a certain function is selected or activated, your shortcut key may not support. Available function choices for shortcut: Blue Light Filter, Splendid, Brightness, Contrast, Input Select, Color Temp., Volume, QuickFit, GamePlus, Rest Reminder, Color Augmentation, Energy Saving.

3.2 Specifications summary

Panel Type	TFT LCD
Panel size	21.5" (16:9,47.6 cm x 26.7 cm) wide screen
Max. Resolution	1920 x 1080
Pixel pitch	0.248 mm x 0.248 mm
Brightness (Typ.)	250 cd/m ²
Contrast Ratio (Typ.)	1000:1
Viewing angle (H/V)	178°/178°
CR>10	
Display colors	16.7 M (6 bits + FRC)
Response time	5 ms (GTG)
Color temperature	4 color temperatures
selection	· ·
Digital input	HDMI v1.4 x 1, DP1.2 x 1, VGA x 1
Digital Output	No
Earphone jack	Yes
Audio input	No
Speaker (Built-in)	Yes
Power LED	White (On)/Amber (Standby)
Tilt	+23°~ -5°
VESA wall mount	100 x 100 mm
Kensington lock	Yes
AC input voltage	AC: 100~240V
Power consumption	Power On: 9.66 W**, Standby: ≤ 0.5 W,
	Power Off: 0.3 W
Temperature (Operating)	0°C ~ 40°C
Temperature (Non-	-20°C ~ +60°C
operating)	400.0
Dimension (W x H x D)	489.2 mm x 297.7 mm x 55.3 mm
without stand Dimension (W x H x D)	489.2 mm x 363.8 mm x 204.4 mm
with stand	489.2 mm x 363.8 mm x 204.4 mm 560 mm x 140 mm x 410 mm (package)
	" ",
Weight (Esti.)	2.9 kg (Net); 2.55 kg (Net, without stand);
Multi-languages	3.9 kg (Gross) 23 languages (English, French, German, Italian,
Multi-languages	Spanish, Dutch, Portuguese, Russian, Czech,
	Croatian, Polish, Romanian, Hungarian, Turkish,
	Simplified Chinese, Traditional Chinese, Japanese,
	Korean, Thai, Indonesian, Persian, Ukrainian,
	Vietnamese)
Accessories	Quick start guide, warranty card, power cord, HDMI
	cable, VGA cable (optional), DisplayPort cable
	(optional), L-shaped screwdriver (optional), 2 screws


Compliance and Standards

cTUVus, FCC, ICES-3, EPEAT Gold, CB, CE, WEEE, ISO 9241-307, UkrSEPRO, Ukraine Energy, ANZ MEPS, CU, BSMI, RCM, VCCI, PSE, PC Recycle, J-MOSS, Energy Star®, RoHs, CEC, Windows 10/11 WHQL, TÜV Flicker Free, TÜV Low Blue Light

^{*}Specifications are subject to change without notice.

^{**}Power consumption of On Mode as defined in Energy Star 8.0 version.

3.3 Outline dimensions



3.4 Troubleshooting (FAQ)

Problem	Possible Solution
Power LED is not ON	 Press the button to check if the monitor is in the ON mode. Check if the power cord is properly connected to the monitor and the power outlet. Check if the power switch is ON.
The power LED lights amber and there is no screen image	 Check if the monitor and the computer are in the ON mode. Make sure the signal cable is properly connected the monitor and the computer. Inspect the signal cable and make sure none of the pins are bent. Connect the computer with another available monitor to check if the computer is properly working.
Screen image is too light or dark	Adjust the Contrast and Brightness settings via OSD.
Screen image bounces or a wave pattern is present in the image	 Make sure the signal cable is properly connected to the monitor and the computer. Move electrical devices that may cause electrical interference.
Screen image has color defects (white does not look white)	 Inspect the signal cable and make sure that none of the pins are bent. Perform All Reset via OSD. Adjust the R/G/B color settings or select the Color Temperature via OSD.
No sound or sound is low	 Ensure that the HDMI cable is properly connected to the monitor and the computer. Adjust the volume settings of both your monitor and HDMI device. Ensure that the computer sound card driver is properly installed and activated.

Supported operating modes 3.5

Resolution Frequency	Horizontal Frequency (KHz)	Vertical Frequency (Hz)	Pixel Clk (MHz)
640 x 480	31.47(N)	59.94(N)	25.18
640 x 480	37.5(N)	75(N)	31.5
800 x 600	37.88(P)	60.32(P)	40
800 x 600	46.88(P)	75(P)	49.50
1024 x 768	48.36(N)	60(N)	65
1024 x 768	60.02(P)	75.03(P)	78.75
1280 x 960	60(P)	60(P)	108
1280 x 1024	63.98(P)	60.02(P)	108
1280 x 720	45(P)	60(P)	74.25
1600 x 900	60(P)	60(P)	108
1920 x 1080	67.5(P)	60(P)	148.5
1920 x 1080	112.38(P)	100(N)	227

[&]quot;P" / "N" stands for "Positive" / "Negative" polarity of incoming H-sync/V-sync (input timing).
VGA mode only support to resolution:1920x1080 /60Hz.

When the monitor is operating in the video mode (ie, not displaying data), the following high definition modes shall be supported in addition to standard definition video.

Resolution	Vertical Frequency (Hz)
	100 Hz
1920 x 1080	60 Hz
	59.94 Hz
	50 Hz
	60 Hz
1280 x 720P	59.94 Hz
	50 Hz
720 x 576P	50 Hz
720 x 480P	60 Hz
720 X 460P	59.94 Hz
0.40 4000	60 Hz
640 x 480P	59.94 Hz