



# COVERT VIDEO KEYCHAIN

RECORD VIDEO & AUDIO

## User Manual

Model CS-KEY-4GB



Covert Security

### Features

**REC** Record Video Clips on the Go

**Audio** Audio Recording up to 20 Feet

**USB** Connects Easily to your Computer

**2 hrs** Record up to 2 Hours of Video/Audio

**4 GB** 4GB Micro SD Card Included

### Ideal Use



#### Home / Family

- Nanny Camera
- Record on-the-go
- Record family activities



#### Office / Business

- Record classes and meetings
- Covert recording
- Monitor your business while traveling



## Table of Contents

Chapter 1 : FCC Radiation Norm .....	3
Chapter 2 : Package Contents .....	4
Chapter 3 : System Requirements.....	5
Chapter 4 : Hardware Description .....	6
Chapter 5 : Charging Your Keychain .....	7
Chapter 6 : Changing the Time and Date .....	8
Chapter 7 : Recording a Video.....	10
Chapter 8 : Download Your Videos .....	11
Chapter 9 : Reset Your Keychain .....	13
Chapter 10 : Warranty.....	14



Interactive How-To videos are available for the chapters indicated with this icon.

You can also visit Night Owl's website at <http://www.nightowlsp.com/Videos>

## Chapter 1: FCC Radiation Norm

### **FCC**

This equipment has been tested and found to comply with limits for Class B digital device pursuant to Part 15 of Federal Communications Commission (FCC) rules.

### **FCC Compliance Statement**

These limits are designed to provide reasonable protection against frequency interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed or used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment off and on. The user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected to.



### **CAUTION!**

The Federal Communications Commission warns the user that changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Your new Keychain will contain the following items.

- Video Keychain
- USB Cable
- 4GB Micro SD Card
- User Manual



## Chapter 3: System Requirements

Please be sure the computer that you will use the Keychain with complies with the following specifications:

- IBM PCs or 100% Compatibles
- Windows® 2000, XP, Vista, 7
- Mac® OS 10.3 and above
- Available USB Port





Prior to use, please charge your new keychain using the included USB cable for 8 hours for optimal performance.

1. To charge your keychain, locate the USB cable that was provided in the packaging. Plug the smaller end of the cable into the USB connection slot on the keychain.



USB Connection

2. Connect the other end of the USB cable to your computer. The LED indicator will flash between green and red while the keychain is charging.



USB Connection

3. Once the keychain is completely charged, the LED indicator will turn to a solid red color.



LED Indicator




If your battery is running low, the LED indicator will flash yellow 3 times then again after 2 seconds before it automatically shuts down.






1. To change the time and date on your keychain, connect it to your computer.
2. A window will pop-up once you have inserted the USB into the computer. Click “Open folder to view files”.



3. Open the text file named “Time” to edit the time and date. The format of the time and date must be set in “YYYY.MM.DD HH:MM:SS” using Military Time.



4. Go to “File”, “Save” the document and safely remove the keychain from your computer.
5. Turn on the keychain once to initiate the reset.



On / Off Button



When your keychain’s battery is too low, the time may reset to factory default. You will need to reset the time again if you want your recorded files to have the correct recording time.



Prior to recording any videos, make sure that the memory card is properly inserted into the keychain.

1. To turn on the keychain, press and hold the On/Off button for 2 seconds, the red LED indicator will come on and turn green to indicate the keychain is on and ready for use.



On / Off Button



LED Indicator

2. Press the Start/Stop button once. The LED indicator will turn red to indicate the keychain is recording.



Start / Stop Button



LED Indicator

3. To stop recording, press the Start/Stop button once again. The LED indicator turns to green when recording stops.



Your keychain will automatically shut down if not used for 30 seconds. The red LED indicator will flash six times then the keychain will automatically shut down when memory card is full.



### For All Operating Systems

1. Turn on your computer.
2. Make sure your keychain is turned off.
3. Locate the USB cable that was provided in the packaging. Plug the smaller end of the cable into the USB connection slot on the keychain.




USB Connection

4. Connect the other end of the USB cable to your computer. Your computer will install the necessary drivers automatically.




USB Connection


5. A window will pop-up once you have inserted the USB into the computer. Click “Open folder to view files”. If you do not receive this pop-up proceed to step 6.



6. If you did not receive a pop-up window, your keychain can be found as “Removable Disk” under “My computer”. Double click the icon to open the folder.



7. All of the recorded files can be found within the drive that indicates your keychain. Recorded files will be listed in the “Video” folder.



## Chapter 9: Reset Your Keychain



If your keychain has stopped working you will need to reset your device.

1. Locate the Reset button on the side of the keychain.



2. Using a pin, press and hold down the reset button for two seconds



3. Your keychain will reset and you will be able to record videos.



This will not erase any data on your keychain.

## Chapter 10: Warranty

NIGHT OWL, LLC (“Night Owl”) provides the following warranty to the original retail purchaser only (the “Purchaser”) with respect to this product (the “Product”):

For a period of one (1) year after the date of sale, the Product shall be free from manufacturing defects in material and workmanship. In the event that the Product is defective, the Purchaser must return the Product at Purchaser’s cost (no CODs) to the address below, with the original proof of purchase receipt. In its sole discretion, Night Owl will either repair or replace the Product at no additional cost to the Purchaser. Any replacement Product (or parts) will be covered by the same warranty as the original Product through the expiration date of the original warranty period.

### **Exclusions:**

This warranty does not apply to the following parts or upon the following events:

- Bulbs, LEDs and batteries;
- The Product was not used or installed in the manner described in the installation instructions;
- Negligent use of the Product, or misuse or abuse of the Product;
- Electrical short circuits or power surges;
- Use of replacement parts not supplied by Night Owl;
- Product is either tampered with, modified, or repaired by another service provider;
- Product has not been maintained in accordance with the instructions;
- Accident, fire, flood or other acts of God;
- Failure to use Night Owl approved accessories;

- Defects or damages arising by use of the Product in other than normal conditions (including normal atmospheric, moisture and humidity conditions).

Except as otherwise prohibited by law, this warranty is in lieu of other warranties, express or implied, and Night Owl neither assumes nor authorizes any person to assume for it any other obligation or liability in connection with the sale or service of the Product.

In no event shall Night Owl be liable for any special or consequential damages arising from the use of the Product or arising from the malfunctioning or non-functioning of the Product, or for any delay in the performance of this warranty due to any cause beyond its control. This warranty shall not apply to installation or the removal and reinstallation of products after repair.

Night Owl does not make any claims or warranties of any kind whatsoever regarding the Product's potential, ability or effectiveness to prevent, minimize, or in any way affect personal or property damage or injury. Night Owl is not responsible for any personal damage, loss or theft related to the Product or to its use for any harm, whether physical or mental related thereto. Any and all claims or statements, whether written or verbal, by salespeople, retailers, dealers or distributors to the contrary are not authorized by Night Owl, and do not affect this provision of this warranty.



## Returns under this Warranty

In order to obtain service, please make sure that you have registered your product on-line no later than thirty (30) days after purchase at [www.NightOwlSP.com](http://www.NightOwlSP.com) in the warranty registration section or in any other matter described in the instructions.

## TOLL FREE CUSTOMER SERVICE

North America: 1-866-390-1303

Email: [Support@NightOwlSP.com](mailto:Support@NightOwlSP.com)

Website: [www.NightOwlSP.com](http://www.NightOwlSP.com)

Email: [Support@NightOwlSP.com](mailto:Support@NightOwlSP.com)

Rev 04-2010

# NIGHT OWL



# CUSTOMER SUPPORT



**BEFORE YOU RETURN TO THE STORE,  
WE MIGHT BE ABLE TO SAVE YOU A TRIP**



## ONLINE

### 24/7 Product Support

- How-To Videos
- Manuals
- Firmware Updates etc.

[www.NightOwlISP.com](http://www.NightOwlISP.com)

---

## EMAIL

### Technical Support

- Technical Issues
- Warranty Replacement

Email: [Support@NightOwlISP.com](mailto:Support@NightOwlISP.com)



### Sales Support

- Accessory Sales
- Sales Related Questions

Email: [Sales@NightOwlISP.com](mailto:Sales@NightOwlISP.com)

---

## PHONE

### Technical Support 1-866-390-1303

- 24/7 365 Days a Year

### Sales Support 1-866-390-1303 choose option 1

- 9:00AM - 5:00PM EST Monday thru Friday

### Professional Installation 1-800-806-5513

- 9:00AM - 5:00PM EST Monday thru Friday

