



Package Contents:

- Light Gun
- Steering Wheel
- Jeli Grips
- Baseball extension
- Tennis extension
- Golf extension
- Pool extension
- Remote Cradle
- 2 Game Grips
- 2 Remote Savers
- 2 Wrist Straps

Light Gun instructions:

1. Place your Wii remote and nunchuck into the Light Gun's casing by setting the Wii remote into the Light Gun's barrel casing and the Wii nunchuck into the Light Gun's handle.
- Open the lid on the Light Gun.
- Place the Wii remote into the Light Gun's barrel casing.
- Place the Wii nunchuck into the Light Gun's handle casing.
2. Close the lid on the Light Gun.
3. You are now ready to enjoy your Light Gun with your favorite 1st person shooter or shooting games.

Steering Wheel instructions:

1. Place your Wii remote into the Steering Wheel.
(the Wii remote's directional pad should be on the left side)
2. The Steering Wheel features an infrared pass-thru, which allows you to make on-screen selections without removing the Wii remote from the Steering Wheel.

Jeli Grip instructions:

1. Carefully slide the Wii remote Jeli Grip over the Wii remote.
2. Carefully slide the Wii nunchuck Jeli Grip over the Wii nunchuck.

Sports extension instructions:

1. Place your Wii remote into the Remote Cradle.
2. Depending on which game you are playing, choose the appropriate remote extension.
3. With your Wii remote connected to the Remote Cradle, attach the Tennis Racket, Golf Club, Baseball Bat, or Pool Cue to the Remote Cradle by screwing the extension of choice into the Remote Cradle.

Game Grips instructions:

1. Replace the battery cover on the back of your Wii remote with the Game Grips for enhanced control during gameplay.

Remote Savers instructions:

1. Carefully remove backing from Remote Saver and place onto your Wii remote, making sure not to obstruct the movement of the buttons.