



User Guide

© Copyright 2017 HP Development Company, L.P.

HDMI, the HDMI Logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC. NVIDIA and G-SYNC are trademarks and/or registered trademarks of NVIDIA Corporation in the U.S. and/or other countries. Windows is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Product Notice


This guide describes features that are common to most models. Some features may not be available on your product. To access the latest user guide, go to <http://www.hp.com/support>. Select **Find your product**, and then follow the on-screen instructions.


First Edition: April 2017


Document Part Number: 922770-001

About This Guide


This guide provides information on monitor features, setting up the monitor, using the software and technical specifications.

 **WARNING!** Indicates a hazardous situation that, if not avoided, **could** result in death or serious injury.

 **CAUTION:** Indicates a hazardous situation that, if not avoided, **could** result in minor or moderate injury.

 **IMPORTANT:** Indicates information considered important but not hazard-related (for example, messages related to property damage). A notice alerts the user that failure to follow a procedure exactly as described could result in loss of data or in damage to hardware or software. Also contains essential information to explain a concept or to complete a task.

 **NOTE:** Contains additional information to emphasize or supplement important points of the main text.

 **TIP:** Provides helpful hints for completing a task.



This product incorporates HDMI technology.

Table of contents

1 Getting started	1
Important safety information	1
Product features and components	2
Features	2
Identifying rear components	3
Setting up the monitor	4
Use caution when setting up the monitor	4
Installing the stand	4
Connecting the cables	5
Connecting USB devices	7
Adjusting the monitor for comfort	8
Turning on the monitor	9
Installing a security cable	10
Storing headphones	10
Using the ambient light	11
Mounting the display head	12
Removing the monitor stand	12
Attaching the VESA mounting bracket	13
2 Using the monitor	14
Software and utilities	14
Enabling G-SYNC	14
The Information file	14
The Image Color Matching file	14
Installing the INF and ICM files	15
Installing from the optical disc (available in select regions)	15
Downloading from the web	15
Using the on-screen display (OSD) menu	15
Selecting a faster response time for gaming	16
Using Deep Sleep mode	16
Selecting the Low Blue Light mode	17
Turning on OverClock	17
3 Support and troubleshooting	18
Solving common problems	18
OSD lockout	18

Contacting support	19
Preparing to call technical support	19
Locating the serial number and product number	19
4 Maintaining the monitor	20
Maintenance guidelines	20
Cleaning the monitor	20
Shipping the monitor	20
Appendix A Technical specifications	21
Preset display resolutions	22
Entering user modes	23
Power adapter	23
Energy saver feature	23
Appendix B Accessibility	24
Supported assistive technologies	24
Contacting support	24

1 Getting started

Important safety information


An AC power adapter and cord may be included with the monitor. If another cord is used, use only a power source and connection appropriate for this monitor. For information on the correct power cord set to use with the monitor, refer to the *Product Notices* provided on the optical disc or in your documentation kit.

 **WARNING!** To reduce the risk of electric shock or damage to the equipment:


- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the computer by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

For your safety, do not place anything on power cords or cables. Arrange them so that no one may accidentally step on or trip over them.

To reduce the risk of serious injury, read the *Safety & Comfort Guide*. It describes proper workstation setup, and proper posture, health, and work habits for computer users. The *Safety & Comfort Guide* also provides important electrical and mechanical safety information. The *Safety & Comfort Guide* is available on the Web at <http://www.hp.com/ergo>.

 **IMPORTANT:** For the protection of the monitor, as well as the computer, connect all power cords for the computer and its peripheral devices (such as a monitor, printer, scanner) to some form of surge protection device such as a power strip or uninterruptible power supply (UPS). Not all power strips provide surge protection; the power strips must be specifically labeled as having this ability. Use a power strip whose manufacturer offers a damage replacement policy so you can replace the equipment if surge protection fails.

Use the appropriate and correctly sized furniture designed to properly support your HP LCD monitor.


 **WARNING!** LCD monitors that are inappropriately situated on dressers, bookcases, shelves, desks, speakers, chests, or carts may fall over and cause personal injury.

Care should be taken to route all cords and cables connected to the LCD monitor so that they cannot be pulled, grabbed, or tripped over.

Be sure that the total ampere rating of the products connected to the AC outlet does not exceed the current rating of the outlet, and that the total ampere rating of the products connected to the cord does not exceed the rating of the cord. Look on the power label to determine the ampere rating (AMPS or A) for each device.

Install the monitor near an AC outlet that you can easily reach. Disconnect the monitor by grasping the plug firmly and pulling it from the AC outlet. Never disconnect the monitor by pulling the cord.

Do not drop the monitor or place it on an unstable surface.


 **NOTE:** This product is suitable for entertainment purposes. Consider placing the monitor in a controlled luminous environment to avoid interference from surrounding light and bright surfaces that may cause disturbing reflections from the screen.

Product features and components


Features

The monitor features include the following:

- 68.47 cm (27-inch) diagonal viewable area with 2560 × 1440 QHD resolution, plus full-screen support for lower resolutions
- Tilt and height-adjustment capability
- Wide viewing angle technology
- HDMI (High-Definition Multimedia Interface) video input
- DisplayPort video input
- HDCP (High-bandwidth Digital Content Protection) used on digital inputs
- USB 3.0 hub with one upstream port and two downstream charging ports
- Audio headphone/variable line-out jack
- DisplayPort, HDMI, and USB Type-B to Type-A cables included
- Plug and Play capability, if supported by your operating system
- On-screen display (OSD) adjustments in several languages for easy setup and screen optimization
- Software and documentation disc that includes monitor drivers and product documentation
- VESA mounting bracket for attaching the monitor to a wall-mount device or swing arm
- Security cable slot provision on rear of monitor for optional security cable
- User configurable ambient lighting with full-range LEDs
- Convenient headphone storage hook on monitor stand
- NVIDIA G-SYNC™ technology with high refresh rates, providing PC gaming advantages in reaction time and a more true-to-life experience
 - Smoothness is achieved by synchronizing display refresh rates to the GPU in your GeForce GTX-powered desktop or notebook, eliminating screen tearing and minimizing display stutter and input lag
 - Scenes appear instantly, objects look sharper, and game play is super smooth, giving you a stunning visual experience and a serious competitive edge
- NVIDIA Ultra Low Motion Blur (ULMB) technology is an additional mode featured in G-SYNC monitors that decreases motion blur and minimizes ghosting introduced when on-screen elements are rapidly moving. With ULMB, objects in motion look smoother than they do during standard operation. ULMB is only available through a DisplayPort input.
- NVIDIA 3D Vision® technology delivers stereoscopic 3D images for gamers, movie-lovers and photo enthusiasts when configured with NVIDIA GPUs, NVIDIA 3D Vision active shutter glasses, and 3D Vision-Ready display/projector. Only NVIDIA 3D Vision supports the richest array of 3D content available - more than 600 3D games, Blu-ray 3D movies, 3D photos and streaming 3D videos.
- Enhanced monitor overclocking provides a higher refresh rate that delivers less blur on moving objects and reduces input latency.

 **NOTE:** For safety and regulatory information, refer to the *Product Notices* provided in your documentation kit. To locate updates to the user guide for your product, go to <http://www.hp.com/support>. Select **Find your product**, and then follow the on-screen instructions.

Identifying rear components



	Component	Description
(1)	Power button	Turns the monitor on or off.
(2)	Plus button	If the OSD menu is open, press to navigate forward through the OSD menu and increase adjustment levels. If the OSD menu is closed, press to open the Viewing Modes menu.
(3)	Minus button	If the OSD menu is open, press to navigate backward through the OSD menu and decrease adjustment levels. If the OSD menu is closed, press to adjust screen brightness.
(4)	Menu button	Press to open the OSD menu, select a menu item from the OSD, or close the OSD menu.
(5)	OK button	Selects the highlighted OSD menu item.
(6)	USB 3.0 Type-A port	Connects USB devices.
(7)	USB 3.0 Type-A port	Connects USB devices.
(8)	USB 3.0 Type-B port	Connects the USB hub cable to the source device.
(9)	Power connector	Connects an AC adapter.
(10)	Service port	Used by qualified HP service technicians only.
(11)	DisplayPort port	Connects the DisplayPort cable to the source device.
(12)	HDMI port	Connects the HDMI cable to the source device.
(13)	Audio-out (headphone) jack	Connects headphones to the monitor. WARNING! To reduce the risk of personal injury, adjust the volume before using headphones, earbuds, or a headset. For additional safety information, see the <i>Product Notices</i> provided on the optical disc, if one is included with your product.

Setting up the monitor


Use caution when setting up the monitor



IMPORTANT: To prevent damage to the monitor, do not touch the surface of the LCD panel. Pressure on the panel may cause nonuniformity of color or disorientation of the liquid crystals. If this occurs, the screen will not recover to its normal condition.

Installing the stand

1. Position the monitor facedown on a flat surface covered by a soft clean cloth.
2. Slide the hinge on the stand into the hinge slot on the back of the display head to secure the stand to the display head. There will be an audible click when the stand is properly seated onto the hinge. Make sure that the stand is properly secured to the display head before use.



Connecting the cables




NOTE: The monitor ships with select cables.

1. Place the monitor in a convenient, well-ventilated location near the computer or source device.
2. Connect a video cable.




NOTE: The monitor will automatically determine which inputs have valid video signals. The inputs can also be selected by pressing the **Menu** button on the rear of the monitor and selecting **Input Control**.


- Connect one end of a DisplayPort cable to the DisplayPort port on the rear of the monitor and the other end to the DisplayPort port on the source device.




- Connect one end of an HDMI cable to the HDMI port on the rear of the monitor and the other end to the HDMI port on the source device.



3. Connect the Type-B connector on the USB upstream cable to the USB upstream port on the rear of the monitor. Then connect the cable's Type-A connector to the USB downstream port on the source device.



4. Connect one end of the power cord to the AC adapter (1) and the other end to a grounded electrical outlet (2). Then connect the AC adapter to the monitor (3).



⚠ WARNING! To reduce the risk of electric shock or damage to the equipment:


Do not disable the power cord grounding plug. The grounding plug is an important safety feature.

Plug the power cord into a grounded (earthed) AC outlet that is easily accessible at all times.

Disconnect power from the equipment by unplugging the power cord from the electrical outlet.

For your safety, do not place anything on power cords or cables. Arrange them so that no one may accidentally step on or trip over them. Do not pull on a cord or cable. When unplugging from the AC outlet, grasp the cord by the plug.


5. Route the cables through the cable management clip on the rear of the monitor.



Connecting USB devices


The rear of the monitor provides one USB Type-B upstream port and two USB Type-A downstream ports.

 **NOTE:** You must connect the USB upstream cable from the source device to the monitor to enable the USB downstream ports on the monitor.




Adjusting the monitor for comfort

Tilt the display head forward or backward to set it to a comfortable eye level.




Adjust the display head up or down to set it to a comfortable eye level.




Turning on the monitor

1. Press the power button on the source device to turn it on.
2. Press the power button on the rear of the monitor to turn it on.




 **IMPORTANT:** Burn-in image damage may occur on monitors that display the same static image on the screen for 12 or more consecutive hours of nonuse. To avoid burn-in image damage on the monitor screen, you should always activate a screen saver application or turn off the monitor when it is not in use for a prolonged period of time. Image retention is a condition that may occur on all LCD screens. Monitors with a “burned-in image” are not covered under the HP warranty.

 **NOTE:** You can disable the power light in the OSD menu. Press the [Menu](#) button on the rear of the monitor, and then select **Power Control > Power LED > Off**.

The monitor automatically scans the signal inputs for an active input and uses that input for the display.

Installing a security cable

You can secure the monitor to a fixed object with an optional security cable available from HP.



Storing headphones

The monitor features a headphone hook at the top of the stand for convenient headphone storage.



Using the ambient light

The monitor features an ambient light to illuminate a desk top or wall and enhance the gaming experience. You can adjust the light or turn it off in the OSD. Press the **Menu** button on the rear of the monitor, and then select **Ambient Lighting**.

You can change the color of the ambient lighting to match LED lighting on computer, keyboard, and mouse. You can also change the screen glow to output the average color on the display, expanding the on-screen action beyond the display.



Mounting the display head

The display head can be attached to a wall, swing arm, or other mounting fixture.



NOTE: This apparatus is intended to be supported by a UL or CSA Listed wall-mount bracket.



IMPORTANT: This VESA mount kit supports the VESA industry-standard 100 mm mounting holes. To attach a third-party mounting solution to the VESA mount, use four 4 mm, 0.7 pitch, 10 mm-long screws. Longer screws must not be used because they may damage the monitor. It is important to verify that the manufacturer's mounting solution is compliant with the VESA standard and is rated to support the weight of the monitor display panel. For best performance, it is important to use the power and video cables provided with the monitor.


Removing the monitor stand

You can remove the display head from the stand to install the display head on a wall, a swing arm, or other mounting fixture.



IMPORTANT: Before beginning to disassemble the monitor, be sure the monitor is turned off and all cables are disconnected.


1. Disconnect and remove all cables from the monitor.
2. Lay the monitor face down on a flat surface covered by a soft clean cloth.
3. Press the release button on the underside of the stand's hinge (1), and then slide the stand off the display head (2).




Attaching the VESA mounting bracket

A VESA mounting bracket is included with the monitor for use when attaching the display head to a wall, swing arm, or other mounting fixture.

1. Lay the monitor face down on a flat surface covered by a soft clean cloth.
2. Remove the monitor stand if it is attached to the display head. Refer to [Removing the monitor stand on page 12](#).
3. Insert the VESA mounting bracket into the slot on the back of the display head's hinge to secure the bracket to the display head. There will be an audible click when the bracket is properly seated onto the hinge. Make sure that the bracket is properly secured to the display head before use.



4. To attach the display head to a swing arm or other mounting device, insert four mounting screws through the holes on the mounting device and into the screw holes on the VESA mounting bracket.



IMPORTANT: Follow the mounting device manufacturer's instructions when mounting the monitor to a wall or swing arm.

IMPORTANT: For optimal monitor performance and screen clarity, do not rotate the monitor 90 degrees to portrait orientation.

2 Using the monitor

Software and utilities

The NVIDIA control panel software must be downloaded and installed from <http://www.geforce.com/drivers>. In order to use NVIDIA G-SYNC, you must have a G-SYNC-compatible graphics card. A list of compatible cards is available at <http://www.geforce.com/hardware/technology/g-sync/supported-gpus>.

The optical disc, if one is included with the monitor, contains files that you can install on the computer. If you do not have an optical drive, you can download the files from <http://www.hp.com/support>.

- INF (Information) file
- ICM (Image Color Matching) files (one for each calibrated color space)

Enabling G-SYNC

To enable the monitor for G-SYNC:

1. Right-click on the Windows® desktop and select **NVIDIA Control Panel**.
2. Select **Display** from the links on the left, and choose **Set up G-SYNC**.
3. Check the box titled **Enable G-SYNC**.

The Information file

The INF file defines monitor resources used by Windows operating systems to ensure monitor compatibility with the computer's graphics adapter.

This monitor is Windows Plug and Play-compatible, and the monitor will work correctly without installing the INF file. Monitor Plug and Play compatibility requires that the computer's graphic card is VESA DDC2-compliant and that the monitor connects directly to the graphics card. Plug and Play does not work through separate BNC-type connectors or through distribution buffers/boxes.

The Image Color Matching file

The ICM files are data files that are used in conjunction with graphics programs to provide consistent color matching from monitor screen to printer, or from scanner to monitor screen. This file is activated from within graphics programs that support this feature.



NOTE: The ICM color profile is written in accordance with the International Color Consortium (ICC) Profile Format specification.

Installing the INF and ICM files

After you determine that you need to update, use one of the following methods to install the files.

Installing from the optical disc (available in select regions)

To install the INF and ICM files on the computer from the optical disc, if one is provided:

1. Insert the optical disc into the computer optical drive. The optical disc menu is displayed.
2. View the **HP Monitor Software Information** file.
3. Select **Install Monitor Driver Software**.
4. Follow the on-screen instructions.
5. Ensure that the proper resolution and refresh rates appear in the Windows Display control panel.

Downloading from the web

If you do not have a computer or source device with an optical drive, you can download the latest version of INF and ICM files from the HP monitors support website.

1. Go to <http://www.hp.com/support>.
2. Select **Get software and drivers**.
3. Follow the on-screen instructions to select your monitor and download the software.

Using the on-screen display (OSD) menu

Use the on-screen display (OSD) menu to adjust the screen image based on your viewing preferences. You can access and make adjustments in the OSD using the buttons on the rear of the monitor.

To access the OSD and make adjustments, do the following:

1. If the monitor is not already on, press the power button to turn on the monitor.
2. To access the OSD menu, press the **Menu** button on the rear of the monitor.
3. To navigate through the OSD menu, press the **Plus** button on the rear of the monitor to scroll up, or the **Minus** button to scroll down.
4. To select an item from the OSD menu, use the **Plus** or **Minus** buttons to scroll to and highlight your selection, then press the **OK** button to select that function.
5. Adjust the item using the **Plus** or **Minus** buttons to adjust the scale.
6. After adjusting the function, select **OK** to save the setting, and then select **Exit** from the Main menu.

Main menu	Description
Luminance (or NVIDIA LightBoost)	Adjusts the brightness level of the screen. The factory default is 100. When NVIDIA 3D vision is enabled, Luminance will be changed to NVIDIA LightBoost.
Color Control	Selects and adjusts the screen color and viewing modes.
Input Control	Selects the video input signal (DisplayPort or HDMI).
Image Control	Adjusts the screen image and response time.
Power Control	Adjusts the power settings.

Main menu	Description
Menu Control	Adjusts the on-screen display (OSD) controls.
Management	Returns all OSD menu settings to the factory default settings.
Ambient Lighting	Adjusts the monitor's ambient lighting.
Language	Selects the language in which the OSD menu is displayed.
Information	Selects and displays important information about the monitor.
Exit	Exits the OSD menu screen.

Selecting a faster response time for gaming

To set a faster response time:

1. Open the OSD menu.
2. Select **Image Control** and then select **Response Time**.
3. Select one of the following levels from the **Response Time** menu:

Level 1

Level 2 (Fast)

Level 3 (Default)

Level 4

Level 5

Level 6 (Fastest)



NOTE: The default response time setting is optimized for G-SYNC gaming purposes. The response time can be adjusted to as fast as 1 ms in the display menu. All performance specifications represent the typical specifications provided by HP's component manufacturers; actual performance may vary either higher or lower.

Using Deep Sleep mode



The monitor is enabled by default to enter a reduced power state mode called Deep Sleep mode. This occurs 13 minutes after the host PC signals low power mode (which is an absence of either horizontal or vertical sync signal).


Upon entering Deep Sleep mode, the monitor screen is blanked, the backlight is turned off, the power LED indicator turns amber, and the monitor draws less than 0.5 W of power.

The monitor wakes from Deep Sleep mode when the host computer sends an active signal to the monitor (for example, if you activate the mouse or keyboard). You can disable Deep Sleep in the OSD. Press the [Menu](#) button on the rear of the monitor to open the OSD. In the OSD menu, select **Power Control**. Then select either **DP Deep Sleep** or **HDMI Deep Sleep**. Then select **Off**.

Selecting the Low Blue Light mode

Decreasing the blue light emitted by the display reduces the blue light exposure to your eyes. HP monitors provide settings to reduce the blue light output and create a more relaxing and less stimulating image while you view content on the screen. To adjust your monitor to a comfortable viewing light, follow the steps below.


1. Press one of the OSD buttons on the monitor to display the OSD icons on the screen.
2. Select the **Viewing Modes** icon  to open the **Viewing Modes** menu, or select the **Menu** icon . Then select **Color Control** > **Viewing Modes**.
3. Choose one of the following settings:
 - Low Blue Light—Reduces blue light for improved eye comfort
 - Night—Adjusts the monitor to the lowest blue light output

 **WARNING!** To reduce the risk of serious injury, read the *Safety & Comfort Guide*. It describes proper workstation setup, and proper posture, health, and work habits for computer users. The *Safety & Comfort Guide* also provides important electrical and mechanical safety information. The *Safety & Comfort Guide* is available on the Web at <http://www.hp.com/ergo>.

Turning on OverClock

Enhanced monitor overclocking provides a higher refresh rate that delivers less blur on moving objects and reduces input latency. To turn on OverClock, follow the steps below.

1. Press the **Menu** button to open the OSD menu.
2. In the OSD menu, select **Image Control**, and then select **OverClock**. Then select **On** to turn on OverClock.

 **NOTE:** Overclocking may result in flicker or other adverse effects that may derive from the total configuration of the system or external source device connected to the monitor, and possibly, in addition, the monitor's panel specifications. It may be possible to resolve or reduce such effects by turning off OverClock to set a lower refresh rate.

3 Support and troubleshooting

Solving common problems

The following table lists possible problems, the possible cause of each problem, and the recommended solutions.

Problem	Possible Cause	Solution
Screen is blank or video is flashing.	Power cord is disconnected.	Connect the monitor power cord.
	Monitor is turned off.	Press the monitor power button.
	Video cable is not connected.	Connect the video cable between the source device and monitor. Be sure the computer power is off while you connect the video cable. Refer to Connecting the cables on page 5 for more information.
	System is in sleep mode.	Press any key on the keyboard or move the mouse to exit sleep mode.
	Video card is incompatible.	Replace the video card or connect the video cable to one of the computer's onboard video sources. A list of compatible NVIDIA G-SYNC video cards is available at http://www.geforce.com/hardware/technology/g-sync/supported-gpus .
Image appears too dark.	Brightness setting is too low.	Open the OSD menu and select Luminance to adjust the brightness scale as needed.
Input Signal Not Found is displayed on screen.	Monitor video cable is disconnected.	Connect the appropriate video signal cable between the computer and monitor. Be sure that the computer power is off while connecting the video cable.
Input Signal Out of Range is displayed on screen.	Video resolution and/or refresh rate are set higher than the monitor supports.	Change the settings to a supported setting (see Preset display resolutions on page 22).
The monitor is off but it did not seem to enter into a low-power sleep mode.	The monitor's sleep mode is disabled.	Open the OSD menu and select Power Control . Then select either DP Deep Sleep or HDMI Deep Sleep . Then select Off .
OSD Lockout is displayed.	The monitor's OSD Lockout function is enabled.	Press and hold the Menu button on the side panel for 10 seconds to disable the OSD Lockout function.

OSD lockout

Holding down the **Menu** button for ten seconds will lock out the functionality of the button. You can restore the functionality by holding the button down again for ten seconds. This functionality is only available when the display is turned on, displaying an active signal, and the OSD is not active.

Contacting support

To resolve a hardware or software problem, go to <http://www.hp.com/support>. Use this site to get more information about your product, including links to discussion forums and instructions on troubleshooting. You can also find information on how to contact HP and open a support case.

Preparing to call technical support

If you can not solve a problem using the troubleshooting tips in this section, you may need to call technical support. Have the following information available when you call:

- Monitor product number
- Monitor serial number
- Purchase date on invoice
- Conditions under which the problem occurred
- Error messages received
- Hardware configuration
- Name and version of the hardware and software you are using

Locating the serial number and product number

The serial number and product number are located on a label on the bottom edge of the display head. You may need these numbers when contacting HP about the monitor model.



4 Maintaining the monitor

Maintenance guidelines

To enhance the performance and extend the life of the monitor:

- Do not open the monitor cabinet or attempt to service this product yourself. Adjust only those controls that are covered in the operating instructions. If the monitor is not operating properly or has been dropped or damaged, contact an authorized HP dealer, reseller, or service provider.
- Use only a power source and connection appropriate for this monitor, as indicated on the label/back plate of the monitor.
- Be sure the total ampere rating of the products connected to the outlet does not exceed the current rating of the electrical outlet, and the total ampere rating of the products connected to the cord does not exceed the rating of the cord. Look on the power label to determine the ampere rating (AMPS or A) for each device.
- Install the monitor near an outlet that you can easily reach. Disconnect the monitor by grasping the plug firmly and pulling it from the outlet. Never disconnect the monitor by pulling the cord.
- Turn the monitor off when not in use. You can substantially increase the life expectancy of the monitor by using a screen saver program and turning off the monitor when not in use.



NOTE: Monitors with a “burned-in image” are not covered under the HP warranty.

- Slots and openings in the cabinet are provided for ventilation. These openings must not be blocked or covered. Never push objects of any kind into cabinet slots or other openings.
- Do not drop the monitor or place it on an unstable surface.
- Do not allow anything to rest on the power cord. Do not walk on the cord.
- Keep the monitor in a well-ventilated area, away from excessive light, heat or moisture.

Cleaning the monitor

1. Turn off the monitor and unplug the power cord from the AC outlet.
2. Dust the monitor by wiping the screen and the cabinet with a soft, clean antistatic cloth.
3. For more difficult cleaning situations, use a 50/50 mix of water and Isopropyl alcohol.



IMPORTANT: Spray the cleaner onto a cloth and use the damp cloth to gently wipe the screen surface. Never spray the cleaner directly on the screen surface. It may run behind the bezel and damage the electronics.

IMPORTANT: Do not use cleaners that contain any petroleum-based materials such as benzene, thinner, or any volatile substance to clean the monitor screen or cabinet. These chemicals may damage the monitor.

Shipping the monitor

Keep the original packing box in a storage area. You may need it later if you move or ship the monitor.

A Technical specifications



NOTE: All specifications represent the typical specifications provided by HP's component manufacturers; actual performance may vary either higher or lower.

For the latest specifications or additional specifications on this product, go to <http://www.hp.com/go/quickspecs/> and search for your specific display model to find the model-specific QuickSpecs.

Specification	Measurement	
Display, wide-screen	68.47 cm	27 in
Type	QHD	
Viewable image size	68.47 cm, diagonal	27 in, diagonal
Tilt	-5° to 23°	
Height adjustment	130 mm	5.12 in
Weight		
Without stand	4.28 kg	9.44 lb
With stand	6.42 kg	14.15 lb
Dimensions (including stand)		
Height	53.36 cm	21.01 in
Depth	27.25 cm	10.73 in
Width	61.4 cm	24.17 in
Maximum graphic resolution	DP 2560 × 1440 (OverClock on = 165 Hz) DP 2560 × 1440 (OverClock on = 144 Hz) HDMI 2560 × 1440 (60 Hz)	
Optimum graphic resolution	2560 × 1440	
Text mode	640 × 480	
Static contrast ratio	1000:1 typical	
Dot pitch	0.233 mm × 0.233 mm	
Pixels per inch	108.97 PPI	
Horizontal frequency	DP (OverClock off) = 34–222 KHz DP (OverClock on) = 34–240 KHz HDMI = 30–140 KHz	
Vertical refresh rate	DP (OverClock off) = 30–144 Hz DP (OverClock on) = 30–165 Hz HDMI = 24–60 Hz	
Response time	The default response time for the monitor is 5 ms. The response time can be adjusted to as fast as 1 ms in the display menu. All performance	

Specification	Measurement	
	specifications represent the typical specifications provided by HP's component manufacturers; actual performance may vary either higher or lower.	
Environmental requirements		
Temperature		
Operating temperature	5°C to 35°C	41°F to 95°F
Storage temperature	-20°C to 60°C	-4°F to 140°F
Relative humidity	20% to 70%	
Altitude		
Operating	0 m to 5,000 m	0 ft to 16,400 ft
Storage	0 m to 12,192 m	0 ft to 40,000 ft
Power source	100 V ac to 240 V ac 50/60 Hz	
Measured power consumption		
Full power	120 W	
Typical settings	75 W	
Sleep	<0.5 W (after 13 minutes)	
Off	<0.5 W (after 14 minutes)	
Input terminals	One HDMI port and one DisplayPort port	

Preset display resolutions

The display resolutions listed below are the most commonly used modes and are set as defaults. The monitor automatically recognizes these preset modes, and they will appear properly sized and centered on the screen.

Preset display resolutions
640 x 480 @ 60 Hz
800 x 600 @ 60 Hz
1024 x 768 @ 60 Hz
2560 x 1440 @ 60 Hz

Entering user modes

The video controller signal may occasionally call for a mode that is not preset if:

- You are not using a standard graphics adapter.
- You are not using a preset mode.

If this occurs, you may need to readjust the parameters of the monitor screen by using the on-screen display. Your changes can be made to any or all of these modes and saved in memory. The monitor automatically stores the new setting, and then recognizes the new mode just as it does a preset mode. In addition to the factory preset modes, there are at least 10 user modes that can be entered and stored.

Power adapter

Manufacturer	Model number	Power supply rating
Delta	ADP-120MH TF	19.5 V dc @ 6.15 A – 120 W

Energy saver feature

The monitor supports a reduced power state. The reduced power state will be entered into if the monitor detects the absence of either the horizontal sync signal and/or the vertical sync signal. Upon detecting the absence of these signals, the monitor screen is blanked, the backlight is turned off, and the power light turns amber. When the monitor is in the reduced power state, the monitor will utilize <0.5 watts of power. There is a brief warm-up period before the monitor will return to its normal operating state.

Refer to the computer manual for instructions on setting the energy saver mode (sometimes called power management feature).



NOTE: The above power saver feature only works when the monitor is connected to a computer that has energy saver features.

By selecting the settings in the monitor's Sleep Timer utility, you can also program the monitor to enter into the reduced power state at a predetermined time. When the monitor's Sleep Timer utility causes the monitor to enter the reduced power state, the power light blinks amber.

B Accessibility

HP designs, produces, and markets products and services that can be used by everyone, including people with disabilities, either on a stand-alone basis or with appropriate assistive devices.

Supported assistive technologies

HP products support a wide variety of operating system assistive technologies and can be configured to work with additional assistive technologies. Use the Search feature on your source device that is connected to the monitor to locate more information about assistive features.



NOTE: For additional information about a particular assistive technology product, contact customer support for that product.

Contacting support

We are constantly refining the accessibility of our products and services and welcome feedback from users. If you have an issue with a product or would like to tell us about accessibility features that have helped you, please contact us at (888) 259-5707, Monday through Friday, 6 a.m. to 9 p.m. Mountain Time. If you are deaf or hard-of-hearing and use TRS/VRS/WebCapTel, contact us if you require technical support or have accessibility questions by calling (877) 656-7058, Monday through Friday, 6 a.m. to 9 p.m. Mountain Time.