

WAGAN Corp. Limited Warranty Registration Form

All WAGAN Corporation products are warranted to the original purchaser of this product.
Warranty Duration: This product is warranted to the original purchaser for a period of one (1) Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the even of a defective item, please ship the item, prepaid, with a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replaces or repair the defective part. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and does not extend to any units which have been used in violation of written instructions furnished.

Warranty Disclaimers: This warranty is in-lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one (1) Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1) Year warranty period.

- Please activate my limited warranty for WAGAN Corp. Wet N' Dry Ultra Vac
- Enclosed copy of original sales receipt.

Name			
Mail Address			
City			
State, Zip Code			
Item Purchased	Wet N' Dry Ultra Vac		
Stores Name			
Date of Purchase			
Signature		Date	

All WAGAN Corporation Products must be registered within (30) days of purchased to activate this warranty. Mail the complete registration form, along with a copy of the original receipt to:

Attn: Customer Service
 WAGAN Corporation
 3589 Yale Way
 Fremont, CA 94538

© 2004 WAGAN Corp.



Item no. 750

WET N' DRY™ ULTRA VAC



User's Manual

Wet N' Dry Ultra Vac by Wagan Tech

USER'S MANUAL — Please read before using this equipment.

Thank you for purchasing the Wet N' Dry Ultra Vac by Wagan Tech. With normal care and proper treatment it will provide years of reliable service. Please read all operating instructions carefully before use.

IMPORTANT!

- This vacuum cleaner OPERATES FROM 12 VOLT ONLY and is designed for use with the 12-VOLT cigarette lighter socket in your car. You MUST CHECK that the standard 30 AMP fuse inserted by most vehicle manufacturers is present in the cigarette lighter circuit BEFORE you attempt to use this vacuum. Referring to your vehicle handbook can easily check this.
- You MUST ENSURE that all other electrical equipment in the car is SWITCHED OFF when vacuum is in use.
- Under no circumstances change the fuse rating in your vehicle; if in doubt seek advice from a qualified person.

ACCESSORIES / SPECIFICATIONS:

Your vacuum cleaner is supplied with:

- a. 10-foot long 12V cord that plugs directly into the cigarette socket.
- b. 40" flexible hose that bends to access all hard to reach areas.
- c. Carpet tool with bristles can be used on even the thickest upholstery.
- d. Crevice attachment allows you to clean ashtrays, under seats and all other narrow areas.
- e. Inflating adaptor allows you to inflate beach balls, air mattresses, rafts and more.


INSTRUCTIONS:

1. On/Off switch is located on the motor housing underneath the casing handle. Do NOT run engine while vacuuming the car.

2. Detach the dirt reservoir by releasing three clips located around the reservoir. Remove the flexible hose attachment from the base of the reservoir and secure the three clips. Select the attachment you wish to use and connect with the hose to the cleaner. Plug into your cigarette socket and turn ON.
3. For inflating, connect the flexible hose attachment to the top of the motor housing and attach the hose adaptor to the other end. Turn ON.
4. Hose and attachments hide away in canister when not in use.

TECHNICAL SPECIFICATIONS:

Operating Voltage:	12 Volts
Motor Rating:	120 Watts
Recommended Fuse:	30 Amps



© 2004 Wagan Corporation.
All Rights Reserved.

Wagan and Wagan.com are trademarks used by Wagan Corporation.