


Cisco Headset 521 and Cisco Headset 522

For Cisco Jabber



High Sound Pressure—Avoid listening to high volume levels for long periods to prevent possible hearing damage.

When you plug in your headset, lower the volume of the headset speaker before you put the headset on. If you remember to lower the volume before you take the headset off, the volume will start lower when you plug in your headset again.

Be aware of your surroundings. When you use your headset, it may block out important external sounds, particularly in emergencies or in noisy environments. Don't use the headset while driving. Don't leave your headset or headset cables in an area where people or pets can trip over them. Always supervise children who are near your headset or headset cables.

Cisco Headset 521 and Cisco Headset 522

Quick Reference Guide

For Cisco Jabber

Answer a call

Press  on the in-line controller.

End a call

Hold  on the in-line controller for 2 seconds.

Reject a call

Press  twice on the in-line controller.

Adjust your volume

Press **+** and **–** on the in-line controller.



Mute yourself on a call

Press  on the in-line controller.



Unmute yourself on a call

Press  on the in-line controller



Put a call on hold and resume a call

1. Press  on the in-line controller.
2. Optional: Select the call you'd like to resume.
3. Press  on the in-line controller.

Change the audio device in Cisco Jabber for Windows

1. Click  and select **Use my computer for calls**.
2. Click **Audio Options** and select Cisco Headset for each audio field.
3. Click  to hear the volume at its current setting.
You can use the volume and mic sensitivity sliders to adjust your speaker volume and mic sensitivity.
4. Click **OK**.

Change the audio device in Cisco Jabber for Mac

1. Click  and select **Use my computer for calls**.
2. Click **Audio Video/Preferences** and select Cisco Headset for each audio field.
3. Click  to hear the volume at its current setting.
You can use the volume and mic sensitivity sliders to adjust your speaker volume and mic sensitivity.
4. Click **OK**.

For more information, visit:

<http://www.cisco.com/go/headsets>

<http://www.cisco.com/go/jabber>