

Ergonomic laptop bag ErgoTraveller



Research

Ergonomic experts do not recommend carrying loads heavier than 4 to 6.4 kg by hand, depending on the distance, frequency and one's sex*. A bag containing a laptop and other contents generally weighs between 4 and 7 kilos. A trolley or rucksack is a good solution if one has to carry this load often and over a fair distance.* Mital et al., 1993

1



1. Lots of storage options
2. Elegant professional look
3. Sleek design

2



3



Ergonomic: open your laptop bag quickly and easily, position your screen at a comfortable height and go straight to work on your laptop.

Portable: start working on your laptop quickly and easily - in the train, hotel lobby, airplane, etc.

Comfortable: keeps your legs cool for using a laptop comfortably on your lap.

Carry-on: perfect for customs checks because the laptop doesn't have to be taken out of its bag.

Great design: exceptionally sleek design made for laptops up to 15.6 inches.

Specifications

Dimensions:	391 x 374 x 64 mm (W x H x D)
Weight:	1816 g
Product code:	BNEET

BAKKER ELKHUIZEN



Health & Safety Regulations

Ergonomists advise not to carry loads heavier than 4-6 kilos with one hand, depending on the frequency and distance the load has to be carried and gender (Mital, et al, 1993). The weight of laptop, bag and further items in the bag commonly lies between 4 and 7 kg. This means that in quite a few cases the bag will be too heavy to carry it for a long time. In these situations a laptop trolley or backpack would be a good solution.