
# Cyber Power<sup>®</sup>

YOUR ULTIMATE ALLY IN POWER

# 6-OUTLET SURGE PROTECTOR

#### CSB604/CSB606/CSB606W

# USER MANUAL



Cyber Power Systems (USA), Inc. 4241 12th Avenue East, Suite 400 | Shakopee, MN 55379 CyberPowerSystems.com

## **FEATURES**

#### 1. ON/OFF Reset Control Switch and Circuit Breaker

Controls power to all outlets. The switch is also a 15 A breaker. When an overload occurs, it will automatically switch off. To resume operation, ensure the overload condition is removed and reset the surge protector by switching the unit ON.

2. Six Standard Outlets

#### SURGE PROTECTOR INSTRUCTIONS

- 1. Set power switch into the "OFF" position. Plug the surge protector into a standard grounding wall receptacle by fully inserting the plug and ensure that there are no exposed conductors.
- 2. Make sure electronic equipment is turned off before plugging into the surge protector outlets. Do not use extension cords to connect equipment to the surge protector.
- 3. Set the power switch into the "RESET" position. The surge protector will now be providing power and surge protection.
- 4. Connected equipment can now be turned on.

### CAUTION

#### TO REDUCE THE RISK OF ELECTRIC SHOCK:

Use only in dry locations and only indoors.

- DO NOT plug into another relocatable power tap.
- DO NOT "daisy chain" surge protectors.
- DO NOT use with any aquarium equipment.

DO NOT use if properly grounded outlets are not available.

**DO NOT** install this device if there is less than 10 meters (30 feet) of wire between the electrical outlet and electrical service panel.

DO NOT use for medical or life support equipment. This device features an internal protection that will disconnect the surge protective component at the end of its useful life, but it will maintain unprotected power to the load.

### FOR MORE INFORMATION

Visit CyberPowerSystems.com for more information regarding

- · Product information and certifications
- Product warranty
- · Connected equipment guarantee

#### CONFORMANCE APPROVALS

This device complies with Part 15 of the FCC Rules. generates, uses, and can radiate radio frequency energy and, if not Operation is subject to the following two conditions: (1) this installed and used in accordance with the instructions, may cause device may not cause harmful interference, and (2) this device must harmful interference to radio communications. accept any interference received, including interference that may However, there is no guarantee that interference will not occur in a cause undesired operation. particular installation. If this equipment does cause harmful interfer-This equipment has been tested and found to comply with the limits. ence to radio or television reception, which can be determined by

for a Class B digital device, pursuant to Part 15 of the ECC Rules. These limits are designed to provide reasonable protection against

# SPECIFICATIONS

Model Number:	CSB604/CSB606/CSB606W
Outlets:	6 Standard Outlets
Surge Protection:	900 Joules
Electrical Rating:	125 V / 15 A / 1875 W
UL Clamping Voltage:	UL 1449 3rd / 500 V (H-N, H-G, N-G)
3 AC Lines Protected:	H-N: 15,000 A, H-G: 15,000 A, N-G: 15,000 A
Response Time:	Less than 1 nanosecond
Attenuation:	Up to 32 dB
Circuit Breaker:	Resettable 15 Amp
EMI/RFI Filtration:	150 kHz to 100 MHz

AWARNING: This product can expose you to chemicals including bisphenol A (BPA) and styrene (ABS), which is known to the State of California to cause reproductive harm and cancer. For more information, go to www.P65Warnings.ca.gov.

### TROUBLESHOOTING

If the ON/OFF is switched OFF, the 15 Amp circuit breaker may have tripped. Examine your connected equipment and remove the device that is overloading the circuit. Then, turn the ON/OFF switch back to RESET.

### TECHNICAL SUPPORT

harmful interference in a residential installation. This equipment

turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:

Visit: CyberPowerSystems.com/support Toll-Free: 1-877-297-6937 © 2022 Cyber Power Systems (USA), Inc. All rights reserved. All other trademarks are the property of their respective owners.

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from
- that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment