

HighPoint

RocketMate 110

USB-C 3.2 20Gb/s to M.2 NVMe Enclosure



Quick Installation Guide

V1.00

Table of Contents

Introducing the HighPoint RocketMate 110.....	2
Kit Contents	2
System Requirement.....	2
Board Layout.....	3
Hardware Installation.....	4
Customer Support.....	7

Introducing the HighPoint RocketMate 110

The RocketMate 110 is a stand-alone, single-bay external M.2 NVMe enclosure designed for use with USB 3.2 20G connectivity.

The RocketMate 110 can be connected to any industry standard USB 3.2 controller or HBA, such as the HighPoint RocketU 1411C, RocketU 1444C, or RocketU 1488C, using the included 20G USB Type-C to Type-C cable.

Kit Contents

- 1x RocketMate 110 M.2 NVMe Enclosure
- 1x 0.5M USB-C 20Gb/s cable
- 1x Quick Installation Guide


System Requirement

- PC with Windows 8.1 and later
- macOS 10.13 and later
- Linux 3.10.0 and later

Board Layout



LED Indicator Status	
Connect to computer(with power supply)	Solid Blue
Drive idle	Solid Blue
Drive activity	Flash Blue
Sleep mode	No light
Drive "Safely Remove"	No light



Hardware Installation

1. Remove the top panel by unscrewing the 4 screws shown below (requires a Phillips screwdriver):



2. To install M.2 NVMe SSD's:
 01. Remove the screws (shown below).
 02. Carefully insert each M.2 SSD into the slot.
 03. Fasten down each SSD using the screws removed in step "01".



Note: Make sure the SSDs are carefully, but securely installed into each M.2 port. Loose connections can cause a variety of stability and performance issues, and may ultimately result in data loss.

3. Align the top panel and secure it to the enclosure using the screws removed in step 1.



Note: Make sure the top panel is aligned properly and secured firmly to the enclosure. A misaligned or loose panel may prevent the RocketMate from functioning properly, and/or prevent the enclosure from properly cooling the M.2 NVMe SSD's. Unsecure connections or overheating may result in damage to the NVMe media or controller hardware, degraded performance, or lead to unstable I/O and data loss.

4. Connect the enclosure to the host platform using the included USB Type-C to Type-C cable.



Customer Support

If you encounter any problems while utilizing this or any other HighPoint Technologies, Inc. product, feel free to contact our Customer Support Department.

Web Support:

<https://www.highpoint-tech.com/support-and-services>

HighPoint Technologies, Inc. websites:

<https://www.highpoint-tech.com>