



## DJI Air 3 Release Notes

---

Date:	2023.11.2
Aircraft Firmware:	v01.00.0700
Remote Controller Firmware:	v02.00.01.00 (DJI RC 2) v01.00.05.00 (DJI RC-N2)
DJI Fly App iOS:	v1.12.3
DJI Fly App Android:	v1.12.3

---

### What's New

- Fixed some bugs.

### Notes:

- Make sure to update the firmware of the aircraft, goggles, and motion controller before linking. The user can use DJI Assistant 2 (Consumer Drone Series) to update the firmware of each device individually, or use the DJI Fly app to update the firmware:
  - a. Aircraft: Update the firmware with the remote controller.
  - b. Goggles and Motion Controller: Power on the goggles and the motion controller. Connect the USB-C port of the goggles to a mobile device, run DJI Fly, and select **Profile > Device Management**. Locate the corresponding goggles. Select **Firmware Update** and follow the on-screen instructions to update the firmware.
- Camera settings will be reset after firmware update. Check the camera settings in DJI Fly.
- If update fails, restart aircraft, remote controller, and DJI Fly or DJI Assistant 2 (Consumer Drones Series), and retry.



## DJI Air 3 Release Notes

---

Date:	2023.09.25
Aircraft Firmware:	v01.00.0600
Remote Controller Firmware:	v02.00.00.00 (DJI RC 2) v01.00.05.00 (DJI RC-N2)
DJI Fly App iOS:	v1.12.0
DJI Fly App Android:	v1.12.0

---

### What's New

- Added support for taking five 48MP photos when using AEB and Burst Shooting.
- Added AR Home Point, AR Return-to-Home Route, and AR Aircraft Shadow.
- Added support for manually setting the Max Horizontal Speed in Normal mode to 15 m/s.
- Added support for DJI Goggles 2, DJI Goggles Integra, and DJI RC Motion 2. Visit <https://www.dji.com/air-3/downloads> and refer to the Consumer Drones and Goggles Compatibility Information for more information.

### Notes:

- Make sure to update the firmware of the aircraft, goggles, and motion controller before linking. The user can use DJI Assistant 2 (Consumer Drone Series) to update the firmware of each device individually, or use the DJI Fly app to update the firmware:
  - a. Aircraft: Update the firmware with the remote controller.
  - b. Goggles and Motion Controller: Power on the goggles and the motion controller. Connect the USB-C port of the goggles to a mobile device, run DJI Fly, and select **Profile > Device Management**. Locate the corresponding goggles. Select **Firmware Update** and follow the on-screen instructions to update the firmware.
- Camera settings will be reset after firmware update. Check the camera settings in DJI Fly.
- If update fails, restart aircraft, remote controller, and DJI Fly or DJI Assistant 2 (Consumer Drones Series), and retry.



## DJI Air 3 Release Notes

---

Date:	2023.08.28
Aircraft Firmware:	v01.00.0400
Remote Controller Firmware:	v01.00.06.00 (DJI RC 2) v01.00.04.00 (DJI RC-N2)
DJI Fly App iOS:	v1.11.0
DJI Fly App Android:	v1.11.0

---

### What's New

- Fixed some known issues.

### Notes:

- Camera settings will be reset after firmware update. Check the camera settings in DJI Fly.
- If update fails, restart aircraft, remote controller, and DJI Fly or DJI Assistant 2 (Consumer Drones Series), and retry.



## DJI Air 3 Release Notes

---

Date:	2023.07.25
Aircraft Firmware:	v01.00.0300
Remote Controller Firmware:	v01.00.05.00 (DJI RC 2) v01.00.03.00 (DJI RC-N2)
DJI Fly App iOS:	v1.11.0
DJI Fly App Android:	v1.11.0

---

### What's New

- Added support for taking 48MP photos.
- Added support for adjusting style parameters such as sharpness and noise reduction in video mode.
- Added support for shutter speed options of 2.5 seconds to 8 seconds for simulated long exposure when taking 12MP photos.
- Added support for using wide-angle lens.
- Optimized RTH in low-light environments.

### Notes:

- Camera settings will be reset after firmware update. Check the camera settings in DJI Fly.
- If update fails, restart aircraft, remote controller, and DJI Fly or DJI Assistant 2 (Consumer Drones Series), and retry.